AVR 1710, AVR 171, AVR 171/230C
AVR 1610, AVR 161, AVR 161/230C

Audio/video receiver

HDMI®
HIGH-DEFINITION MULTIMEDIA INTERFACE

Owner's Manual



harman/kardon®
by HARMAN

Table of Contents

INTRODUCTION 3
SUPPLIED ACCESSORIES 3
IMPORTANT SAFETY INFORMATION 3
PLACE THE AVR 3
FRONT-PANEL CONTROLS 4
REAR-PANEL CONNECTORS 6
SYSTEM REMOTE CONTROL FUNCTIONS 8
INTRODUCTION TO HOME THEATER 10
- TYPICAL HOME THEATER SYSTEM 10
- MULTICHANNEL AUDIO 10
- SURROUND MODES 10

PLACE YOUR SPEAKERS 11
- PLACING THE LEFT, CENTER AND RIGHT SPEAKERS 11
- PLACING THE SURROUND SPEAKERS IN A 5.1-CHANNEL SYSTEM 11
- AVR 1710/AVR 171 ONLY: PLACING THE SURROUND SPEAKERS IN A 7.1-CHANNEL SYSTEM 11
- AVR 1710/AVR 171 ONLY: PLACING FRONT HEIGHT SPEAKERS IN A 7.1-CHANNEL SYSTEM 11
- PLACING THE SUBWOOFER 11

TYPES OF HOME THEATER SYSTEM CONNECTIONS 12
- SPEAKER CONNECTIONS 12
- SUBWOOFER CONNECTIONS 12
- SOURCE DEVICE CONNECTIONS 12
- VIDEO CONNECTIONS 13
- RADIO CONNECTIONS 13
- NETWORK CONNECTOR 14
- USB PORT 14

MAKING CONNECTIONS 14
- CONNECT YOUR SPEAKERS 14
- CONNECT YOUR SUBWOOFER 15
- CONNECT YOUR TV OR VIDEO DISPLAY 15
- CONNECT YOUR AUDIO AND VIDEO SOURCE DEVICES 16
- USB AND IOS DEVICES 18
- CONNECT TO YOUR HOME NETWORK 18
- CONNECT THE RADIO ANTENNAS 18
- INSTALL A MULTIZONE SYSTEM 19
- CONNECT IR EQUIPMENT 20
- CONNECT THE TRIGGER OUTPUT 20
- CONNECT TO AC POWER 20

SET UP THE REMOTE CONTROL 21
- INSTALL THE BATTERIES IN THE REMOTE CONTROL 21
- PROGRAM THE REMOTE TO CONTROL YOUR SOURCE DEVICES AND TV 21

SET UP THE AVR 22
- TURN ON THE AVR 22
- USING THE ON-SCREEN MENU SYSTEM 22
- CONFIGURE THE AVR FOR YOUR SPEAKERS 22
- SET UP YOUR SOURCES 23
- SET UP THE NETWORK 24

OPERATING YOUR AVR 25
- HARMAN REMOTE APP 25
- CONTROLLING THE VOLUME 25
- MUTING THE SOUND 25
- LISTENING THROUGH HEADPHONES 25
- SELECTING A SOURCE 25
- SELECTING A SURROUND MODE 25
- LISTENING TO FM AND AM RADIO 26
- LISTENING TO MEDIA ON A USB DEVICE 26
- LISTENING TO AN IPOD/IPHONE/IPAD DEVICE 27
- LISTENING TO VTUNER (INTERNET RADIO) 28
- LISTENING TO MEDIA VIA YOUR HOME NETWORK 28
- PLAYING MEDIA FROM A ROKU STREAMING STICK 29

ADVANCED FUNCTIONS 29
- AUDIO PROCESSING AND SURROUND SOUND 29
- MANUAL SPEAKER SETUP 30
- LISTENING IN ZONE 2 33

SYSTEM SETTINGS 34
- SLEEP TIMER 34
- PROCESSOR RESET 34

TROUBLESHOOTING 35
SPECIFICATIONS 36
APPENDIX 37

Introduction

Thank you for choosing this Harman Kardon product!

For more than fifty years, the Harman Kardon mission has been to share a passion for music and entertainment, using leading-edge technology to achieve premium performance. Sidney Harman and Bernard Kardon invented the receiver, a single component designed to simplify home entertainment without compromising performance. Over the years, Harman Kardon products have become easier to use, while offering more features and sounding better than ever.

The AVR 1710/AVR 171 7.2-channel and AVR 1610/AVR 161 5.1-channel digital audio/video receivers (AVRs) continue this tradition with some of the most advanced audio and video processing capabilities yet, and a wealth of listening and viewing options.

To obtain the maximum enjoyment from your new AVR, please read this manual and refer back to it as you become more familiar with its features and their operation.

If you have any questions about this product, its installation or its operation, please contact your Harman Kardon retailer or custom installer, or visit the Web site at www.harmankardon.com.

Supplied Accessories

The following accessory items are supplied with your AVR. If any of these items are missing, please contact your Harman Kardon dealer or Harman Kardon customer service at www.harmankardon.com.

- System remote control
- EzSet/EQ™ microphone
- AM loop antenna
- FM wire antenna
- Two AAA batteries
- AC power cord (AVR 171/AVR 161 only)

IMPORTANT SAFETY INFORMATION

Verify Line Voltage Before Use

The AVR 1710 and AVR 1610 have been designed for use with 120-volt alternating current (AC). The AVR 171 and AVR 161 have been designed for use with 220 – 240-volt AC. Connection to a line voltage other than that for which your receiver is intended can create a safety and fire hazard and may damage the unit. If you have any questions about the voltage requirements for your specific model, or about the line voltage in your area, contact your selling dealer before plugging the unit into a wall outlet.

Do Not Use Extension Cords

To avoid safety hazards, use only the power cord supplied with your unit. We do not recommend that extension cords be used with this product. As with all electrical devices, do not run power cords under rugs or carpets, or place heavy objects on them. Damaged power cords should be replaced immediately by an authorized service center with a cord meeting factory specifications.

Handle the AC Power Cord Gently

When disconnecting the power cord from an AC outlet, always pull the plug; never pull the cord. If you do not intend to use your AVR for any considerable length of time, disconnect the plug from the AC outlet.

Do Not Open the Cabinet

There are no user-serviceable components inside this product. Opening the cabinet may present a shock hazard, and any modification to the product will void your warranty. If water or any metal object such as a paper clip, wire or staple accidentally falls inside the unit, disconnect it from the AC power source immediately, and consult an authorized service center.

CATV or Antenna Grounding (AVR 1710/AVR 1610)

If an outside antenna or cable system is connected to this product, be certain that it is grounded so as to provide some protection against voltage surges and static charges. Section 810 of the United States National Electrical Code, ANSI/NFPA No. 70-1984, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes and requirements of the grounding electrode.

NOTE TO CATV SYSTEM INSTALLER: This reminder is provided to call the CATV (cable TV) system installer's attention to article 820-40 of the NEC, which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as possible.

Place the AVR

- Place the AVR on a firm and level surface. Be certain that the surface and any mounting hardware can support the AVR's weight.
- Provide proper space above and below the AVR for ventilation. Recommended clearance distances are 30cm above the unit, 30cm behind the unit and 30cm on each side of the unit.
- If you install the AVR in a cabinet or other enclosed area, provide cooling air within the cabinet. Under some circumstances, a fan may be required.
- Do not obstruct the ventilation slots on the top of the AVR or place objects directly over them.
- Do not place the AVR directly on a carpeted surface.
- Do not place the AVR in moist or humid locations, in extremely hot or cold locations, in areas near heaters or heat registers, or in direct sunlight.

Front-Panel Controls



Front-Panel Controls, continued

Power indicator/Power button: The AVR has three different power modes:

- Off (Power indicator glows solid amber): The Off mode minimizes energy consumption when you're not using the AVR. When the AVR is off, it will not automatically turn on or play audio in response to an AirPlay stream from a networked device (AVR 1710/ AVR 171 only). When the AVR is off, pressing the Power button turns it on. To turn the AVR off when it is on, press the Power button for more than three seconds. The Front-Panel Display will indicate "Your device is switched off" for two seconds, then will switch off.

  NOTE: You can use the System Setup menu to set the AVR to automatically enter the off mode after it has been in the Sleep mode for a certain period of time. See *System Settings,* on page 34.

- **Sleep** (Power indicator glows solid amber and front-panel display indicates "Device sleep"): The Sleep mode powers-down some of the AVR's circuitry, but allows the AVR to automatically turn on and play audio in response to an AirPlay or DLNA DMR stream from a networked device (AVR 1710/AVR 171 only). When the AVR is in Sleep, pressing the Power button turns it on. To put the AVR into Sleep when it is on, press the Power button for less than three seconds. The front-panel display will indicate "Device sleep" while the AVR is in the Sleep mode.

  NOTE: The AVR will automatically enter the Sleep mode after 30 minutes of no audio signal or user control input , unless USB, iPod, Home Network, vTuner, AirPlay, or DLNA DMR is active. In these cases, the AVR will automatically enter the Sleep mode after the number of hours set in the Auto Power Off system setting. See System Settings, on page 34.

- **On** (Power indicator glows solid white): When the AVR is on it is fully operational.

Headphone jack/EzSet/EQ Mic input: Connect a 1/4" stereo headphone plug to this jack for private listening. This jack is also used to connect the supplied microphone for the EzSet/EQ setup procedure described in *Configure the AVR For Your Speakers,* on page 22.

Tuning Mode button (AVR 1710/AVR 1610 only): Press this button to toggle the radio between the manual (one frequency step at a time) and automatic (seeks frequencies with acceptable signal strength) FM tuning mode. The button also toggles the radio between stereo and mono modes when an FM station is tuned in.

RDS button (AVR 171/AVR 161 only): When listening to an FM radio station that broadcasts RDS information, this button activates the various RDS functions.

USB port: The USB port can be used to play audio files from an Apple iOS® device connected to the port, and can also be used to play MP3 and WMA audio files from a USB device inserted into the port. Insert the connector or device into the USB port oriented so it fits all the way into the port. You may insert or remove the connector or device at any time – there is no installation or ejection procedure.

You can also use the USB port to perform firmware upgrades. If an upgrade for the AVR's operating system is released in the future, you will be able to download it to the AVR using this port. Complete instructions will be provided at that time.

IMPORTANT: Do not connect a PC or other USB host/controller to this port, or you may damage both the AVR and the other device.

Channel Volume Adjust button: Press this button to activate the individual channel level adjustment. After pressing this button, use the Up/Down buttons/Tuning buttons to select the channel for adjustment and use theLeft/Right buttons to adjust the channel's level.

Audio Input button: Press this button to change the audio input connection for the current source. Use the Left/Right buttons to cycle through the available input connections, and press the Set button to assign the currently-displayed connection to the source.

IR sensor: This sensor receives infrared (IR) commands from the remote control. Make sure that the sensor is not blocked.

Set button: Press this button to select the currently highlighted menu item.

Left/Right buttons: Use these buttons to navigate the AVR's menus.

Front-panel display: Various messages appear on this two-line display in response to commands and changes in the incoming signal. In normal operation, the current source name appears on the upper line, while the active surround mode is displayed on the lower line. When the on-screen display menu system (OSD) is in use, the current menu settings appear.

Up/Down buttons/Tuning buttons: Use these buttons to navigate the AVR's menus. When the radio is the active source, use these buttons to tune stations according to the setting of the Tuning Mode button (see above).

Surround Mode Category button: Press this button to select a surround-sound category. Each press changes the surround-mode category: Auto Select, Virtual, Stereo, HARMAN NSP, Movie, Music and Video Game. To change the specific surround-sound mode within the category, use the Surround Mode Select buttons. See *Audio Processing and Surround Sound,* on page 29, for more information about surround modes.

Surround Mode Select buttons: After you have selected the desired surround-mode category, press these buttons to select a specific mode within the category, such as to change from Dolby® Pro Logic® II Movie mode to DTS® NEO:6 Cinema mode. Surround mode availability depends on the nature of the source input signal, i.e., digital versus analog, and the number of channels encoded within the signal.

Source Select buttons: Press these buttons to select the active source.

Volume knob: Turn this knob to raise or lower the volume.

Rear-Panel Connectors

AVR 1710/AVR 171



AVR 1610/AVR 161



Rear-Panel Connectors, continued

Digital Audio connectors: If your non-HDMI source devices have digital outputs, connect them to the AVR's digital audio connectors. NOTE: Make only one type of digital connection (HDMI, optical or coaxial) from each device. See *Connect Your Audio and Video Source Devices,* on page 16, for more information.

Radio Antenna connectors: Connect the supplied AM and FM antennas to their respective terminals for radio reception.

Analog Audio connectors: The following analog audio connectors are provided:

- **Analog Audio Input connectors:** Use the AVR's Analog Audio Input connectors for source devices that don't have HDMI or digital audio connectors. See *Connect Your Audio and Video Source Devices,* on page 16, for more information.
- **Zone 2 Out connectors (AVR 1710/AVR 171 only):** Connect these jacks to an external amplifier to power the speakers in the remote zone of a multizone system.

Network connector: If your home network is wired, use a Cat. 5 or Cat. 5E Ethernet cable (not supplied) to connect the AVR's Network connector to your home network to enjoy Internet radio and content from DLNA-compatible devices that are connected to the network. See *Connect to Your Home Network,* on page 18, for more information.

Subwoofer Pre-Out connector: Connect this jack to a powered subwoofer with a line-level input. See *Connect Your Subwoofer,* on page 15, for more information. NOTE: The AVR 1710 and AVR 171 have two subwoofer connectors.

HDMI Output connectors: If your TV has an HDMI connector and you are connecting HDMI source devices to the AVR, use an HDMI cable (not included) to connect it to the AVR's HDMI Out connector. **NOTE:** The AVR 1710 and AVR 171 have two HDMI Out connectors.

Notes on using the HDMI Output connector:

- When connecting a DVI-equipped display to the HDMI Out connector, use an HDMI-to-DVI adapter and make a separate audio connection.
- Make sure the HDMI-equipped display is HDCP (High-bandwidth Digital Content Protection)-compliant. If it isn't, do not connect it via an HDMI connection; use an analog video connection instead and make a separate audio connection.
- AVR 1710/AVR 171 only: If you have connected a 3D-capable TV to HDMI Out 1 and a 2D-capable TV to HDMI Out 2, the AVR will not allow 3D playback when both TVs are powered on. To watch 3D content, turn off the AVR and both TVs, then first turn on the 3D TV, then turn on the AVR, and finally turn on the 3D source device. Do NOT turn the 2D TV back on.

HDMI/MHL Input connector: If you have a Roku Streaming Stick or other MHL-capable device, connect it only to this HDMI/MHL In connector. If you do not have an MHL device you can use this connector for an HDMI-capable device.

Speaker connectors: Use two-conductor speaker wire to connect each set of terminals to the correct speaker. See *Connect Your Speakers,* on page 14, for more information.

NOTE: The Assigned Amp speaker connectors (AVR 1710/AVR 171 only) are used for the surround back or Front Height channels in a 7.1- channel home theater, or you can reassign them to a remote room for multizone operation or to front height channels for Dolby® Pro Logic IIz operation. See *Place Your Speakers*, on page 11, for more information.

Analog Video connectors: The following Analog Video connectors are provided:

- **Composite Video Input connectors:** Use composite video connectors for video source devices that don't have HDMI connectors. You will also need to make an audio connection from the source device to the AVR. See *Connect Your Audio and Video Source Devices,* on page 16, for more information.
- **Composite Video Monitor Out connector:** If your TV or video display does not have an HDMI connector, or if your TV does have an HDMI connector *but you are connecting some source devices with only composite video connectors,* use a composite video cable (not included) to connect the AVR's Composite Video Monitor Out connector to your TV 's composite video input.

HDMI® Input connectors: An HDMI connection transmits digital audio and video signals between devices. If your source devices have HDMI connectors, using them will provide the best possible video and audio performance quality. Since the HDMI cable carries both digital video and digital audio signals, you do not have to make any additional audio connections for devices you connect via the HDMI connection. See *Connect Your Audio and Video Source Devices,* on page 16, for more information.

IR and Trigger connector: The following IR and trigger connectors are provided:

- **IR In connectors:** When the IR sensor on the front panel is blocked (such as when the AVR is installed inside a cabinet), connect an optional IR receiver to the IR In jack.
- **12V Trigger connector:** This connector provides 12V DC whenever the AVR is on. It can be used to turn on and off other devices such as a powered subwoofer.
- **Zone 2 IR Input connector (AVR 1710/AVR 171 only):** Connect a remote IR receiver located in Zone 2 of a multizone system to this jack to control the AVR from the remote zone.

Fan Vents (AVR 1710/AVR 171 only): These vents are used by the AVR's fan to cool the system. Maintain a clearance of at least three inches (75mm) from the nearest surface to avoid overheating the unit. It is normal for the fan to remain off at most normal volume levels. An automatic temperature sensor turns the fan on only when it is needed.

IMPORTANT NOTE: Never block the fan vents. Doing so could allow the AVR to overheat to dangerous levels.

AC Input connector (AVR 171/AVR 161 only): After you have made and verified all other connections, plug the supplied AC power cord into this receptacle and into an *unswitched* wall outlet.

Power cord (AVR 1710/AVR 1610 only): After you have made and verified all other connections, plug the power cord into an *unswitched* wall outlet.

System Remote Control Functions



System Remote Control Functions, continued

In addition to controlling the AVR, the AVR remote is capable of controlling eight other devices, including an iPod/iPhone device connected to the AVR's front-panel USB port. During the installation process, you may program the codes for each of your source components into the remote. (See *Program the Remote to Control Your Source Devices and TV*, on page 21, for programming information.) To operate a component, press its Source Selector button to change the remote's control mode.

A button's function depends on which component is being controlled. See Table A13 in the Appendix for listings of the functions for each type of component. Most of the buttons on the remote have dedicated functions, although the precise codes transmitted vary depending on the specific device being controlled. Due to the wide variety of functions for various source devices, we have included only a few of the most-often used functions on the remote: number buttons, transport controls, television-channel control, menu access and power on and off. Buttons dedicated to the AVR – AVR Power On/Off, Surround Modes, Volume, Mute, Delay and Sleep Settings – are available at any time, even when the remote is controlling another device.

Power On/Power Off buttons: Press these buttons to turn the AVR on and put it into Sleep or turn it off. See *Power Indicator/Power Button,* on page 4, for more information.

IR Transmitter: As buttons are pressed on the remote, infrared codes are emitted through this lens.

Zone 2 button (AVR 1710/AVR 171 only): Use this button to select whether the AVR commands will affect the main listening area (Zone 1) or the remote zone of a multizone system (Zone 2). When the remote is in the Zone 2 control mode, the Zone 2 button will illuminate whenever you press a button.

Mute button: Press this button to mute the AVR's speaker-output connectors and headphone jack. To restore the sound, press this button or adjust the volume.

Source Selector buttons: Press one of these buttons to select a source device, e.g., Disc, Cable/Sat, Radio, etc. This action will also turn on the AVR and switch the remote's control mode to operate the selected source device.

- The first press of the Radio button switches the AVR to the last-used tuner band (AM or FM). Each successive press changes the band.
- The first press of the USB button switches the AVR to the last-used source (USB or iPod). Each successive press cycles between the two sources.
- The first press of the Network button switches the AVR to the last-used source (Network or vTuner). Each successive press cycles between the two sources.

AVR button: Press to put the remote into the AVR control mode.

Surround Modes button: Press this button to access the Surround Modes submenu. Select a surround-mode category: Auto Select, Virtual Surround, Stereo, HARMAN NSP, Movie, Music or Game. When you select the category, it is highlighted and the surround mode changes.

To change the surround mode for the selected category navigate to the Surround Mode menu in the AVR's on-screen display menu, select the desired category, and use the Left/Right buttons to select one of the available surround modes. See the *Advanced Functions* section, on page 29, for more information.

OSD/Menu button: When the remote is controlling the AVR, press this button to display the AVR's on-screen display (OSD) menu. This button is also used within the tuner menus and an iPod connected to the AVR's front-panel USB port, and is also used to display the main menu on some source devices.

Up/Down/Left/Right buttons: These buttons are used to navigate the menu system and to operate the tuner.

OK button: This button is used to select items from the menu system.

Back/Exit button: Press this button to return to the previous menu or to exit the menu system.

Home button: Press this button to display the Home menu for a Roku Streaming Stick™ that is connected to the AVR's MHL/HDMI connector.

Number buttons: Use these buttons to enter numbers for radio-station frequencies or to select station presets.

Clear button: Press this button to clear a radio station frequency you have started to enter.

Test Tone button: Press this button to activate test noise that will circulate through each speaker, allowing you to adjust the individual speaker levels. Use the Up/Down buttons to switch the noise to a different speaker and use the Left/Right buttons to change the volume of the speaker the noise is playing through.

Delay Adjust button: Pressing this button lets you adjust two different types of delay settings (use the Up/Down buttons to cycle through the settings):

- Lip Sync: This setting lets you resynchronize the audio and video signals from a source to eliminate a "lip sync" problem. Lip-sync issues can occur when the video portion of a signal undergoes additional processing in either the source device or the video display. Use the Left/Right buttons to delay the audio by up to 180ms.
- Distance: These settings let you set the delay for each speaker to compensate for the different distances they may be from the listening position. Use the Up/Down buttons to cycle through each of the system's speakers, and use the Left/Right buttons to set the distance each speaker is from the listening position. See *Manual Speaker Setup,* on page 30, for more information.

Sleep button: Press this button to activate the sleep timer, which turns off the receiver after a programmed period of time. Each press increases the time by 10 minutes, up to 90 minutes – ending with the "Sleep Off" message.

Volume Up/Down buttons: Press these buttons to raise or lower the volume.

Channel/Tuner buttons: When radio has been selected, press these buttons to select a preset radio station. While operating a cable, satellite or HDTV set-top box or a television, press these buttons to change channels.

Info/Option button: Press to display the available option settings for the current source.

Display Dimmer button: Press this button to dim the AVR's front-panel Message Display partially or fully.

Preset Scan button: When Radio is the selected source, press this button to play each of your preset radio stations in order for five seconds. Pressing the button again to remain tuned to the current station.

RDS button (AVR 171/AVR 161 only): When listening to an FM radio station that broadcasts RDS information, this button activates the various RDS functions.

Direct button: Press this button to directly tune to a radio station by using the Number buttons to enter its frequency.

Memory button: Press this button to save the current radio or vTuner station as a preset.

Transport Control buttons: These buttons are used to control source devices.

Previous Channel button: When TV is the selected source, press this button to switch to the previously-tuned channel.

Introduction to Home Theater

This introductory section will help you to familiarize yourself with some basic concepts unique to multichannel surround-sound receivers, which will make it easier for you to set up and operate your AVR.

Typical Home Theater System

A home theater typically includes an audio/video receiver, which controls the system and supplies amplification for the loudspeakers; a disc player; a source component for television broadcasts (cable box, satellite dish receiver, HDTV tuner or antenna connected to the TV); a TV or video display; and multiple loudspeakers.

Multichannel Audio

The main benefit of a home theater system is its ability to produce "surround sound." Surround sound uses multiple speakers and amplifier channels to immerse you in the audio/video presentation for a dramatically increased sense of realism.

Your AVR may have up to seven main speakers connected directly to it, plus a subwoofer. Each main speaker is powered by its own amplifier channel inside the AVR. A system with more than two speakers is called a multichannel system. The different main speaker types in a home theater system are:

Front Left and Right: The front left and right speakers are used as in a two-channel system. In many surround-sound modes, these speakers are secondary, while the main action, especially dialogue, is reproduced by the center speaker.

Center: When you are watching movies and television programs, the center speaker reproduces most of the dialogue and other soundtrack information, anchoring it with the picture. When you are listening to a musical program, the center speaker helps to create a seamless front soundstage, creating a realistic "you-are-there" listening experience.

Surround Left and Right: The surround left and right speakers produce ambient sounds that help create a realistic and immersive surround-sound environment. They also help recreate directional sound effects such as aircraft flyovers.

Many people expect the surround speakers to play as loudly as the front speakers. Although you will calibrate all of the speakers in your system to sound equally loud at the listening position, most artists use the surround speakers for ambient effects only, and they create their programs to steer relatively little sound to these speakers.

Subwoofer: A subwoofer is designed to play only the lowest frequencies (the deep bass). It augments smaller, limited-range main speakers that are usually used for the other channels. Many digital-format programs, such as movies recorded in Dolby Digital, contain a low-frequency effects (LFE) channel that is directed to the subwoofer. The LFE channel packs the punch of a rumbling train or airplane, or the power of an explosion, adding realism and excitement to your home theater. Some people use two subwoofers for additional power and for even distribution of the sound.

Surround Back Left and Right (AVR 1710/AVR 171 only): Surround back channel speakers are used with surround modes such as the Dolby Digital EX, Dolby Digital Plus, Dolby TrueHD, DTS-ES® (Discrete and Matrix), DTS-HD™ High Resolution Audio, DTS-HD Master Audio™ and Logic 7® 7.1 modes that are designed for 7.1-channel systems.

Front Height Left and Right (AVR 1710/AVR 171 only): Your AVR includes Dolby Pro Logic IIz decoding, which uses the AVR's Assigned Amp channels as front height channels. The addition of front height channels – an additional pair of speakers positioned above the front left and right speakers – produces a surround-sound experience with added depth and dimension by creating lifelike sound that comes at you from varying heights.

NOTE: You can set up your system to use either surround back speakers or front height speakers; you cannot use both.

The surround back and front height channel speakers are optional. If your system does not include surround back or front height speakers, you can set up your AVR with a 5.1-channel surround-sound system in the main listening area, and you can reassign the surround back channel amplifiers to power loudspeakers located in another room in a multizone system.

Surround Modes

There are different theories as to the best way to present surround sound and to distribute each audio channel's sounds to the surround-sound system's speakers. A variety of algorithms have been developed in an effort to recreate the way we hear sounds in the real world, providing you with a rich variety of options. Several companies have developed different surround-sound technologies, all of which can be accurately reproduced by your AVR:

- **Dolby Laboratories:** Dolby TrueHD, Dolby Digital Plus, Dolby Digital, Dolby Digital EX, Dolby Pro Logic® II, Dolby Pro Logic® IIx and IIz (AVR 170/AVR 171 only).
- **DTS:** DTS-HD High Resolution Audio, DTS-HD Master Audio, DTS, DTS-ES (Discrete and Matrix), DTS Neo:6®, DTS 96/24™.
- **HARMAN International:** HARMAN NSP, HARMAN Headphone.
- **Stereo Modes:** Generic modes that expand upon conventional two-channel stereo, including 5CH Stereo and 7CH Stereo (AVR 1710/AVR 171 only)..

Appendix Table A10, on page 41, contains detailed explanations of the different surround-sound options available on your AVR. Digital surround-sound modes, such as the Dolby Digital and DTS modes, are available only on specially encoded programs, such as those available via HDTV, DVD and Blu-ray Disc media and digital cable or satellite television. Other surround modes may be used with digital and analog signals to create a different surround presentation or to use a different number of speakers. Surround-mode selection depends upon the number of speakers in your system, the program you are watching or listening to, and your personal tastes.

Place Your Speakers

Determine the locations for your system's speakers according to their manufacturer's directions and the layout of your listening room. Use the illustrations below as a guide for 7.1-channel systems (AVR 1710/AVR 171 only) and 5.1-channel systems.

To create the most realistic surround-sound environment possible, you should place your speakers in a circle with the listening position at its center. You should angle each speaker so it directly faces the listening position. Use the diagrams below as a guide.



Speaker Positioning for 5.1-Channel Systems





* FHL and FHR speakers should be at least 3 ft (0.9m) above the FL and FR speakers.

Speaker Positioning for 7.1-Channel Systems (AVR 1710/AVR 171 only)
(Middle: with Surround Back Speakers; Bottom: with Front Height Speakers)

NOTE: In a 7.1-channel system, you must choose to use either surround back speakers or front height speakers – you cannot use both simultaneously.

Placing the Left, Center and Right Speakers

Place the center speaker either on top of, below or mounted on the wall above or below the TV or video display screen. Place the front left and right speakers along the circle, about 30 degrees from the center speaker and angled toward the listener.

Place the front left, front right and center speakers at the same height, preferably at about the same height as the listener's ears. The center speaker should be no more than 2 feet (0.6m) above or below the left/right speakers. If you're using only two speakers with your AVR, place them in the front left and right positions.

Placing the Surround Speakers in a 5.1-Channel System

You should place the left and right surround speakers approximately 110 degrees from the center speaker, slightly behind and angled toward the listener. Alternatively, place them behind the listener, with each surround speaker facing the opposite-side front speaker. You should place the surround speakers 2 feet – 6 feet (0.6m – 1.8m) higher than the listener's ears.

AVR 1710/AVR 171 only: Placing the Surround Speakers in a 7.1-Channel System

In a 7.1-channel system, place the side surround speakers 90 degrees from the center speaker, directly to either side of the listening position. Place the surround back left and right speakers 150 degrees from the center speaker, directly facing the opposite-side front speaker. You should place all the surround speakers 2 feet – 6 feet (0.6m – 1.8m) higher than the listener's ears.

AVR 1710/AVR 171 only: Placing Front Height Speakers in a 7.1-Channel System

Your AVR includes Dolby Pro Logic IIz decoding, which uses the AVR's Assigned Amp channels as front height channels. The addition of front height channels – an additional pair of speakers positioned above the front left and right speakers – produces a surround-sound experience with added depth and dimension by creating lifelike sound that comes at you from varying heights.

We recommend placing front height speakers at least 3 feet (0.9m) higher than the front left and front right speakers, and directly above or farther apart than the front left and right speakers. The higher and further apart you place the front height speakers, the more you should angle them down and in toward the listening position.

NOTE: Your receiver will sound its best when the same model or brand of loudspeaker is used for all positions.

Placing the Subwoofer

Because a room's shape and volume can have a dramatic effect on a subwoofer's performance, it is best to experiment with placement so that you will find the location that produces the best results in your particular listening room. With that in mind, these rules will help you get started:

- Placing the subwoofer next to a wall generally will increase the amount of bass in the room.
- Placing the subwoofer in a corner generally will maximize the amount of bass in the room.
- In many rooms, placing the subwoofer along the same plane as the left and right speakers can produce the best integration between the sound of the subwoofer and that of the left and right speakers.
- In some rooms, the best performance could even result from placing the subwoofer behind the listening position.

A good way to determine the best location for the subwoofer is by temporarily placing it in the listening position and playing music with strong bass content. Move around to various locations in the room while the system is playing (putting your ears where the subwoofer would be placed), and listen until you find the location where the bass performance is best. Place the subwoofer in that location.

Types of Home Theater System Connections

There are different types of audio and video connections used to connect the AVR to your speakers, your TV or video display, and your source devices. The Consumer Electronics Association has established the CEA® color-coding standard.

Analog Audio Connection	Color
Front Left/Right	White/Red
Center	Green
Surround Left/Right	Blue/Gray
Surround Back/Front Height Left/Right	Brown/Tan
Subwoofer	Purple

Digital Audio Connection	Color
Coaxial (input or output)	Orange
Optical Input	Black

Analog Video Connection	Color
Composite Video	Yellow

Speaker Connections

Speaker cables carry an amplified signal from the AVR's speaker terminals to each loudspeaker. They contain two wire conductors, or leads, that are differentiated in some way, such as with colors or stripes.

The differentiation helps you maintain proper polarity, without which your system's low-frequency performance can suffer. Each speaker is connected to the AVR's speaker-output terminals using two wires, one positive (+) and one negative (–). Always connect the positive terminal on the speaker, which is usually colored red, to the positive terminal on the receiver, which is colored as indicated in the Connection Color Guide Table, above. The negative terminals on the speakers and the AVR are black.

Your AVR uses binding-post speaker terminals that can accept bare-wire cables or banana plugs. Bare-wire cables are installed as shown below:



1. Unscrew Cap 2. Insert Bare Wire 3. Tighten Cap

Banana plugs are inserted into the hole in the middle of the terminal cap, as shown below:

A. Tighten Cap B. Insert Banana Connector into Hole in Cap



Always connect the colored (+) terminal on the AVR to the (+) terminal on the speaker (usually red), and the black (–) terminal on the AVR to the (–) terminal on the speaker (usually black).

IMPORTANT: Make sure the (+) and (–) bare wires do not touch each other or the other terminal. Touching wires can cause a short circuit that can damage your receiver or amplifier.

Subwoofer Connections

The subwoofer is a speaker dedicated to reproducing only the low (bass) frequencies, which require more power. To obtain the best results, most speaker manufacturers offer powered subwoofers that contain their own amplifiers. Use a single RCA audio cable to make a line-level (non-amplified) connection from the AVR's Subwoofer connector to a corresponding input jack on the subwoofer. (The AVR 1710 and AVR 171 have two subwoofer output connections.)



Although the AVR's purple subwoofer output looks similar to a full-range analog audio jack, it is filtered so that only the low frequencies pass through it. Don't connect this output to any device other than a subwoofer.

Source Device Connections

Audio and video signals originate in source devices (components where a playback signal originates) such as your Blu-ray Disc or DVD player, CD player, DVR (digital video recorder) or other recorder, tape deck, game console, cable or satellite television tuner, an iPod or iPhone (connected to the AVR's USB port) or an MP3 player. The AVR's FM/AM tuner also counts as a source, even though no external connections are needed other than the FM and AM antennas. Separate connections are required for the audio and video portions of the source device's signal, except for digital HDMI connections. The types of connections you use will depend upon the capabilities of the source device and of your TV or video display.

Digital Audio Connections – HDMI

There are two types of audio connections – digital and analog. Digital audio signals are required for listening to sources encoded with digital surround modes, such as Dolby Digital and DTS, or for uncompressed PCM digital audio. Your AVR has three types of digital audio connections: HDMI, coaxial and optical. Do not use more than one type of digital audio connection for each source device. However, it's okay to make both analog and digital audio connections to the same source.

Your AVR is equipped with rear-panel HDMI input and output connectors. HDMI technology enables high-definition digital audio and video information to be carried using a single cable, delivering the highest quality picture and sound. If your TV or video display device has an HDMI input connector, make a single HDMI connection from each HDMI-enabled source device to the AVR. Usually, a separate digital audio connection is not required.

The AVR's HDMI output connection contains an Audio Return Channel (ARC) that carries a digital audio signal from your TV or video display back to the AVR. It allows you to listen to HDMI devices that are connected directly to your TV (such as an Internet connection) without making an additional connection from the device to the AVR. The ARC signal is active when the TV source is selected. See *System Settings*, on page 34, for more information. (The AVR 1710 and AVR 171 have two HDMI output connections. Only HDMI Out 1 has ARC.)

The HDMI connector is shaped for easy plug-in (see illustration, below), and HDMI cable runs are limited to about 10 feet (3m). If your video display has a DVI input and is HDCP-compliant, use an HDMI-to-DVI adapter (not included), and make a separate audio connection.



Digital Audio Connections – Coaxial

Coaxial digital audio jacks are usually color-coded in orange. Although they look like standard RCA-type analog jacks, you should not connect coaxial digital audio outputs to analog inputs or vice versa.



Digital Audio Connections – Optical

Optical digital audio connectors are normally covered by a shutter to protect them from dust. The shutter opens as the cable is inserted. Optical input connectors are color-coded using a black shutter.



Analog Audio Connections

Two-channel analog connections require a stereo audio cable, with one connector for the left channel (white) and one for the right channel (red). These two connectors are attached to each other.



For source devices that have both digital and analog audio outputs, you may make both connections. If you are going to be setting up a multizone system (AVR 1710/AVR 171 only), remember that Zone 2 is an audio-only zone (the AVR does not have a Zone 2 video output). Therefore, make analog connections for any audio source devices (such as a CD changer) that you will want available for listening in Zone 2 at all times.

Video Connections

Many source devices output both audio and video signals (e.g., Blu-ray Disc, DVD player, cable television box, HDTV tuner, satellite box, VCR, DVR). In addition to an audio connection as described above, make a video connection for each of these source devices. Make only one type of video connection for each device.

Digital Video Connections

If you have already connected a source device to one of the AVR's HDMI input connectors, you have automatically made a video connection for that device, since the HDMI cable carries both digital audio and digital video signals.

Analog Video Connections – Composite Video

Composite video is the most commonly available analog video connection. Both the chrominance (color) and luminance (intensity) components of the video signal are transmitted using a single cable. The jack is usually color-coded yellow and looks like an analog audio jack. Do not connect a composite video jack to an analog audio or coaxial digital audio jack, or vice versa.



Radio Connections

Your AVR uses separate terminals for the included FM and AM antennas. The FM antenna uses a 75-ohm F-connector.



The AM antenna connector uses spring-clip terminals. After assembling the antenna as shown below, press the levers to open the connectors, insert the bare wires into the openings, and release the levers to secure the wires. The antenna wires are not polarized, so you can insert either wire into either connector.

Network Connector

The AVR's Network connector allows you to enjoy Internet radio or content from other DLNA- or Airplay-compatible devices that are connected to the same network. Use a Cat. 5 or Cat. 5E Ethernet cable to connect the AVR's RJ-45 connector to your home network.



USB Port

The AVR can play audio files from an Apple iOS® device connected to the USB port, and allows you to control the iOS device via the AVR remote control. The AVR can also play MP3 and WMA audio files from a USB device inserted into the USB port. Insert the connector or device into the USB port oriented so it fits all the way into the port. You may insert or remove the connector or device at any time – there is no installation or ejection procedure.

The USB port on your AVR is also used to perform firmware upgrades. If an upgrade for the AVR's operating system is released in the future, you will be able to download it to the AVR using this port. Complete instructions will be provided at that time.



IMPORTANT: Do not connect a PC or other USB host/controller to the AVR's USB port, or you may damage both the AVR and the other device.

Making Connections

CAUTION: Before making any connections to the audio/video receiver, ensure that the AVR's AC cord is unplugged from the AC outlet. Making connections with the receiver plugged in and turned on could damage the speakers.

Connect Your Speakers

After you have placed your loudspeakers in the room as explained in *Place Your Speakers*, on page 11, connect each speaker to its color-coded terminal on the AVR as explained in *Speaker Connections*, on page 12. Connect the speakers as shown in the illustration.



NOTE: If you installed front height speakers, connect them as shown for the SBL and SBR speakers.

Connect Your Subwoofer

Use a single RCA audio cable to connect the AVR's Subwoofer connector to your subwoofer as explained in *Subwoofer Connections*, on page 12. NOTE: The AVR 1710 and AVR 171 provide connections for two subwoofers. See *Manual Speaker Setup: Number of Speakers,* on page 31, for information about activating the two subwoofer outputs. Consult your subwoofer's user manual for specific information about making connections to it.



Connect Your TV or Video Display

If your TV has an HDMI connector and you have HDMI source devices: Use an HDMI cable (not included) to connect it to the AVR's HDMI Monitor Out connector. The AVR 1710 and AVR 171 provide HDMI connections for two TVs (only HDMI Out 1 has ARC and enables you to view the AVR's on-screen menus). This will provide the best possible picture quality.



If your TV does not have an HDMI connector o*r if your TV does have an HDMI connector but you are connecting some source devices with only composite video connectors:* Use a composite video cable (not included) to connect the AVR's Composite Monitor Out connector to your TV's composite video connector.



NOTE: If you use only the composite video connection to your TV, you will not be able to view the AVR's on-screen menus.

Connect Your Audio and Video Source Devices

Source devices are components where a playback signal originates, e.g. a Blu-ray Disc™ or DVD player; a cable, satellite or HDTV tuner; etc. Your AVR has several different types of input connectors for your audio and video source devices: HDMI, composite video, optical digital audio, coaxial digital audio and analog audio. The connectors are not labeled for specific types of source devices; they are labeled numerically, so you can connect your devices according to your individual system's makeup.

Your AVR's various source buttons have default assignments to different input connectors (listed in the "Default Connector(s)" column of the table below). For ease of setup, you should connect each source device to the connector where the corresponding default source button is assigned (e.g., connect your Blu-ray Disc player to HDMI 2).

However, you can connect your source devices as you wish and re-assign any of the input connections to any of the Source Buttons listed in the table according to where you actually connect each of your source devices.

As you connect your various source devices, fill out the "Connected Component" column in the table – it will make it easier for you to assign the various source buttons after you have completed making all of the connections. (You will make any changes to the source-button assignments and fill in the "Assigned Connector(s)" column later in the setup process.)

Note: You cannot assign connectors to the Network, Radio, TV and USB source buttons.

Source Buttons and Assigned Connectors

Source Button	Default Connector(s)	Assigned Connector(s)	Connected Device
MHL	HDMI 1		
Disc	HDMI 2		
Cable-Sat	HDMI 3		
STB	HDMI 4		
Game	HDMI 5		
Audio	None/Analog 2		
Aux	Composite 1/Analog 1		

Monitor Output Connector	_____	_____	Connected Device
HDMI Out 1	_____	_____	
HDMI Out 2 (AVR 1710/AVR 171 only)	_____	_____	
Composite Video Monitor Out	_____	_____	

Roku Streaming Stick™:

If you have a Roku Streaming Stick device, insert it into the AVR's HDMI/MHL In connector. NOTE: Do not insert the Roku Streaming Stick device into any other HDMI In connector.



Roku® Streaming Stick

Connect Your HDMI Devices

If any of your source devices have HDMI connectors, using them will provide the best possible video and audio performance quality. Since the HDMI cable carries both digital video and digital audio signals, you do not have to make any additional audio connections for devices you connect via an HDMI cable.



HDMI-Equipped Source Device

NOTE: If you have HDMI devices (such as an Internet connection) already connected directly to your TV, you can feed their sound to the AVR via the HDMI Out connector's Audio Return Channel, and they will not require additional connections to the AVR. AVR 1710/AVR 171 only: Only the HDMI Out 1 connection has the Audio Return Channel.

Connect Your Composite Video Devices

Use composite video connectors for video source devices that don't have HDMI connectors. You will also need to make an audio connection from the source device to the AVR.



Composite-Equipped Source Device

Connect Your Optical Digital Audio Devices

If your non-HDMI source devices have optical digital outputs, connect them to the AVR's optical digital audio connectors. **NOTE:** Make only one type of digital connection (HDMI, optical or coaxial) from each device.



Optical-Equipped Source Device

Connect Your Coaxial Digital Audio Devices

If your non-HDMI source device has a coaxial digital output, connect it to the AVR's coaxial digital audio connector. **NOTE:** Make only one type of digital connection (HDMI, optical or coaxial) from each device.



Connect Your Analog Audio Devices

Use the AVR's analog audio connectors for source devices that don't have HDMI or digital audio connectors. **NOTE:** If you're installing a multizone system, make analog audio connections for any source devices you want to be able to listen to in Zone 2. Only analog sources are available in Zone 2.



USB and iOS Devices

Use the AVR's front-panel USB port to connect an iPod, iPhone or iPad using an Apple cable (not supplied) or to directly connect a USB memory stick. You can play audio files from the device or memory stick and use the AVR's remote to control playback.



Connect to Your Home Network

Use a Cat. 5 or Cat. 5E cable (not supplied) to connect the AVR's Network connector to your home network to enjoy Internet radio and content from DLNA-compatible devices that are connected to the network.



Connect the Radio Antennas

- Connect the supplied FM antenna to the AVR's FM 75Ω antenna connector. For the best reception, extend the FM antenna as far as possible.
- Bend and fold the base of the supplied AM antenna as shown and connect the antenna wires to the AVR's AM and Gnd connectors. (You can connect either wire to either connector.) Rotate the antenna as necessary to minimize background noise.



AVR 1710/AVR 171 only: Install a Multizone System

IMPORTANT SAFETY NOTE: Installing a multizone system typically requires running cables inside walls. Always comply with the appropriate safety codes when installing concealed wiring, particularly all applicable building codes. Failure to do so may present a safety hazard. If you have any doubt about your ability to work with electrical wiring, hire a licensed electrician or custom installer to install the multizone system.

NOTE: Only the following analog audio sources are available to Zone 2: the internal radio, an iPod/iPhone device or a USB memory device inserted in the AVR's USB port and up to two source devices connected to the rear-panel Analog Audio In 1 and 2 connectors.

Your AVR offers two different methods of distributing audio to other areas in your home. Each requires different connections:

A. Connect the Zone 2 speakers directly to the Assigned Amp Speaker Output connectors. Assign the Assigned Amp channels to power the Zone 2 speakers (see *Manual Speaker Setup*, on page 30). This method allows you to power a single pair of speakers for Zone 2.

This method offers the benefit of reduced cost and complexity, but your home theater system will be limited to 5.1 channels – the AVR will automatically downmix the playback of programs recorded in 6.1 or 7.1 channels to 5.1 channels.



B. Connect an external amplifier to the AVR's Zone 2 Out connectors. This method offers the benefit of retaining a 7.1-channel home theater in the main room simultaneously with multizone operation, although it does require an additional amplifier for Zone 2.

We recommend that you place the Zone 2 amplifier in the same room as the AVR so that you can use a short length of stereo audio cable along with a long run of speaker wire to the remote room. A long run of stereo audio cable would increase the chance of signal degradation. Depending on your Zone 2 amplifier you can distribute the audio signal to a single pair of speakers or to several pairs placed in different rooms.



Connect IR Equipment

The AVR is equipped with a Remote IR Input connector that lets you remotely control the AVR in a variety of situations:

- When you place the AVR inside a cabinet or facing away from the listener, connect an external IR receiver, such as the optional Harman Kardon HE 1000, to the AVR's IR In jack.



- If you install a multizone system (AVR 1710/AVR 171 only), connect an IR control device to the Zone 2 IR In connector for remote-room control of the multizone system, source devices and volume in the remote zone.



If a source device is shared with the main listening area, any control commands issued to that source will also affect the main room.

Connect the Trigger Output

If your system has equipment that can be controlled by a DC trigger signal, connect it to the AVR's Trigger Out connector with a mono 1/8-inch (3.5mm) mini-plug interconnect cable. The AVR will supply a 12V DC (100mA) trigger signal at this connection whenever it is powered on.



Connect to AC Power

AVR 171/AVR 161:

Connect the supplied AC power cord to the AVR's AC Input connector and then to a working, non-switched AC power outlet.



AVR 1710/AVR 1610:

Connect the AVR's power cord to a working, non-switched AC power outlet.



Set Up the Remote Control

Install the Batteries in the Remote Control

Remove the remote control's battery cover, insert the two supplied AAA batteries as shown in the illustration, and replace the battery cover.



Program the Remote to Control Your Source Devices and TV

You can program your AVR remote to control many brands and models of audio/video source devices and TVs. The remote is also ready to operate your iPod or iPhone when it is connected to the AVR's front-panel USB port.

Each of the remote's Source Selector buttons has been preprogrammed to control certain types of source devices:

Cable/Sat: Controls cable TV and satellite TV tuner boxes

Disc: Controls Blu-ray Disc and DVD players

Radio: Controls the AVR's built-in FM/AM tuner

TV: Controls TVs and video displays

USB: Browses compatible media on an Apple iOS device that is connected to, or a USB device that is inserted in the AVR's USB port Note: Does not require programming.

DVR: Controls TiVo® recorders

Game: Controls video-game consoles

Media Server: Controls media servers

Network: Browses compatible media on DLNA-compatible devices connected to your home network and on vTuner (Internet Radio). Note: Does not require programming.

AUX: Controls HDTV tuner boxes, CD players, VCRs and PVDs.

Although the Source Selector buttons are preprogrammed for the device types listed above, you can reassign a Source Selector button to a different device type. See *Reassigning a Source Selector Button for a Different Device Type*, on page 21.

Once you have programmed the remote, you can switch the remote's control mode to access the functions for a particular device by pressing the remote's Source Selector button for that device.

Follow these steps to program the Source Selector buttons for your source devices:

1. Turn on the source device you want to program the remote to control.
2. Look up the code numbers for the device in Tables A12-A22 in the Appendix. Write all the applicable code numbers in a convenient place.
3. Press the Source Selector button for the device and hold it as it glows red, goes dark and glows red again. Then release it. The remote is now in the Programming mode.

NOTE: The remote will remain in the Programming mode for 20 seconds. If you do not complete Step 4 within 20 seconds, the remote will exit the Programming mode, and you will need to repeat Step 3.

4. Aim the remote at the source device and use the remote's Number buttons to enter a code number from Step 1, above.
   a) If the device turns off, press the Source Selector button again to save the code. The Source Selector button will flash, and the remote will exit the Programming mode.
   b) If the device does not turn off, enter another code number.
   c) If you run out of code numbers for a device, you can search through all of the codes in the remote's library for dervices of its type by pressing the remote's Up button repeatedly until the device turns off. When it does, press the Source Selector button to save the code.
5. Check that other functions control the device correctly. Sometimes manufacturers use the same Power code for several models, while other function codes vary. Repeat this process until you've programmed a satisfactory code set that operates most of the device's functions.
6. If you searched through the remote's code library to find the code, you can find out which code number you have programmed by pressing and holding the Source Selector button to re-enter the Programming Mode. Then press the remote's OK Button, and the Source Selector button will flash in the code sequence. One flash represents "1," two flashes for "2," and so forth. A series of quick flashes represents "0." Record the code number programmed for each device in Table A7 in the Appendix.

Repeat Steps 3 – 6 for each source device you want to control with the AVR remote.

Reassigning a Source Selector Button for a Different Device Type

You can reassign a Source Button to control a different device type (for example, you can program the Media Server button to control a DVD player).

1. Turn on the source device you want the remote to control.
2. Look up the code numbers for the device in Tables A12-A22 in the Appendix. Write all the applicable code numbers in a convenient place.
3. Press the Source Selector button you want to override and hold it for three seconds as it glows red, goes dark and glows red again. Then release it. The remote is now in the Programming mode.
4. Press the Source Selector button that corresponds to the source device's type (i.e., for a DVD player, press the Blu-ray button). The Source Selector button you pressed in Step 3 will flash once.
5. Aim the remote at the source device and use the remote's Number buttons to enter a code number from Step 2, above.
   a) If the device turns off, press the Source Selector button from Step 3 again to save the code. The Source Selector button will flash, and the remote will exit the Programming mode.
   b) If the device does not turn off, enter another code number.
   c) If you run out of code numbers for a device, you can search through all of the codes in the remote's library for devices of its type by pressing the remote's Up button repeatedly until the device turns off. When it does, press the Source Selector button from Step 3 to save the code.

Most of the button labels on the AVR remote describe each button's function when the remote is used to control the AVR. However, the button may perform a different function when used to control another device. Refer to the Remote Control Function List, Table A13 in the Appendix.

Set Up the AVR

In this section, you will configure the AVR to match your actual system's makeup. Although it's possible to configure the AVR using only the remote and the messages on the AVR's front-panel display, it is easier if you use the on-screen menu system.

Turn On the AVR

Press the front-panel Power button.



Using the On-Screen Menu System

To access the menu system, press the OSD/Menu button on the remote. The OSD/Menu Menu will appear, and if a video source is playing, the menu will automatically re-size so the picture will be visible behind the menu.



NOTE: The actual on-screen menus may differ slightly from the illustrations in this manual.

The Main Menu system consists of six submenus: Source Select, Source Setup, Surround Mode, Speaker Setup, Network and System Setup. (The AVR 1710/AVR 171 also have a Zone 2 submenu.) Use the Up/Down/Left/Right buttons on the remote or the front panel to navigate the menu system, and press the OK button to select a menu or setting line, or to enter a new setting.

The current menu, setting line or new setting will appear in the front-panel Message Display, as well as on screen.

To return to the previous menu or exit the menu system, press the Back/Exit button. Be certain all settings are correct, as any changes you have made will be retained.

Most users should follow the instructions in this *Set Up the AVR* section to configure a basic home theater system. You may return to these menus at any time to make additional adjustments, such as those described in the *Advanced Functions* section, on page 29.

Before beginning the following setup steps, all loudspeakers, a video display and all source devices should be connected. You should be able to turn on the AVR and view the main menu when you press the AVR button. If necessary, reread the *Making Connections* and *Set Up the Remote* sections before continuing.

Configure the AVR for Your Speakers

1. Plug the supplied EzSet/EQ microphone into the AVR's Headphone connector.



2. Place the microphone at ear height in your listening position.
3. Set the volume control on your subwoofer to approximately the halfway point.
4. Turn on your TV and select the TV input where you connected the AVR in *Connect Your TV or Video Display*, on page 15.
5. Press the remote control's AVR button. The AVR's on-screen display (OSD) Main Menu screen will appear on the TV.



6. Use the remote's Up/Down/Left/Right and OK buttons to select "Speaker Setup."



7. Select “Auto: EzSet/EQ”.
8. If you have a subwoofer connected, select “Yes with Sub.” Otherwise, select “Yes without Sub.”
9. For AVR 1610/AVR 161, or for AVR 1710/AVR 171’s in 5.0- or 5.1-channel systems, select “5.0” or “5.1” in the Speaker Configuration screen. For AVR 1710/AVR 171’s in 7.0- or 7.1-channel systems, select “7.0” or “7.1.”
10. The test will begin. Make sure that the room is quiet while the test noise is playing through the speakers.
11. When the test finishes, select “Done” to exit.

NOTES:

- If there are fewer than five main speakers in your system, do not use the EzSet/EQ process. Instead, proceed as described in *Manual Speaker Setup*, on page 30.
- If you are using an AVR 1710/AVR 171 in 6.0- or 6.1-channel configuration with a single surround back speaker, do not use the EzSet/EQ process. Instead, proceed as described in *Manual Speaker Setup,* on page 30.

Set Up Your Sources

The Source Setup menu lets you assign the correct physical audio and video connections to each source and lets you set many audio and video playback features for each source. **IMPORTANT: The “Video In” and “Audio In” settings are not optional and must be adjusted *before* you use your AVR to enable playback of each source.** You can adjust the other settings later. See *System Settings*, on page 34, for complete information about adjusting all of the Settings menu options.

1. Review the input connections you listed on the *Source Buttons and Assigned Connectors table,* on page 16. Note what changes (if any) you want to make from the default connector assignments that appear on the list.
2. Turn on your TV and select the TV input where you connected the AVR in Connect Your TV or Video Display, on page 15.
3. Press the remote control’s OSD/Menu button. The AVR’s OSD setup menu will appear on the TV. (Note: If you have used a composite video connection to your TV, the OSD menus will not appear on your TV. Follow the steps below using the AVR’s front-panel display.)



4. Use the remote’s arrow and OK buttons to select “Source Setup,” and use the left/right arrow buttons to select a source button with connectors that you want to re-assign.



5. Select “Video In” and select the video input connector you want to assign to the source button. Press the OK button. NOTE: If you select an HDMI connector as the video input connector, the audio input connector will automatically change to the same HDMI connector.



6. If you have not selected an HDMI connector for Video In, select “Audio In” and select the audio input connector you want to assign to the source button. Press the OK button. You cannot use a different video input connector with an HDMI audio input connector.



7. Press the remote’s Back/Exit button and repeat steps 3 – 6 for the remaining source buttons with connectors you want to re-assign.

Title: This selection lets you change the display name for the source, which is useful if your source’s device type is different from the source’s preprogrammed name. Use the Up/Down buttons to scroll forward or backeard through the alphanumeric characters until the desired character appears, then use the Left/Right buttons to move the cursor to the next or previous position. Move the cursor again to leave a blank space. (Your name can have a maximum of 10 characters.) When you have finished, press the OK Button. The new name will appear on the AVR’s front panel and throughout the on-screen menu system.

Tone: This setting determines whether the treble and bass controls are active for the source. When it’s set to Off, the tone controls are out of the circuit, with no changes to the sound. When it’s set to On, the bass and treble controls are in the circuit.

Treble/Bass: These settings boost or cut the treble or bass frequencies by up to 10dB, in 2dB increments. Use the Left/Right buttons to change the setting. The default setting is 0dB.

Night Mode: This setting activates Night mode for the source, which works with specially encoded Dolby Digital discs or broadcasts. Night mode compresses the audio so that louder passages are reduced in volume to avoid disturbing others, while dialogue remains intelligible. The following settings are available:

- Off: No compression is applied. Loud passages in the program remain as they were recorded.
- Mid: Loud passages in the program are reduced moderately in volume.
- Max: Loud passages in the program are reduced more in volume.

Lip Sync: This setting lets you resynchronize the audio and video signals from the source to eliminate a "lip sync" problem. Lip-sync issues can occur when the video portion of a signal undergoes additional processing in either the source device or the video display. Use the Left/Right buttons to delay the audio by up to 180ms. (The active source's video will be visible behind the OSD menu, allowing you to synchronize the audio with the picture.)

You can also make lip sync adjustments without activating the AVR's OSD menus. Pressing the remote's Delay button will display the Lip Sync menu bar on the TV, superimposed at the bottom of the video. Use the Left/Right buttons to delay the audio until it is synchronized with the picture.

Zone 2 In (AVR 1710/AVR 171 only): This setting determines the audio source for Zone 2 of a multizone system. Select the analog audio input the source is connected to. Digital audio is not available to the multizone system.

To configure the next source, press the Back/Exit button, then return to the Setup Source line of the Main Menu. When you have finished configuring all sources, press the Back/Exit button to clear the menus from view.

Set Up the Network

To play MP3 or WMA media located on DLNA-compatible devices connected to the network, use the AVR's internal Internet radio tuner or listen to sources via AirPlay (AVR 1710/AVR 171 only), the AVR must be connected to your home network and you must join them with the network.

If your network uses an automatic IP address, you should not have to perform any network setup procedures. Once you connect the AVR to your home network, the network should automatically assign the AVR an IP address, and the AVR should automatically join your network.

If your AVR does not automatically join your network (in which case the AVR will display a "Not Connected" message when you press the Network source button):

1. Press the OSD/Menu button, select System Setup, then select Network.
2. The Network menu will appear.



3. Select IP Configuration, then press the Right button button twice to cycle the setting from "Auto" to "Manual" and back to "Auto."
4. Select Apply & Save. The AVR will attempt to connect to the network.
5. If the AVR again fails to connect to the network, you may need to enter your network's settings manually. You may need to obtain your network's settings from your ISP or network administrator.

NOTE: We recommend that you directly connect the AVR to a home-network router so that it can directly access the Internet for Internet radio, or access devices on the network for playback of content stored on the devices (see *Listening to Media via Your Home Network*, on page 28, for more information).

NOTE: If you have trouble connecting to the network at any time, cycle the AVR into the Sleep mode, and then turn it back on.

Pair the AVR with Your Bluetooth Device

1. Press the OSD/Menu button and select "Source Select."



2. Scroll to "*Bluetooth*" and select it. The OSD will display that Bluetooth is unpaired.

3. Press the remote's Option /Info button. The *Bluetooth* Options Menu will appear.



4. Select "Force Pairing > OK" and press the OK button. The AVR will enter the pairing mode.
5. Open your *Bluetooth* device's pairing menu. The AVR will appear on your device's pairing menu as "HK AVR."
   - If your device requires a passcode, use 0000.
6. Pair your device with the AVR. Once paired, press the OSD/Menu button to exit the menu.

To stream audio from the paired *Bluetooth* device:

1. Press the OSD/Menu button.
2. Select the Source Select menu.
3. Select *Bluetooth* from the source list.

Operating Your AVR

Now that you have installed your components and completed a basic configuration, you are ready to begin enjoying your home theater system.

HARMAN Remote App

For easy control of your AVR with your hand-held device, download the free Harman Kardon Remote app from iTunes App Store for compatible Apple products, or from Google Play for compatible Android powered smartphones.

The Harman Kardon Remote App controls virtually all the functions of AVR 1710, AVR 171, AVR 1610 and AVR 161 AVRs that are connected to the same network as the device that has the app installed. With this easy-to-use app you can turn the AVR on or off, select a source, control the volume and virtually any other function. You can also access and navigate all of the AVR's on-screen setup menus.

Controlling the Volume

Adjust the volume either by turning the front-panel Volume knob (clockwise to increase volume or counterclockwise to decrease volume) or by pressing the Volume Up/Down buttons on the remote. The volume is displayed as a negative number of decibels (dB) below the 0dB reference point (–80dB – +10dB).

0dB is the maximum recommended volume for your AVR. Although it's possible to turn the volume to a higher level, doing so may damage your hearing and your speakers. For certain more dynamic audio materials, even 0dB may be too high, allowing for damage to equipment. Use caution with regard to volume levels.

To change the volume level display from the default decibel scale to a 0-to-90 scale, adjust the Volume Units setting in the System Settings menu, as described in *System Settings*, on page 34.

Muting the Sound

To mute all speakers and the headphones, press the Mute button on the remote. Any recording in progress will not be affected. The MUTE message will appear in the display as a reminder. To restore the sound, press the Mute button again, or adjust the volume.

Listening Through Headphones

Plug the 1/4-inch stereo plug on a pair of headphones into the front-panel Phones jack for private listening. The default HARMAN Headphone mode uses virtual surround processing to emulate the sound of a 5.1-channel speaker system. Press the Surround Modes button on the front panel or the remote to switch to the Headphone Bypass mode, which delivers a conventional two-channel signal to the headphones. No other surround modes are available for the headphones.

NOTE: You will be unable to listen through headphones if the iPod source is selected.

Selecting a Source

There are three different ways to select a source:

- Press the front-panel Source buttons to scroll through the sources.
- Using the on-screen menus, press the OSD/Menu button, highlight "Source Select" and press the OK button. Scroll to the desired source and press the OK button.
- You can directly select any source by pressing its Source Selector button on the remote.

The AVR selects the audio and video inputs assigned to the source, and any other settings you made during setup.

The source name, the audio and video inputs assigned to the source, and the surround mode will appear on the front panel. The source name and active surround mode will also briefly appear on the TV screen.

Video Troubleshooting Tips

If there is no picture:

- Check the source selection and video input assignment.
- Check all connections for a loose or incorrect connection.
- Check the video input selection on the TV/display device.

Additional Tips for Troubleshooting HDMI Connections

- Turn off all devices (including the TV, the AVR and any source components).
- Unplug the HDMI cables, starting with the cable between the AVR and the TV, and continuing with the cables between the AVR and each source device.
- Carefully reconnect the cables from the source devices to the AVR. Connect the cable from the AVR to the TV last.
- Turn on the devices in this order: TV, AVR, source devices.

NOTE: Depending upon the particular components involved, the complexity of the required communication between HDMI components may cause delays of up to a minute in the completion of some actions, such as input switching or switching between SD and HD channels.

Selecting a Surround Mode

Selecting a surround mode can be as simple or sophisticated as your individual system and tastes. Feel free to experiment, and you may find a few favorites for certain sources or program types. You can find more detailed information on surround modes in *Audio Processing and Surround Sound*, on page 29.

To select a surround mode, press the OSD/Menu button and select Surround Mode. The Surround Mode menu will appear.



Auto Select: For digital programs, such as a movie recorded with a Dolby Digital or DTS soundtrack, the AVR will automatically use the soundtrack's native surround format. For two-channel analog and PCM programs, the AVR uses the HARMAN NSP mode.

Virtual Surround: When only two main speakers are present in the system, you can use Virtual Surround to create an enhanced soundfield that virtualizes the missing speakers.

Stereo: When you want two-channel playback, select the number of speakers you want to use for playback:

- "2 CH Stereo" uses two speakers.
- "5 CH Stereo" plays the left-channel signal through the front left and surround left speakers, the right-channel signal through the front right and surround right speakers, and a summed mono signal through the center speaker.
- "7 CH Stereo" (AVR 1710/AVR 171 only) follows the same scheme as 5 CH Stereo but adds the surround back left and surround back right speakers. This mode is available only when the surround back speakers are present and have not been reassigned to multizone or front height operation. See *Audio Processing and Surround Sound*, on page 29, for more information.

HARMAN NSP: A HARMAN proprietary technology, NSP uses sophisticated digital processing to deliver a true natural sounding three-dimensional listening experience from conventional 2-channel stereo sources like CDs and stereo broadcasts. While preserving the recording's original timbre and spatial balance, HARMAN NSP creates a simulated listening space that automatically adjusts to suit the type of program you are listening to.

The following adjustments are available:

- Stage Width: This adjustment allows you to widen or narrow the width of the apparent listening space in front of you. For example, a higher setting would be appropriate for a recording of an orchestra playing in a concert hall, while a lower setting would be more appropriate for a recording of a singer playing an acoustic guitar.
- Stage Depth: This adjustment lets you control the total size of the apparent listening space. A higher setting would approximate the acoustic qualities of larger listening spaces, such as concert halls and arenas, while a lower setting would approximate the acoustic qualities of smaller listening spaces like small clubs or coffee houses.

Movie: Select from the following when you want a surround mode for movie playback: DTS Neo:6 Cinema or Dolby Pro Logic II (IIx or IIz when seven main speakers are present) in the AVR 1710/AVR 171.

Music: Select from the following when you want a surround mode for music playback: DTS Neo:6 Music or Dolby Pro Logic II (IIx or IIz when seven main speakers are present in the AVR 1710/AVR 171). The Dolby Pro Logic II/IIx/IIz Music mode allows access to a submenu with some additional settings. See A*udio Processing and Surround Sound*, on page 29, for more information.

Game: Dolby Pro Logic II (IIx/IIz when seven main speakers are present) Game is available for video game playback..

After you have made your selection, press the Back/Exit button.

You can also change surround mode categories by repeatedly pressing the Surround Mode button on either the remote or the front panel.

- You can change surround modes within surround mode categories by pressing the Surround Mode Select buttons on the front panel.

See *Audio Processing and Surround Sound*, on page 29, for more information on surround modes.

Listening to FM and AM Radio

Select the Radio source. A screen similar to the one in the illustration below will appear.

Use the Up/Down buttons or the Remote's Channel buttons to tune a station as displayed on the front panel and on-screen display.

The AVR defaults to automatic tuning, meaning each press of the Up/Down buttons scans up or down the frequency band until a station with acceptable signal strength is found. To switch to manual tuning, in which each press of the Up/Down buttons steps through a single tuning frequency increment, press the Tuning Mode button on the front panel or press and hold the OK button on the remote control for more than 3 seconds. Each press of the button toggles between automatic and manual tuning modes.

Once you have tuned an FM station, toggling the Mode setting also switches the radio between stereo and monaural reception. (Mono reception may improve reception of weaker stations.) Note that some surround modes are not available with monaural reception.

Preset Stations

You can store a total of 30 stations (AM and FM combined) as presets. When you want to save the currently tuned station as a preset, press the remote's Memory button. Use the Number buttons to enter the desired preset number.

To tune to a preset station:

- Press the Left/Right buttons.
- Press the remote's Preset Scan button. The AVR will tune to each preset station in order for five seconds. When the desired preset is tuned, press the Preset Scan button again.
- Enter the preset number using the Number buttons. For presets 10 through 30, press 0 before the preset number. For example, to enter preset 21, press 0-2-1.

Auto Store is an alternate method for storing presets automatically. When you select Auto Store, your AVR will scan for any frequencies with good signal and save them as presets automatically. To use Auto Store:

- In either FM or AM source, press the Info/Option button on the AVR's remote control.
- Press OK to select "Auto Store."
- Highlight "Yes" and press "OK."

Your AVR may take several minutes to complete the Auto Store process. Note that performing Auto Store will erase all currently saved preset station.

Listening to Media on a USB Device

Your AVR is compatible with MP3 and WMA media.

MP3 compatibility: Mono or stereo, contstant bit rates (CBR) from 8kbps to 320kbps, variable bit rates (VBR) from lowest to highest quality, with sample rates from 8kHz – 48kHz.

WMA compatibility: Ver. 9.2 basic, stereo CBR with 32kHz – 48kHz sampling rate and 40kbps – 192kbps bit rate, mono CBR with 8kHz – 16kHz sampling rate and 5kbps – 16kbps bit rate, VBR Pass Encoding and Quality Encoding 10 – 98, 44kHz and 48kHz sampling rate.

No other types of media are supported.

Playing files on a USB device

1. Insert the USB drive into the AVR's front-panel USB port.

IMPORTANT: Do not connect a personal computer or peripheral to the USB port. USB hubs and multi-card readers are not supported.

2. Press the USB source selector button on the remote until the front-panel display's "USB" as the source. The USB screen will appear.



3. Select a folder and press the OK button. The AVR will list all compatible audio files.

4. Select a file to begin playback. The USB play screen will appear. Any ID3 information will be displayed, along with the track's elapsed/current time and icons indicating the current playback status.



NOTES:

- To skip to the next track, press the Right button; to skip to the beginning of the current track, press the Left button once ; to skip to the beginning of the previous track, press the Left button twice (or the Left button once if the track's elapsed time is less than 5 seconds.).
- You can use the Transport Control buttons to control playback (skipping to the previous or next track, searching at high speed forward or backward within a track, playing a file, pausing playback or stopping playback).
- To repeat a file or folder, press the Option/Info Button and select the Repeat option. Each press of the Left or Right buttons will change the setting from Off (no repeat) to repeat One (file) to repeat All (files at the current directory level of the drive). Repeat All will always be activated when Shuffle Music playback is turned on.
- To play the audio tracks in random order, press the Options/Info button and select Shuffle. Each press of the Shuffle turns the setting on or off. The AVR will automatically repeat the tracks until playback is stopped manually.
- To collapse a folder or return to the previous menu level, press the Back/Exit button

Listening to an iPod/iPhone/iPad Device

When an iPod, iPhone or iPad device is connected to the AVR's front-panel USB port, you may play audio files through your high-quality audio system, operate the iPod, iPad or iPhone using the AVR remote or the AVR's front-panel controls, view navigation messages on the AVR's front panel or a connected video display and charge the iPod, iPad or iPhone. For the latest compatibility information, please see our Web site: www.harmankardon.com.

Press the USB source selector button on the remote until the front-panel displays "iPod" as the source. The iPod screen will appear.



The table below summarizes the controls available during normal playback via the USB port.

iPod or iPhone Function	Remote Control Button
Play	Play
Pause	Pause
Menu	OSD/Menu
Back/Exit	Back/Exit or Left Arrow
Select	OK or Right Arrow
Scroll Reverse	Up Arrow
Scroll Forward	Down Arrow
Forward Search	Forward Search
Reverse Search	Reverse Search
Next Track	Skip Forward or Right Arrow
Previous Track	Skip Backward or Left Arrow

While scrolling, hold the button to scroll faster.

While a selection is playing, the song title, and play mode icon will appear on the front-panel display.

If the AVR is connected to your TV, an iPod screen will appear and display the play mode icon, song title, artist and album. If random or repeat play has been programmed, an icon will appear.



CAUTION: We strongly recommend that you use the screen saver built into your video display to avoid possible damage from "burn-in" that may occur with plasma and CRT displays when a still image, such as a menu screen, remains on the display for an extended period of time.

Press the Option/Info button to view the iPod options menu:

Repeat: Select this setting to repeat a track or all tracks in the current album or playlist. Each press of the OK button switches the setting: repeat Off, repeat One or repeat All.

Shuffle: Select this setting to play all the available songs in random order. Each press of the OK button switches the setting: shuffle by Song, shuffle by Album, or Off to end shuffle playback.

NOTE: The iTunes application allows you to exempt some tracks from Shuffle mode. The AVR cannot override this setting.

Listening to Media via AirPlay (AVR 1710/AVR 171 only)

If you have joined an AVR 1710/AVR 171 to your home network you can stream audio to it via AirPlay from compatible Apple devices with iOS 4.2 or newer and computers that have iTunes 10.1 or newer that are joined on the same network. See *Connect to Your Home Network,* on page 18, for information about connecting to your network, and *Set Up the Network,* on page 24 for information about joining your network.

To initiate AirPlay streaming to the AVR:

- To initiate AirPlay streaming from a computer with iTunes, launch iTunes, click on the AirPlay button that appears at the bottom of the computer's iTunes window, and select "HK AVR" in the pop-up list that appears.



- To initiate AirPlay streaming from an iPod, iPhone or iPad device, tap the AirPlay button on the device's screen and select "HK AVR171_1710" in the speaker-selection list that appears.

The AirPlay audio stream will break in (the OSD will display an "AirPlay activated" message) and interrupt the source that is currently playing through the AVR. If the AVR is in the Sleep mode, it will turn on and begin playing the AirPlay audio stream. The music playback screen will appear on the OSD.

Use the remote's Transport Control buttons to control playback.

Listening to vTuner (Internet Radio)

Your AVR's Network connection brings you a world of MP3- and WMA-format streams via the Internet. After you have successfully connected to your home network as described in *Connect to Your Home Network*, on page 18, and set up the network as described in *Set Up the Network*, on page 24, press the Network Source Selector button on the remote. Each press toggles between the Network and vTuner screens.



With the vTuner screen (above) displayed, the AVR will automatically connect to the Internet via the www.radioharmankardon.com portal. To select a stream use the Up/Down buttons to search by category.

NOTE: The categories displayed vary by region.

To create a Favourites list, log onto www.radioharmankardon.com from your computer. Enter your either you AVR's MAC address as its ID # (the MAC address is on the Network Settings screen in the System Settings menu - AVR 171/AVR 1710 only) or your AVR's vTuner ID # (the vTuner ID # is found on the Help page on the vTuner main menu - AVR 161/AVR 1610 only) and create an account. Favourites that you select on the Web site will be available on the AVR.

Navigation is similar to other menus. Scroll to the desired item and press the OK button to select it. To return to the previous menu level (or to clear the top-level menu from view), press the Back/Exit button or the Left button.

The AVR is not able to connect to streams that require site registration or other interaction prior to playing the stream. If the AVR cannot connect to the stream, a "Network Error" message will appear briefly, and the Internet Radio screen will remain essentially blank.

Listening to Media via Your Home Network

Your AVR is DLNA-compatible and can access MP3 and WMA audio media that is stored on other DLNA-compatible devices that are connected to the same network as your AVR.

DLNA is a file sharing protocol that creates a bridge between the AVR and other devices on the same network that contain audio media. DLNA is supported by PCs that have Windows Media Player, Windows Media Center or Intel Media Server file sharing. Apple computers can also share files via DLNA using HARMAN Music Manager software, which you can download without charge from www.harmankardon.com. (Third-party software that enables DLNA file-sharing also is available.)

MP3 compatibility: Mono or stereo, contstant bit rates (CBR) from 8kbps to 320kbps, variable bit rates (VBR) from lowest to highest quality, with sample rates from 8kHz – 48kHz.

WMA compatibility: Ver. 9.2 basic, stereo CBR with 32kHz – 48kHz sampling rate and 40kbps – 192kbps bit rate, mono CBR with 8kHz – 16kHz sampling rate and 5kbps – 16kbps bit rate, VBR Pass Encoding and Quality Encoding 10 – 98, 44kHz and 48kHz sampling rate.

Before you can access files located on other devices via the network, each device must first give permission to share files with the AVR:

To share media on PCs:

1. Open Windows Media Player.
2. Open the Library menu and select Media Sharing. The Media Sharing window will appear.
3. Check the "Share My Media" box. An icon for the AVR will appear in the window.
4. Select the AVR icon, select "Allow," then select "OK."

The computer's WMA and MP3 media should now be available to the AVR.

To share media on other types of computers, operating systems or media software: Check the instructions for the computer, operating system or media player.

To listen to shared media, press the Network Source Selector button. (If vTuner appears as the source, press the button a second time to switch from the Internet Radio source to the Network source.) The Home Network screen will appear.



The screen will list by name all devices on the network that allow sharing. Use the Up/Down and OK buttons to browse the content stored in the device's media player library. Scroll to the desired item and press the OK button to select it. To return to the previous menu level (or to clear the menu from view from the top level), press the Back/Exit button.

NOTE: Although video content may appear in the menu, the AVR does not support video playback from the network connection.

Playing Media from a Roku Streaming Stick

When you connect a Roku Streaming Stick to the AVR's MHL/HDMI input and join it with your home Wi-Fi network, you can use the AVR's remote to search for and control streaming media. NOTE: Your home network must be Wi-Fi for you to be able to use the Roku Streaming Stick with your AVR.

1. After connecting the Roku Streaming Stick to the AVR's MHL/HDMI input, select the AVR's MHL source. The Roku Streaming Stick's video output should be displayed on your TV.
2. Follow the Roku instructions for joining the Roku Streaming Stick with your Wi-Fi network, using the Roku remote.
3. Once the Roku Streaming Stick is joined with your Wi-Fi network, the AVR remote buttons shown below will perform the same functions as their counterparts on the Roku remote:



Advanced Functions

Much of the adjusting and configuration your AVR requires is handled automatically, with little intervention required on your part. You can also customize your AVR to suit your system and your tastes. In this section we will describe some of the more advanced adjustments available to you.

Audio Processing and Surround Sound

Audio signals can be encoded in a variety of formats that can affect not only the quality of the sound but the number of speaker channels and the surround mode. You may also manually select a different surround mode, when available.

Analog Audio Signals

Analog audio signals usually consist of two channels – left and right. Your AVR is able to process two-channel audio signals to produce multichannel surround sound, even when no surround sound has been encoded in the recording. Among the available modes are the Dolby Pro Logic II/IIx/IIz, Virtual Speaker, DTS Neo:6, HARMAN NSP, 5 CH and 7 CH Stereo modes. To select one of these modes, press the Surround Modes button.

Digital Audio Signals

Digital audio signals offer greater flexibility and capacity than analog signals, and allow the encoding of discrete channel information directly into the signal. The result is improved sound quality and startling directionality, since each channel's information is transmitted discretely. High-resolution recordings sound extraordinarily distortion-free, especially in the high frequencies.

Surround Modes

Surround-mode selection depends upon the format of the incoming audio signal as well as your personal taste. Although there is never a time when all of the AVR's surround modes are available, there is usually a wide variety of modes available for a given input. Table A12 in the Appendix, on page 47, offers a brief description of each mode and indicates the types of incoming signals or digital bitstreams the mode may be used with. Additional information about the Dolby and DTS modes is available on the companies' Web sites: www.dolby.com and www.dtsonline.com.

When in doubt, check the jacket of your disc for more information on which surround modes are available. Usually, nonessential sections of the disc, such as trailers, extra materials or the disc menu, are available only in Dolby Digital 2.0 (two-channel) or PCM two-channel mode. If the main title is playing and the display shows one of these surround modes, look for an audio or language setup section in the disc's menu. Also, make sure your disc player's audio output is set to the original bitstream rather than two-channel PCM. Stop play and check the player's output setting.

Multichannel digital recordings are produced in five-channel, six-channel or seven-channel formats, with or without a ".1" channel. The channels included in a typical 5.1-channel recording are front left, front right, center, surround left, surround right and LFE (low-frequency effects). The LFE channel is denoted as ".1" to represent the fact that it is limited to the low frequencies. 6.1-channel recordings add a single surround back channel, and 7.1-channel recordings add surround back left and surround back right channels to the 5.1-channel configuration. New formats are available in 7.1-channel configurations. Your AVR is able to play the new audio formats, delivering a more exciting home theater experience.

AVR 1710/AVR 171 only: To use the 6.1- and 7.1-channel surround modes, the surround back channels must be enabled. See *Manual Speaker Setup*, on page 30 for more information.

Digital formats include Dolby Digital 2.0 (two channels only), Dolby Digital 5.1, Dolby Digital EX (6.1), Dolby Digital Plus (7.1), Dolby TrueHD (7.1), DTS-HD High-Resolution Audio (7.1), DTS-HD Master Audio (7.1), DTS 5.1, DTS-ES (6.1 Matrix and Discrete), DTS 96/24 (5.1), two-channel PCM modes in 32kHz, 44.1kHz, 48kHz, 88.1kHz, 96kHz, 176.4kHz or 192kHz, and 5.1 or 7.1 multichannel PCM.

When the AVR receives a digital signal, it detects the encoding method and the number of channels, which is displayed briefly as three numbers, separated by slashes (e.g., "3/2/.1").

The first number indicates the number of front channels in the signal: “1” represents a monophonic recording (usually an older program that has been digitally remastered or, more rarely, a modern program for which the director has chosen mono as a special effect). “2” indicates the presence of the left and right channels, but no center channel. “3” indicates that all three front channels (left, right and center) are present.

The second number indicates whether any surround channels are present: “0” indicates that no surround information is present. “1” indicates that a matrixed surround signal is present. “2” indicates discrete left and right surround channels. “3” is used with DTS-ES bitstreams to represent the presence of the discrete surround back channel, in addition to the side surround left and right channels. “4” is used with 7.1-channel digital formats to indicate the presence of two discrete side surround channels and two discrete back surround channels.

The third number is used for the LFE channel: “0” indicates no LFE channel. “.1” indicates that an LFE channel is present.

The 6.1-channel signals – Dolby Digital EX and DTS-ES Matrix and Discrete – each include a flag that signals the receiver to decode the surround back channel, indicated as 3/2/.1 EX-ON for Dolby Digital EX materials, and 3/3/.1 ES-ON for DTS-ES materials.

Dolby Digital 2.0 signals may include a Dolby Surround flag indicating DS-ON or DS-OFF, depending on whether the two-channel bitstream contains only stereo information or a downmix of a multichannel program that can be decoded by the AVR’s Dolby Pro Logic decoder. By default, these signals are played in Dolby Pro Logic IIx Movie mode.

When a PCM signal is received, the PCM message and the sampling rate (32kHz, 44.1kHz, 48kHz, 88.2kHz, 96kHz, 176.4kHz or 192kHz) will appear.

When only two channels – left and right – are present, the analog surround modes may be used to decode the signal into multiple channels. If you would prefer a different surround format than the native signal’s digital encoding, press the Surround Modes button to display the Surround Modes menu (see *Selecting a Surround Mode*, on page 25).

The Auto Select option sets the surround mode to the native signal’s digital encoding, e.g., Dolby Digital, DTS, Dolby TrueHD or DTS-HD Master Audio. For two-channel materials, the AVR defaults to the HARMAN NSP mode. If you prefer a different surround mode, select the surround-mode category: Virtual Surround, Stereo, Movie, Music or Video Game. Press the OK button to change the mode.

Each surround-mode category is set to a default surround mode:

- Virtual Surround: Virtual speaker.
- Stereo: 7-CH Stereo or 5-CH Stereo (depending on how many main speakers are present in the system).
- NSP: HARMAN NSP.
- Movie: Dolby Pro Logic II Movie.
- Music: Dolby Pro Logic II Movie.
- Video Game: Dolby Pro Logic II Movie.

You may select a different mode for each category. Below is a complete list of available surround modes. (The actual surround modes available will depend on the number of speakers in your system.)

- Virtual Surround: Virtual speaker.
- Stereo: 2-CH Stereo, 5-CH Stereo or 7-CH Stereo (AVR 1710/AVR 171 only).
- NSP: HARMAN NSP.
- Movie: DTS Neo:6 Cinema, Dolby Pro Logic II Movie, Dolby Pro Logic IIx Movie (AVR 1710/AVR 171 only), Dolby Pro Logic IIz (AVR 1710/AVR 171 only).
- Music: DTS Neo:6 Music, Dolby Pro Logic II Music, Dolby Pro Logic IIx Music (AVR 1710/AVR 171 only), Dolby Pro Logic IIz (AVR 1710/AVR 171 only).
- Video Game: Dolby Pro Logic II Game, Dolby Pro Logic IIx Game (AVR 1710/AVR 171 only), Dolby Pro Logic IIz (AVR 1710/AVR 171 only).

Once you have programmed the surround mode for each type of audio, select the line from the Surround Modes menu to override the AVR’s automatic surround-mode selection. The AVR will use the same surround mode the next time the source is selected.

AVR 1710/AVR 171 only: Dolby Pro Logic IIx is available only if you have set up the AVR’s Assigned Amp to Surround Back; Dolby Pro Logic IIz is available only if you have set up the AVR’s Assigned Amp to Front Height. See *Manual Speaker Setup*, on page 30, for more information.

PLIIz Height Gain (AVR 1710/AVR 171 only): When you have set the Assigned Amp to Front Height (see *Manual Speaker Setup*, on page 30), the PLIIz Height Gain setting will become available. The front height channels can greatly improve the spatial experience of a surround-sound system. Some listeners may want the depth and dimension that height channels provide, but from a seemingly transparent experience. Other listeners may prefer to accentuate the front height channels by using a higher volume setting.

The PLIIz Height Gain control gives you the ability to change the volume of the front height channels to suit different programs. The control has three settings: Low (normal volume), Mid (moderate volume increase) and High (maximum volume increase). Note that you can also fine-tune the front height channel volume levels. See *Setting Channel Output Levels Manually*, on page 32, for details.

Dolby PLII/Dolby PLIIx Music: Some additional settings are available when you select the Dolby Pro Logic II or IIx Music Mode in the Surround Modes menu:



Center Width: This setting affects how vocals sound through the three front speakers. A lower number focuses the vocal information tightly on the center channel. Higher numbers (up to 7) broaden the vocal soundstage. Use the Left/Right buttons to adjust.

Dimension: This setting affects the depth of the surround presentation, allowing you to “move” the sound toward the front or rear of the room. The setting of “0” is a neutral default. Setting “F-3” moves the sound toward the front of the room, while setting “R-3” moves the sound toward the rear. Use the Left/Right buttons to adjust it.

Panorama: With the Panorama mode turned on, some of the sound from the front speakers is moved to the surround speakers, creating an enveloping “wraparound” effect. Each press of the OK button toggles the setting On or Off.

Please refer to Table A10 in the Appendix for more information on which surround modes are available with different bitstreams.

Manual Speaker Setup

Your AVR is flexible and may be configured to work with most speakers and to compensate for the acoustic characteristics of your room.

The EzSet/EQ process automatically detects the capabilities of each connected speaker and optimizes the AVR’s performance with your speakers. If you are unable to run EzSet/EQ calibration, or if you wish to set up your AVR for your speakers manually, use the Speaker Setup on-screen menus.

Before beginning, place your loudspeakers as explained in the *Place Your Speakers* section, on page 11, and connect them to the AVR. Consult the owner’s guide for the speakers or the manufacturer’s Web site for their frequency-range specification. Although you may set the AVR’s individual channel levels “by ear,” an SPL (sound-pressure level) meter purchased at a local electronics store will provide greater accuracy.

Record your configuration settings in Tables A3 through A12 in the Appendix for easy re-entry after a system reset or the unit has been unplugged for more than four weeks.

Step One – Determine Your Speakers' Crossover Frequencies

Without using the EzSet/EQ process, the AVR can't detect how many speakers you've connected to it; nor can it determine their capabilities. Consult the technical specifications for all of your speakers and locate the frequency response, usually given as a range, e.g., 100Hz – 20kHz (±3dB). Write down the lowest frequency that each of your speakers (except the subwoofer) is capable of playing (100Hz in the above example) as the crossover in Table A3 in the Appendix. NOTE: This is *not* the same as the crossover frequency listed in the speaker's specifications.

The AVR's bass management determines which speakers will be used to play back the low-frequency (bass) portion of the source program. Sending the lowest notes to small satellite speakers will result in bad sound and may even damage the speakers. The highest notes may not be heard at all through the subwoofer.

With proper bass management, the AVR divides the source signal at a crossover frequency. All information above that crossover frequency is played through your system's speakers, and all information below the crossover frequency is played through the subwoofer. This way, each loudspeaker in your system will perform at its best, delivering a more powerful and enjoyable sound experience.

Step Two – Measure the Speaker Distances

Ideally, all of your speakers would be placed in a circle, with the listening position at the center. However, you may have had to place some speakers a little farther away from the listening position than others. Because of this, sounds that are supposed to arrive simultaneously from different speakers may blur, due to different arrival times.

Your AVR provides a Distance adjustment that compensates for these real-world speaker placement differences.

Measure the distance from each speaker to the listening position, and write it down in Table A4 in the Appendix. Even if all of your speakers are the same distance from the listening position, enter your speaker distances as described in *Set the Speaker Distances*, on page 32.

Step Three – Manual Speaker Setup Menu

Now you are ready to program the AVR. Sit in your usual listening position, and make the room as quiet as possible.

With the AVR and video display turned on, press the OSD/Menu button to display the menu system. Select the Speaker Setup menu, and then select Manual Setup.



If you have already run the EzSet/EQ process as explained in *Configure the AVR for Your Speakers*, on page 22, the AVR saved the results. To fine-tune the EzSet/EQ results, or to configure the AVR from scratch, select Manual Setup. The Manual Setup screen will appear.



NOTE: To save the current settings, press the Back/Exit button.

For best results, adjust the submenus in this order: Speakers, Crossover, Distance and Output Adjust.

Speakers

This selection lets you program the correct setting for each speaker group. The settings in this menu affect the remainder of the speaker setup process and the availability of various surround modes at any time.

Select ON when the speakers are present in the system; select OFF for positions where no speakers are installed. The Front Left & Right setting is always ON and may not be disabled.



Any changes will be reflected in the total Number Of Speakers displayed at the top of the screen.

AVR 1710/AVR 171 only: The Assigned AMP setting includes four options:

- **Surround Back:** Select the Surr. Back option if your main system is a 7.1-channel system and you are using surround back left and surround back right speakers.
- **Zone 2:** Select the Zone 2 option if your main system is a 5.1-channel system and you want to use the Assigned Amp speaker outputs to power speakers in Zone 2. See *Install a Multizone System*, on page 19, for more information.
- **Front Height:** Select the Front Height option if your main system is a 7.1-channel system and you are using Front Height speakers with Dolby Pro Logic IIz.
- **Off:** Select Off if you have not connected speakers to the Assigned Amp speaker outputs.

NOTE: When you set Assigned AMP to "Zone 2," the speakers connected to the Assigned Amp outputs will not be configured during the EzSet/EQ process. Configure the speakers manually, as explained below.

When you have finished, press the Back/Exit button.

Crossover

After you return to the Speaker Setup menu, navigate to the Crossover line and press the OK button to display the Crossover menu.



The AVR will display only those speaker groups you set to On in the Number of Speakers menu.

Refer to Table A3 to see the crossover frequencies that you wrote down for your speakers.

For each speaker group, select one of these eight crossover frequencies: Large, 40Hz, 50Hz, 60Hz, 70Hz, 80Hz, 90Hz, 100Hz, 110Hz, 120Hz, 140Hz, 150Hz, 160Hz, 180Hz or 200Hz. If the speaker's crossover frequency is below 40Hz, select the first option, "Large." This setting doesn't refer to the speaker's physical size but to its frequency response, which is also called "full range."

NOTE: If you have Room EQ set to On, the crossover frequencies have been automatically set by the AVR and cannot be adjusted.

Write down the settings in Table A6 in the Appendix.

When you have finished entering the settings, press the Back/Exit button to return to the Manual Setup menu.

Select the "Speakers" menu again and note the Subwoofer setting: This setting depends upon the Crossover setting you selected for the front left and right speakers.

- If you set the front speakers to a numeric crossover frequency, the subwoofer setting will always be SUB. All low-frequency information will always be sent to the subwoofer. If you don't have a subwoofer, either upgrade to full-range front left and right speakers or add a subwoofer at the earliest opportunity.
- If you set the front left/right speakers to LARGE, select one of the three following settings for the subwoofer:

  L/R+LFE: This setting sends all low-frequency information to the subwoofer, including a) information that would normally be played through the front left and right speakers and b) the special low-frequency effects (LFE) channel information.

  OFF: Select this setting when no subwoofer is in use. All low-frequency information will be sent to the front left and right speakers.

  LFE: This setting plays low-frequency information contained in the left and right program channels through the front left and right speakers, and directs only the LFE-channel information to the subwoofer.

Distance

As described above in Step Two, when you measured the distances from each of your speakers to the listening position, your AVR provides an adjustment that compensates for the different distances so that the sound from each speaker will reach the listening position at the proper time. This process will improve the clarity and detail of the sound.

On the Manual Setup menu, move the cursor to the Distance line and press the OK button to display the Adjust Speaker Distance menu.



Enter the distance from each speaker to the listening position that you measured in Step Two and recorded in Table A4 in the Appendix (see page 39). Select a speaker, then use the Left/Right buttons to change the measurement. You can enter distances between 0 and 30 feet (9.1m). The default distance for all speakers is 10 feet (3m).

The default unit of measurement is feet. To change the unit to meters, select the Unit of Measure line and press the Left or Right button to change the setting.

NOTE: If you set the Assigned AMP channels to Zone 2, you will not be able to adjust their delay settings.

Step Four – Setting Channel Output Levels Manually

For a conventional stereo receiver, a simple balance control adjusts the stereo imaging by varying the relative loudness of the left and right channels. In a home theater system with up to seven main channels plus up to two subwoofers, achieving proper imaging becomes both more critical and more complex. The goal is to ensure that each channel is heard at the listening position with equal loudness (when signals of equal loudness are played through them).

Your AVR's EzSet/EQ calibration can handle this critical task for you simply and automatically. However, the Output Adjust menu allows you to calibrate the levels manually, either using the system's built-in test tone or while playing source material.

From the Manual Setup menu select Output Adjust to display the speaker volume adjustment menu.



All of the system's speakers will appear with their current level settings. You can adjust each speaker's level between –10dB and +10dB in 1dB increments.

While making adjustments, you can measure the channel levels in one of these ways:

- Preferably, use a handheld SPL meter set to the C-weighting, slow scale. Adjust each speaker so that the meter reads 75dB when the AVR's built-in test noise is playing.
- By ear. Adjust the levels so that the test tone sounds equally loud to you when it plays through each speaker.

To set your levels using the AVR's internal test tone, select the menu's Test Tone line and use the Left/Right buttons to turn the test tone on. Then select the Test Tone SEQ line to select between Auto and Manual:

Auto: The test tone will automatically circulate to all speakers, as indicated by the highlight bar. Use the Left/Right buttons to adjust the level for any speaker when the test tone is paused there. Use the Up/Down buttons to move the highlight bar to another line, and the test tone will follow the bar. To stop the test tone, use the Up/Down buttons to move the cursor out of the screen's speaker listings area.

Manual: The test tone will stay on the selected speaker until you use the Up/Down buttons to move it to another speaker. Use the Left/Right buttons to adjust the level for the speaker through which the test tone is playing.

If you are using an external source to set your output levels, set Test Tone to Off, use the Up/Down buttons to navigate to each speaker, and use the Left/Right buttons to adjust the speaker's level while the source plays.

NOTE: If you are using a handheld SPL meter with external source material, such as a test disc or an audio selection, play it and adjust the AVR's master volume control until the meter measures 75dB. Then adjust the individual speaker levels.

Output Reset: To reset all levels to their factory defaults of 0dB, scroll down to this line and press the OK button.

When you have finished adjusting the speaker levels, record the settings in Table A3 in the Appendix. Then press the Back/Exit Button.

Notes on Setting Speaker Volumes in Home Theater Systems:

While setting your system's individual speaker volume levels is ultimately up to your personal taste, here are some ideas you may find helpful:

- For films and video-music programs, your overall goal should be to create an enveloping, realistic sound field that draws you into the film or music program without drawing your attention away from the action on the screen.
- For multichannel music recordings, some music producers will create a sound field that places the musicians all around you; others will create a sound field that places the musicians in front of you, with more subtle ambience in the surround speakers (as you would experience in a concert hall).
- In most 5.1-channel and 7.1-channel film soundtracks, the surround speakers are not intended to be as loud or as active as the front speakers. Adjusting the surround speakers so they are always as loud as the front speakers could make dialogue difficult to understand and will make some sound effects sound unrealistically loud.

Notes on Setting Subwoofer Volume:

- Sometimes the ideal subwoofer volume setting for music is too loud for films, while the ideal setting for films is too quiet for music. When setting the subwoofer volume, listen to both music and films with strong bass content and find a "middle ground" volume level that works for both.
- If your subwoofer always seems too loud or too quiet, you may want to place it in a different location. Placing the subwoofer in a corner will always tend to increase its bass output, while placing it away from any walls or corners will always tend to reduce its bass output.

AVR 1710/AVR 171 only: Listening in Zone 2

With the multizone system in use, you may enjoy an exciting 5.1-channel home theater presentation in the main listening area, while others listen to an entirely different source in another room. See *Install a Multizone System*, on page 19, for installation information.

You set up and activate the AVR's multizone system from the on-screen Zone 2 menu. Press the OSD/Menu button, and navigate to the Zone 2 line. Press the OK button to display the Zone 2 menu.



Status: This line lets you turn Zone 2 on or off.

Source: This line lets you select the source input for Zone 2. You may select a different source from the one currently operating in the main listening area. However, if the same source has been selected for both the main listening area and Zone 2, listeners in both areas will hear the same content.

Only analog audio sources are available to Zone 2. To hear digital devices such as a CD player in Zone 2, follow these steps:

1. In addition to making a digital audio connection, connect the source device's analog audio outputs to the AVR. Make a note in Table A5 on page 39 to record which set of analog inputs you used.
2. Use the AVR's front-panel Audio Input button to select the analog audio input. (Leave the Audio setting for the source device in the Source Setup menu set to the digital input.)

Notes about listening in Zone 2:

- Although you can listen to iPod or USB as a source in Zone 2, you cannot begin iPod or USB playback from within Zone 2. You must initially select iPod or USB as a source in Zone 1 and begin playback of a track or playlist from there. Then you can select iPod as the Zone 2 source and control playback from within Zone 2 even if you switch Zone 1 to a different source.
- Only one of the AVR's internal sources (iPod, USB, vTuner, Network, AirPlay, DLNA DMR) can be active at a time across both zones. For example, if you are listening to vTuner as the source in Zone 1 and switch the source in Zone 2 to USB, it will switch the source in Zone 1 to USB(and vice versa). To listen to different sources in Zone 1 and Zone 2 at the same time, at least one source must be one of the AVR's configurable external sources (Cable/Sat, Disc, STB or TV) that is connected to one of the AVR's analog audio inputs, or one of the AVR's terrestrial radio sources (FM or AM).

Volume: Highlight this line, and use the Left/Right buttons to control the volume in Zone 2.

Assigned AMP: This line lets you assign the Assigned AMP channels to "Zone 2" for multizone operation (see *Number of Speakers*, on page 31). When this line is set to Zone 2, you may configure the main listening room for only up to 5.1 channels.

To use the remote to control the sound in Zone 2, press the remote's Zone 2 button. The volume, mute and source select buttons will control the sound in Zone 2 and the Zone 2 button will illuminate whenever you press a button to indicate that the remote is in the Zone 2 control mode. Press the Zone 2 button again to return the remote to the main listening area control mode.

System Settings

The AVR's System Settings menu lets you customize in what way many of the AVR's features operate. Press the OSD/Menu button and navigate to the System line. Press the OK button to display the System Settings menu.



Panel Timeout: This setting allows you to set the AVR's front-panel display to automatically turn off after remaining on for a predetermined time (3 – 10 seconds) each time you use a control. Set this to "Off" to have the display remain on continually.

Auto Power Off: This setting allows you to set the AVR to automatically switch to the Off mode after being in the Sleep mode for a predetermined time (1 – 8 hours). See *Power Indicator/Power Button,* on page 4, for more information. It also allows the AVR to automatically switch to the Sleep mode after being on for the predetermined amount of time. Note that it will not transition to Sleep mode this way if the active source has one of the Digital Audio Connectors selected as the Audio Input. See Source Setup, on page 23, for more information.

Menu Timeout: This setting allows you to set the amount of time (20 – 50 seconds) a menu screen will remain on after the last adjustment. Set this to "Off" to have the menus remain on continually until you press the OSD/Menu button.

Status Message: When the AVR is turned on, the volume is adjusted, the source is changed or a change in the input signal is detected, a status message will be displayed on the TV screen. Select how long the message remains visible, from 2 to 10 seconds, with a default of 3 seconds. Select "Off" if you do not wish to see the status messages on the TV screen (they will still appear on the AVR's front-panel display).

Volume Default and Default Volume Setting: These two settings are used together to program the volume level when you turn on the AVR. Set Volume Default to On, and then set the Default Volume Setting to the desired turn-on volume. When Volume Default is set to Off, the AVR will turn on at the last-used volume setting from the previous listening session.

HDMI Audio to TV: This setting determines whether HDMI audio signals are passed through the HDMI Monitor Out connector to the video display. In normal operation, leave this setting at Off, as audio will be played through the AVR. To use the TV by itself, without the home theater system, turn this setting to On.

HDMI Link: This setting allows the communication of control information among the HDMI devices in your system. Turn this setting to On to allow control communication between the HDMI devices; turn the setting to Off to forbid control communication.

Software Update: If a software upgrade is released for your AVR, installation instructions will be available in the Product Support section of the Web site or from Harman Kardon customer service. At that time, you may use this submenu to install the upgrade software.

IMPORTANT: During a software upgrade, do not power off the AVR or use any of its controls. Doing so could permanently damage the AVR.

Sleep Timer

The sleep timer sets the AVR to play for up to 90 minutes and then turn off automatically.

Press the Sleep button on the remote, and the time until turn-off will be displayed. Each additional press of the Sleep button increases the play time by 10 minutes, with a maximum of 90 minutes. The SLEEP OFF setting disables the sleep timer.

When the sleep timer has been set, the front-panel display will automatically dim to half brightness.

If you press the Sleep button after the timer has been set, the remaining play time will be displayed. Press the Sleep button again to change the play time.

The front-panel display will count down during the final 10 seconds before going to Sleep mode. Pressing any button during this countdown will cancel the process and disable the Sleep timer.

Processor Reset

If the AVR behaves erratically after a power surge, unplug the AC power cord for at least 3 minutes. Plug the cord back in and turn the AVR on. If this procedure doesn't help, reset the AVR's processor as described below.

NOTE: A processor reset erases all user configurations, including speaker and level settings and tuner presets. After a reset, reenter all of these settings from your entries in the Appendix worksheets.

To reset the AVR's processor:

1. Press the front-panel Power Button for more than three seconds to turn the AVR off (the Power Indicator will turn amber).
2. Press and hold the front-panel Surround Mode Category button for at least 5 seconds until the RESET message appears on the front-panel display.

NOTE: After performing a processor reset, wait at least 1 minute before pressing any Source Selector buttons.

If the AVR does not function correctly after a processor reset, contact an authorized Harman Kardon service center for assistance. Authorized service centers may be located by visiting our Web site at www.harmankardon.com.

Symptom	Cause	Solution
Unit does not function	• No AC power	• Ensure that the power cord is plugged into a live AC power outlet • Check if the AC outlet is switch-controlled
Front-panel display lights, but there's no sound or picture	• Intermittent input connection • Mute is on • Volume control is turned down	• Secure all input and speaker connections • Press Mute button • Turn up Volume control
No sound from any speaker	• Amplifier is in protection mode due to possible short circuit • Amplifier is in protection mode due to internal problems	• Check all speaker wires at speaker and AVR connections for crossed wires • Contact your local Harman Kardon service center
No sound from center or surround speakers	• Incorrect surround mode • Program material is monophonic • Incorrect speaker configuration • Program material is stereo	• Select a surround mode other than stereo • Mono programs contain no surround information • Check the speaker configuration in the setup menu • The surround decoder may not create center- or surround-channel information from nonencoded programs
Unit does not respond to remote control commands	• Weak batteries in remote • Remote sensor is obscured	• Change batteries in remote • Ensure that the AVR's front-panel remote sensor is in the line of sight of the remote
Intermittent buzzing in tuner	• Local interference	• Move the AVR or antenna away from computers, fluorescent lights, motors or other electrical appliances
(AVR 1710/AVR 171 only): Surround-back speaker settings cannot be accessed, and the test tone does not play through the surround back speakers	• Multi-zone operation has been selected/Assigned AMP channels have been assigned to Zone 2	• Use the Speaker Setup menu to reassign the Assigned AMP to the surround back left and right channels
Unable to activate remote control Programming mode	• Source Selector button is not held for at least 3 seconds	• Be sure to hold the Source Selector button for at least 3 seconds
Remote buttons light, but AVR does not respond	• Remote is in Zone 2 mode	• Press Zone 2 button (button will not illuminate when remote is in Zone 1 control mode).
Unable to establish network connection	• AVR network programming requires rebooting	• Cycle the AVR into the Off mode, and then turn it on again

Additional information on troubleshooting possible problems with your AVR and installation-related issues may be found in the list of "Frequently Asked Questions," which is located in the Product Support section of our Web site: www.harmankardon.com

Specifications

Audio Section

Stereo power:	AVR 1710/AVR 171: 100W per channel, two channels driven @ 6/8 ohms, 1kHz, <0.9% THD AVR 1610/AVR 161: 85W per channel, two channels driven @ 6/8 ohms, 1kHz, <0.9% THD
Multichannel power:	AVR 1710/AVR 171: 100W per channel, two channels driven @ 6/8 ohms, 1kHz, <0.9% THD AVR 1610/AVR 161: 85W per channel, two channels driven @ 6/8 ohms, 1kHz, <0.9% THD
Input sensitivity/impedance:	250mV/27k ohms
Signal-to-noise ratio (IHF-A):	100dB
Surround system adjacent channel separation:	Dolby Pro Logic/DPLII: 40dB Dolby Digital: 55dB DTS: 55dB
Frequency response (@ 1W):	10Hz – 130kHz (+0dB/–3dB)
High instantaneous current capability (HCC):	±40 amps (AVR 1710/AVR 171); ±29 amps (AVR 1610/AVR 161)
Transient intermodulation distortion (TIM):	Unmeasurable
Slew rate:	40V/µsec

FM Tuner Section

Frequency range:	87.5 – 108.0MHz
Usable sensitivity IHF:	1.3µV/13.2dBf
Signal-to-noise ratio (mono/stereo):	70dB/68dB
Distortion (mono/stereo):	0.2%/0.3%
Stereo separation:	40dB @ 1kHz
Selectivity (±400kHz):	70dB
Image rejection:	80dB
IF rejection:	80dB

AM Tuner Section

Frequency range:	520 – 1710kHz (AVR 1710/AVR 1610) 522 – 1620kHz (AVR 170/AVR 160)
Signal-to-noise ratio:	38dB
Usable sensitivity (loop):	500µV
Distortion (1kHz, 50% mod):	1.0%
Selectivity (±10kHz):	30dB

Bluetooth Section

Frequency range:	2402MHz - 2480MHz
Transmitter power:	0-4dBm
Modulation:	GFSK, π/4-DQPSK, 8-DPSK
Functions:	Streaming audio play, supports Bluetooth 3.0, A2DP v1.2, AVRCP v1.4

Video Section

Television format:	NTSC (AVR 1710/AVR 1610); PAL (AVR 171/AVR 161)
Input level/impedance:	1Vp-p/75 ohms
Output level/impedance:	1Vp-p/75 ohms
Video frequency response (composite video):	10Hz – 8MHz (–3dB)
HDMI:	HDMI 1.4 with 4k x 2k bypass

General Specifications

Power requirement:	120V AC/60Hz (AVR 1710/AVR 1610); 220V – 240V AC/50Hz – 60Hz (AVR 171/AVR 161)
Power consumption:	<0.5W (standby); 510W maximum (AVR 1710/AVR 171); 450W maximum (AVR 1610/AVR 161)
Dimensions (W x H x D):	17-5/16" x 4-3/4" x 11-3/16" (440mm x 121mm x 300mm)
Weight	(AVR 1710/AVR 171): 11 lb (5.1kg) (AVR 1610/AVR 161): 10 lb (4.6kg)

Depth measurement includes knobs, buttons and terminal connections.
Height measurement includes feet and chassis.

Appendix – Default settings, worksheets, remote product codes

Table A1 – Recommended Source Component Connections

Device Type	AVR Source	Digital Audio Connection	Analog Audio Connection	Video Connections
Roku Streaming Stick or other portable device; HDMI-capable device	MHL (AVR 1710/AVR 171/ AVR 1610/AVR 161)	HDMI 1/MHL	Analog 1 or 2	HDMI 1/MHL
DVD Audio/Video, SACD, Blu-ray Disc, HD-DVD player	Disc	HDMI 2	Analog 1 or 2	HDMI 2
Cable TV, satellite TV, HDTV or other device that delivers television programs	Cable/Sat	HDMI 3	Analog 1 or 2	HDMI 3
DVR or set-top box	STB	HDMI 4	Analog 1 or 2	HDMI 4
Video-game console	Game	HDMI 5	Analog 1 or 2	HDMI 5
Any audio or video device, e.g., CD player, camcorder, cassette deck	Aux	Coaxial or Optical	Analog 1 or 2	Composite Video 1 or 2 (not used for audio-only devices)
Any audio-only playback device (e.g. CD player, cassette deck)	Audio	Coaxial or Optical	Analog 1 or 2	None
iPod, iPhone, iPad or USB memory stick	USB/iPod	USB	N/A	N/A

Table A2 – Speaker/Channel Setting Defaults

	Default Settings	Your Settings Position 1	Your Settings Position 2
Front Left/Right Speakers	ON		
Center Speaker	ON		
Surround Left/Right Speakers	ON		
Surround Back Left/Right Speakers (AVR 1710/AVR 171 only)	OFF		
Subwoofer	ON		
Front Left/Right Speakers Crossover Frequency	100Hz		
Center Speaker Crossover Frequency	100Hz		
Surround Left/Right Speakers Crossover Frequency	100Hz		
Surround Back Left/Right or Left/Right Front Height Speakers Crossover Frequency (AVR 1710/AVR 171 only)	100Hz		
Subwoofer Mode (if Front Speakers are set to Large)	L/R + LFE		
Front Left Level	0dB		
Center Level	0dB		
Front Right Level	0dB		
Surround Right Level	0dB		
Surround Back Right/Front Height Right Level (AVR 1710/AVR 171 only)	0dB		
Surround Back Left/Front Height Left Level (AVR 1710/AVR 171 only)	0dB		
Surround Left Level	0dB		
Subwoofer Level	0dB		

Table A3 – Delay Setting Defaults

Speaker Position	Distance From Speaker to Listening Position	Your Delay Settings Position 1	Your Delay Settings Position 2
Front Left	10 feet (3 meters)		
Center	10 feet (3 meters)		
Front Right	10 feet (3 meters)		
Surround Right	10 feet (3 meters)		
Surround Left	10 feet (3 meters)		
Surround Back Right/Front Height Right	10 feet (3 meters)		
Surround Back Left/Front Height Left	10 feet (3 meters)		
Subwoofer	10 feet (3 meters)		

Table A4 – Source Settings

	Cable/ Sat	Disc	MHL	Radio	TV	iPod/ USB	Network / vTuner	Game	AUX	STB	Audio	*Bluetooth*
Connected Device						USB						N/A
Surround Mode												
Video Input				N/A	N/A	N/A	N/A					N/A
Audio Input				Radio	HDMI ARC	USB	Network					*Bluetooth*
Night Mode				N/A		N/A	N/A					N/A
Adjust Lip Sync				N/A		N/A	N/A					N/A
Change Name				N/A	N/A	N/A	N/A					N/A
Zone 2 Input				N/A		N/A	N/A					N/A
Bass												
Treble												

Table A5 – HARMAN NSP Settings

	Default Settings	Your Settings
Stage Width	45	
Stage Depth	30	

Table A6 – Dolby Pro Logic II Music Settings

	Default Settings	Your Settings
Center Width	3	
Dimension	0	
Panorama	Off	

Table A7 – Remote Control Codes

Source Input	Device Type (if changed)	Product Brand and Code Number
Cable/Sat		
Disc		
TV		
Game		
AUX		

Table A8 – System Settings

Feature	Default	Your Settings
Panel Timeout	Off	
Auto Power Off	8 hours	
Menu Timeout	20 seconds	
Status Message	5 seconds	
Volume Default	Off	
Default Volume Setting	–25dB	
HDMI Audio to TV	Off	
HDMI Link	Off	

Table A9 – Zone 2 Settings

Source Input	Default	Your Settings
Status	Off	
Source	Cable/Sat	
Volume	–25dB	
Assigned AMP	Surround Back	

Table A10 – Surround Modes

Surround Mode	Description	Incoming Bitstream or Signal
Dolby Digital	Provides up to five separate main audio channels and a dedicated low-frequency effects (LFE) channel.	• Dolby Digital 1/0/.0 or .1, 2/0/.0 or .1, 3/0/.0 or .1, 2/1/.0 or .1, 2/2/.0 or .1, 3/2/.0 or .1 • Dolby Digital EX (played as 5.1) • Dolby Digital Plus decoded and delivered via coaxial or optical connection
Dolby Digital EX	An expansion of Dolby Digital 5.1 that adds a surround back channel that may be played through one or two surround back speakers. May be manually selected when a non-EX Dolby Digital stream is detected.	• Dolby Digital EX • Dolby Digital 2/2/.0 or .1, 3/2/.0 or .1
Dolby Digital Plus	An enhanced version of Dolby Digital encoded more efficiently, Dolby Digital Plus has the capacity for additional discrete channels and for streaming audio from the Internet, all with enhanced audio quality. Source material may be delivered via an HDMI connection or decoded to Dolby Digital or PCM and transmitted via coaxial or optical digital audio.	• Dolby Digital Plus via HDMI connection (source device decodes to Dolby Digital when a coaxial or optical connection is used)
Dolby TrueHD	Dolby TrueHD is an expansion of MLP Lossless™ audio, the same format used on DVD-Audio discs. Dolby TrueHD adds the features found in Dolby Digital, such as night mode settings, while delivering fully lossless audio that is a true reproduction of studio master recordings.	• Blu-ray Disc or HD-DVD encoded with Dolby TrueHD, delivered via HDMI
Dolby Digital Stereo	Delivers a two-channel downmix of Dolby Digital materials.	• Dolby Digital 1/0/.0 or .1, 2/0/.0 or .1, 3/0/.0 or .1, 2/1/.0 or .1, 2/2/.0 or .1, 3/2/.0 or .1 • Dolby Digital EX
Dolby Pro Logic II Mode Group	Analog decoder that derives five full-range, discrete main audio channels from matrix surround-encoded or two-channel analog sources. Four variants are available.	See below
Dolby Pro Logic II Movie	Variant of Dolby Pro Logic II that is optimized for movie and television programs.	• Dolby Digital 2.0 or 2.1 • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
Dolby Pro Logic II Music	Variant of Dolby Pro Logic II that is optimized for music selections. Allows adjustment of sound-field presentation in three dimensions: • Center Width (adjusts width of vocal soundstage) • Dimension (adjusts depth of soundstage) • Panorama (adjusts wraparound surround effect)	• Dolby Digital 2.0 or 2.1 • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
Dolby Pro Logic	Variant of Dolby Pro Logic II that emphasizes use of the surround channels and subwoofer for total immersion in the video gaming experience.	• Dolby Digital 2.0 or 2.1 • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
Dolby Pro Logic II Game	Original version of Dolby Pro Logic that steered a mono signal containing information below 7kHz to the surround channels.	• Dolby Digital 2.0 or 2.1 • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
Dolby Pro Logic IIx Mode Group (AVR 1710/ AVR 171 only)	An expansion of Dolby Pro Logic II that adds a surround back channel which may be played through one or two surround back speakers. The Dolby Pro Logic IIx modes may be selected not only with Dolby Digital bitstreams, but thanks to the AVR's post-processor, they may also be used with some DTS bitstreams to add a surround back channel to 5.1 modes.	See below

Table A10 – Surround Modes – continued

Surround Mode	Description	Incoming Bitstream or Signal
Dolby Pro Logic IIx Music (AVR 1710/ AVR 171 only)	This mode is similar to Dolby Pro Logic II Movie, with an added surround back channel.	• Dolby Digital 2/0/.0 or .1, 2/2/.0 or .1, 3/2/.0 or .1, EX • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
Dolby Pro Logic IIx Music (AVR 1710/ AVR 171 only)	This mode is similar to Dolby Pro Logic II Music, including the availability of center width, dimension and panorama adjustments. Dolby Pro Logic IIx Music adds a surround back channel.	• Dolby Digital 2/0/.0 or .1, 2/2/.0 or .1, 3/2/.0 or .1, EX • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
Dolby Pro Logic IIx Game (AVR 1710/ AVR 171 only)	This mode is similar to Dolby Pro Logic II Game, with the added benefit of a surround back channel.	• Dolby Digital 2/0/.0 or .1 • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz or 48kHz)
Dolby Pro Logic IIz (AVR 1710/ AVR 171 only)	An expansion of Dolby Pro Logic II that adds left and right front height channels that are played through two front height speakers mounted above and outside of the front left and right speakers.	• Dolby Digital 2/0/.0 or .1, 2/2/.0 or .1, 3/2/.0 or .1, EX • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
Virtual speaker	Simulates 5.1 channels when only two speakers are present or a more enveloping sound field is desired.	• Dolby Digital • Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz or 48kHz)
DTS Digital	Using a different encoding/decoding method than Dolby Digital, DTS Digital also provides up to five discrete main channels, plus an LFE channel.	• DTS 1/0/.0 or .1, 2/0/.0 or .1, 3/0/.0 or .1, 3/1/.0 or .1, 2/2/.0 or .1, 3/2/.0 or .1 • DTS-ES Matrix (played as 5.1) • DTS-ES Discrete (played as 5.1)
DTS-HD	DTS-HD is a new high-definition audio format that complements the high-definition video found on Blu-ray Disc and HD-DVD discs. It is transmitted using a DTS core with high-resolution extensions. Even when only DTS 5.1 surround sound is desired (or available, if the multizone system is in use), the higher capacity of high-resolution discs serves up DTS at twice the bit rate used on DVD-Video discs.	• Blu-ray Disc or HD-DVD discs encoded with DTS-HD modes, delivered via HDMI connection
DTS-HD Master Audio	DTS-HD Master Audio technology delivers bit-for-bit reproductions of the studio master recording in up to 7.1 channels for an incredibly accurate performance.	• Blu-ray Disc or HD-DVD discs encoded with DTS-HD Master Audio technology, delivered via HDMI connection
DTS-ES Matrix	DTS Extended Surround adds a single surround back channel to DTS 5.1 digital surround sound. The Matrix version includes the surround back channel information “matrixed” into the left and right (side) surround channels for compatibility with 5.1-channel systems.	• DTS-ES Matrix
DTS-ES Discrete	DTS-ES Discrete is another Extended Surround mode that adds a surround back channel, but this information is encoded discretely on the disc and is not derived from information contained in the surround channels.	• DTS-ES Discrete
DTS Stereo	Delivers a two-channel downmix of DTS Digital materials or presents a matrix-encoded surround presentation.	• DTS 1/0/.0 or .1, 2/0/.0 or .1, 3/0/.0 or .1, 3/1/.0 or .1, 2/2/.0 or .1, 3/2/.0 or .1 • DTS 96/24 • DTS-ES Matrix • DTS-ES Discrete

Table A10 – Surround Modes – continued

Surround Mode	Description	Incoming Bitstream or Signal
DTS Neo:6 Mode Group	DTS Neo:6 analog processing is available with DTS and DTS 96/24 signals and two-channel analog or PCM signals to create a 3-, 5- or 6-channel presentation.	See below
DTS Neo:6 Cinema	Depending on the number of speakers in your system, select 3-, 5- or 6-channel modes, enhanced for movie or video presentations.	• DTS 2/2/.0 or .1, 3/2/.0 or .1 • DTS 96/24 • Analog (two-channel) • PCM (32kHz, 44.1kHz or 48kHz)
DTS Neo:6 Music	Available only in 5- and 6-channel modes, creates a surround presentation suitable for music recordings.	• DTS 2/2/.0 or .1, 3/2/.0 or .1 • DTS 96/24 • Analog (two-channel) • PCM (32kHz, 44.1kHz or 48kHz)
HARMAN NSP	A HARMAN proprietary technology, NSP uses sophisticated digital processing to deliver a true natural sounding three-dimensional listening experience from conventional 2-channel stereo sources like CDs and stereo broadcasts. While preserving the recording's original timbre and spatial balance, HARMAN NSP creates a simulated listening space that automatically adjusts to suit the type of program you are listening to. Adjustments are available for the size of the simulated space and for how aggressively NSP automatically adjusts the simulated space to compliment the program material.	• Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
5-Channel Stereo	Useful for parties, the left- and right-channel information is played through both the front and surround speakers on each side, while the center speaker plays a summed mono mix.	• Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
7-Channel Stereo (AVR 1710/ AVR 171 only)	Expands the 5-Channel Stereo presentation to include the surround back channels.	• Analog (two-channel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)
2-Channel Stereo	Turns off all surround processing and plays a pure two-channel signal or a downmix of a multichannel signal. The signal is digitized and bass management settings are applied, making it appropriate when a subwoofer is used.	• Analog (two-channel; DSP downmix available for multichannel) • Tuner • PCM (32kHz, 44.1kHz, 48kHz, 96kHz)



Refer to the numbered buttons when using the Function List in Table A11.

Table A11 – Remote Control Function List

No.	Button Name	AVR	Radio		NETWORK/vTUNER	Blu-ray/DVD	Media Server DMC1000	TV	USB/iPod
			FM	AM					
01	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On
02	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off
03*	Zone 2	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle
04	Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute
05	Cable/Sat	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
06	STB	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
07	TV	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
08	Disc	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
09	MHL	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
10	Aux	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
11	Audio	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
12	Game	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
13	AVR	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
14	USB	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
15	Network	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
16	Radio	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
17	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes
18	OSD/Menu	Menu	Start	Menu	Menu	Menu		Menu	Menu
19	Up	Up	Up	Up	Up	Up		Up	Up
20	Left	Left	Left	Left	Left	Left		Left	Left
21	OK	OK	Select	Enter	Setup	Select		Enter	Setup
22	Right	Right	Right	Right	Right	Right		Right	Right
23	Down	Down	Down	Down	Down	Down		Down	Down
24	Back/Exit	Bypass	Clear	Exit/Cancel	Exit	Exit		Cancel	Exit
25	Home	MHL Home							
26	1	1	1	1	1	1	1	1	1
27	2	2	2	2	2	2	2	2	2
28	3	3	3	3	3	3	3	3	3
29	4	4	4	4	4	4	4	4	4
30	5	5	5	5	5	5	5	5	5
31	6	6	6	6	6	6	6	6	6
32	7	7	7	7	7	7	7	7	7
33	8	8	8	8	8	8	8	8	8
34	Clear		Clear		Clear	Exit		Clear	Clear
35	9	9	9	9	9	9	9	9	9
36	0	0	0	0	0	0	0	0	0
37	Test								
38	Volume +	Volume +	Volume +	Volume +	Volume +	Volume +	Volume +	Volume +	Volume +
39	Delay								
40	Sleep	Sleep	Sleep	Sleep	Sleep	Sleep	Sleep	Sleep	Sleep
41	Channel/Tuner Up	Channel Up	Scan Up	Channel Up	Page Up	Channel Up	(+10)	Channel Up	Page Up
42	Volume -	Volume –	Volume –	Volume –	Volume –	Volume –	Volume –	Volume –	Volume –
43	Info/Option	Options	Options	Options	Options				Options
44	Dim								
45	Channel/Tuner Down	Channel Down	Scan Down	Channel Down	Page Down	Channel Down	Disc Skip	Channel Down	Page Down
46	Preset Scan								
47	Direct								
48	Memory	FAV				Repeat/Live TV			
49	RDS								
50	Previous		Slow Down	Back	Previous	Thumb Down	Skip Down	Scan Down	Previous
51	Rew ◄◄		Previous	Rew ◄◄	Rew ◄◄	Rew ◄◄	R. Search	Rew ◄◄	Rew ◄◄
52	FF ►►	FF ►►	Next	FF ►►	FF ►►	FF ►►	F. Search	FF ►►	FF ►►
53	Next		Slow Up	Replay	Next	Thumb Up	Skip Up	Scan Up	Next
54	Top Menu								
55	Stop		Stop	Stop	Stop	Stop	Stop	Stop	Stop
56	Play ►/Pause		Play ►/Pause	Play ►/Pause	Play ►/Pause	Play ►/Pause	Play ►/Pause	Play ►/Pause	Play ►/Pause
57	Prev. CH			Prev. Ch					

* AVR 1710/AVR 171 only.

Table A11 – Remote Control Function List – continued

				DVR			AUX	
No.	Button Name	Cable/SAT	Game	HDTV	PVD	TIVO	CD	VCR
01	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On	AVR Power On
02	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off	AVR Power Off
03*	Zone 2	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle	Zone 2 Toggle
04	Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute	AVR Mute
05	Cable/Sat	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
06	STB	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
07	TV	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
08	Disc	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
09	MHL	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
10	Aux	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
11	Audio	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
12	Game	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
13	AVR	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
14	USB	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
15	Network	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
16	Radio	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel	Input Sel
17	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes	Surround Modes
18	OSD/Menu	Menu	Start	Menu	Menu	Menu		Menu
19	Up	Up	Up	Up	Up	Up		Up
20	Left	Left	Left	Left	Left	Left		Left
21	OK	OK	Select	Enter	Setup	Select		Enter
22	Right	Right	Right	Right	Right	Right		Right
23	Down	Down	Down	Down	Down	Down		Down
24	Back/Exit	Bypass	Clear	Exit/Cancel	Exit	Exit		Cancel
25	Home							
26	1	1	1	1	1	1	1	1
27	2	2	2	2	2	2	2	2
28	3	3	3	3	3	3	3	3
29	4	4	4	4	4	4	4	4
30	5	5	5	5	5	5	5	5
31	6	6	6	6	6	6	6	6
32	7	7	7	7	7	7	7	7
33	8	8	8	8	8	8	8	8
34	Clear		Clear		Clear	Exit		Clear
35	9	9	9	9	9	9	9	9
36	0	0	0	0	0	0	0	0
37	Test							
38	Volume +	Volume +	Volume +	Volume +	Volume +	Volume +	Volume +	Volume +
39	Delay							
40	Sleep	Sleep	Sleep	Sleep	Sleep	Sleep	Sleep	Sleep
41	Channel/Tuner Up	Channel Up	Scan Up	Channel Up	Page Up	Channel Up	(+10)	Channel Up
42	Volume -	Volume –	Volume –	Volume –	Volume –	Volume –	Volume –	Volume –
43	Info/Option							
44	Dim							
45	Channel/Tuner Down	Channel Down	Scan Down	Channel Down	Page Down	Channel Down	Disc Skip	Channel Down
46	Preset Scan							
47	Direct							
48	Memory	FAV				Repeat/Live TV		
49	RDS							
50	Previous		Slow Down	Back	Previous	Thumb Down	Skip Down	Scan Down
51	Rew ◄◄		Previous	Rew ◄◄	Rew ◄◄	Rew ◄◄	R. Search	Rew ◄◄
52	FF ►►	FF ►►	Next	FF ►►	FF ►►	FF ►►	F. Search	FF ►►
53	Next		Slow Up	Replay	Next	Thumb Up	Skip Up	Scan Up
54	Top Menu							
55	Stop		Stop	Stop	Stop	Stop	Stop	Stop
56	Play ►/Pause		Play ►/Pause	Play ►/Pause	Play ►/Pause	Play ►/Pause	Play ►/Pause	Play ►/Pause
57	Prev. CH			Prev. Ch				

* AVR 1710/AVR 171 only.

Refer to Tables A12 through A22 when programming the codes for your components into the remote.

Table A12 – Remote Control Product Codes: TV

TV Manufacturer/Brand	Setup Code Number
ADMIRAL	192
ANAM	045 106 109 112 122
AOC	037 122 123 128
AUDIOVOX	012
BLAUPUNKT	084
BROKSONIC	205 206
CITIZEN	045 123 128 132
CONTEC	045
CRAIG	045 157 158 159
CROWN	045 132
CURTIS MATHES	123 128 132
DAEWOO	045 087 102 105 106 108 111 114 116 119 127 128 132
DAYTRON	128 132
DYNATECH	063
DYNEX	014
ELECTROHOME	115 132
EMERSON	045 123 128 132 139 157 158 159 162 205
FUJITSU	041 042
FUNAI	045
FUTURETECH	045
GE	029 087 121 123 128 133 145 159 163
GRUNDIG	193
HALL MARK	128
HARMAN KARDON	201
HITACHI	123 128 132 144 147
HYTEK	016
INKEL	120
JC PENNEY	115 123 128 132 145
JENSEN	019
JVC	079 087 134
KEC	045
KLH	006
KTV	045 123 132 162
LG/GOLDSTAR	002 013 101 110 122 128 132
LLOYTRON	172 173
LODGENET	069
LXI 077	145 148
MAGNAVOX	030 040 123 128 132 145 148
MARANTZ	115 123 148
MEMOREX	069 128
METZ	084
MGA	115 123 128
MITSUBISHI	077 115 123 128 160 167 168
MTC	175 176
NATIONAL	148 177 179 180 181 182
NEC	010 115 121 123 125
OLEVIA	007
OPTONICA	077
ORION	207 208 209 210 211
PANASONIC	087 148 169
PHILCO	045 115 123 128 132 148
PHILIPS	033 034 035 036 123 128 132 145 148
PIONEER	024 123 128
POLAROID	003 004 005 006 043
PORTLAND	128 132
PROSCAN	133
PROTON	008 059 122 128 132 165
QUASAR	032 087
RADIO SHACK	045 128 132 180 196 197
RCA	021 115 123 128 133 145 161 163
REALISTIC	045 167 196
RUNCO	044 046 152 153
SAMPO	059 123 128
SAMSUNG	020 022 124 128 132 145
SANYO	026 054
SCOTT	045 128 132
SEARS	128 132 145
SHARP	077 128 132
SIEMENS	084
SIGNATURE	069
SONY	028 031 117 130 136 194 212
SOUNDESIGN	045 128
SYLVANIA	025 123 128 145 148
SYMPHONIC	184
TANDY	077
TATUNG	063
TECHNICS	181
TECHWOOD	128
TEKNIKA	045 069 115 123 128 132
TELERENT	069
TERA	156
THOMSON	190 191
TIVO	051 052 and See Table A22
TMK	128
TOSHIBA	063 129 202
TOTEVISION	132
VIDEO CONCEPTS	160
VIDTECH	128
VIEWSONIC	011 038 039 047
VIZIO	001 002
WARDS	069 128 132 148
WESTINGHOUSE	017 018 023
YAMAHA	123 128
YORK	128
ZENITH	069 090

Table A13 – Remote Control Product Codes: AUX-HDTV

TV Manufacturer/Brand	Setup Code Number
APEX	614 616
DISH NETWORK	612
LG	604
MAGNAVOX	607 608 609 610 611
MOTOROLA	605
RCA	601 612
SAMSUNG	603
TATUNG	618
TIVO	See Table A22
ZENITH	602 606 619

Table A14 – Remote Control Product Codes: AUX-VCR

VCR Manufacturer/Brand	Setup Code Number
AIWA	340
AKAI	348 408 409 426
AUDIO DYNAMICS	318 348
BROKSONIC	410 447
CANON	435 440
CAPEHART	394
CITIZEN	434
CRAIG	345 416
DAEWOO	317 394 404
DAYTRON	394
DBX	318 348
DYNATECH	340
EMERSON	313 340 342 410 412
FISHER	317
FUNAI	340
GE	376 395 424
HARMAN KARDON	302 303 318 349
HITACHI	340 348
JC PENNEY	318 345
JENSEN	348
JVC	318 348 411 432
KENWOOD	320 348
LG/GOLDSTAR	318 407
LLOYD	340
LXI	320 340
MAGNAVOX	340
MARANTZ	318
MEMOREX	317 320 340 352 353 354 376 442
MGA	349
MITSUBISHI	349 431
MULTITECH	340
NAD	439
NATIONAL	440
NEC	318 348
NORDMENDE	348
OPTIMUS	459
ORION	447
PANASONIC	425 450 467 472
PHILCO	340
PHILIPS	340 375
PORTLAND	394
PULSAR	376
QUASAR	301 425
RADIO SHACK	355 434 440 442 458 459
RCA	395 424 425 457 472
REALISTIC	317 320 340 345 459
SAMSUNG	345 351 395 405 409
SANSUI	348 416 447
SANYO	317 320
SCOTT	410 412
SEARS	317 320
SHARP	429 456
SONY	380 429
SOUNDESIGN	340
SYLVANIA	340
SYMPHONIC	340
TANDY	317 340
TEAC	340 348
TEKNIKA	340
THOMAS 340	
TIVO See Table A22	
TMK	313
TOSHIBA	412 455
TOTEVISION	345
UNITECH	345
VECTOR RESEARCH	318
VIDEO CONCEPTS	318 340
VIDEOSONIC	345
WARDS	340 345 412
YAMAHA	318 340 348
ZENITH	340 350 376 383

Table A15 – Remote Control Product Codes: AUX-CD

CD Manufacturer/Brand	Setup Code Number
ADCOM	063 069
AIWA	072 111 118 156 170
AKAI	050 177 184
AUDIO TECHNICA	053
AUDIOACCESS	125
AUDIOFILE	211
BSR	044
CALIFORNIA AUDIO	109
CAPETRONIC	070
CARRERA	087
CARVER	136 140 141 143 144 145 185 186
CASIO	117 166
CLARINETTE	166
DENON	187 188 213
EMERSON	052 093 108
FISHER	055 095
FUNAI	126
GE	164
HAITAI	099 214
HARMAN KARDON	001 002 025 054 190
HITACHI	093
INKEL	216
JC PENNEY	098 147
JENSEN	153
JVC	176 195 196
KENWOOD	030 062 078 079 148 151 176 178 181
LG/GOLDSTAR	016 087
LOTTE	108
LUXMAN	077 102
LXI	164
MAGNAVOX	039 113
MARANTZ	058 084 191 192 193
MCINTOSH	194
MCS	080 098
MITSUMI	152
MODULAIRE	166
NAD	013 074 197 198
NAKAMICHI	199 200 201
NEC	069
NIKKO	053 055
ONKYO	037 038 045 046 171 175 202 203
OPTIMUS	065 089 091 092 099 104 212
PANASONIC	075 109 119 158 183 204
PHILIPS	039 138 149 209
PIONEER	071 094 100 112 123 131 161 162 215
PROTON	210
RADIO SHACK	126 166 213
RCA	024 081 093 150
REALISTIC	058 093 095 104 105 108 164 166
SANSUI	047 081 134 157 172
SANYO	033 082 095
SCOTT	108
SHARP	058 105 114 151 159 167 180 181
SHERWOOD	003 041 058 105 133
SONY	103 115 116 118 132 139 163 205 206 207 208 212 217
SOUNDSTREAM	124
SYMPHONIC	059 110
TAEKWANG	177
TEAC	011 058 085 086 106 107 110 121 137 146 154
THETA DIGITAL	039
TOSHIBA	013 074 097 151 155 173
VECTOR RESEARCH	087
VICTOR	120 130
WARDS	095
YAMAHA	019 031 053 061 135 169
YORK	166

Table A16 – Remote Control Product Codes: DVD

DVD Manufacturer/Brand	Setup Code Number
APEX DIGITAL	061
DENON	019 020 051
GE	003 004
HARMAN KARDON	001 002 032
JVC	006
LG/GOLDSTAR	005 010 055 064 066
MAGNAVOX	056
MARANTZ	059
MITSUBISHI	023
NAD	062
ONKYO	009 048
PANASONIC	008 024 030 044
PHILIPS	016 056
PIONEER	018 027 041 065
PROCEED	060
PROSCAN	003 004
RCA	003 004
SAMSUNG	017 053 054
SHARP	028
SONY	011 012 015 043 045
THOMSON	003 004
TOSHIBA	009 058 067
YAMAHA	030 063
ZENITH	005 055 064

Table A17 – Remote Control Product Codes: SAT

SAT Manufacturer/Brand	Setup Code Number
BIRDVIEW	425
CHANNEL MASTER	320 321 325 361
CHAPARRAL	315 316 451
CITOH	360
DIRECTV	309 310 314
DISH NETWORK	364
DRAKE	313 317 318 413 481
DX ANTENNA	331 352 379 483
ECHOSTAR	364 395 397 452 453 463 477 478 484 485
ELECTRO HOME	392
FUJITSU	324 329 334
GENERAL INSTRUMENT	303 311 323 365 403 454 468 474
HITACHI	304 455
HOUSTON TRACKER	463
HUGHES	305 306 437 489
JANIEL	366
JERROLD	454 468 484
LEGEND	453
MACOM	317 365 369 370 371
MAGNAVOX	461 473
MEMOREX	453
MITSUBISHI	307
MOTOROLA	312 319
NEXTWAVE	423
NORSAT	373
OPTIMUS	466
PACE	328 487
PANASONIC	353 366 457 469
PANSAT	420
PERSONAL CABLE	418
PHILIPS	375
PICO	407
PRESIDENT	381 404
RCA	301 358 439 458 465 490
REALISTIC	349 480
SAMSUNG	322 326 442
SATELLITE SERVICE CO	335 388
SCIENTIFIC ATLANTA	339 356
SONY	362 405
STAR CHOICE DBS	459
STARCAST	347
SUPER GUIDE	327 423
TELECOM	330 333 390 391 393 409
TOSHIBA	302 426 460 461 462 470
UNIDEN	323 332 348 349 350 351 354 355 381 383 389 403 466 479 480
ZENITH	359 384 385 387 394 419 488

Table A18 – Remote Control Product Codes: Game

GAME Manufacturer/Brand	Setup Code Number
Microsoft (XBOX, XBOX 360)	001 003
NYKO (PS3)	005
SONY (PS2, PS3)	002 004

Table A19 – Remote Control Product Codes: Cable

Cable Manufacturer/Brand	Setup Code Number
ABC	001 011
ALLEGRO	111
AMERICAST	212
ARCHER	112
BELCOR	113
CABLE STAR	033 113
CITIZEN	111
COMCAST	007
DIGI LINK	114
EAGLE	186
EASTERN	066 070
EMERSON	112
GENERAL INSTRUMENT	001 011 017 096 097 210
GC ELECTRONICS	113
GEMINI	032 060
HAMLIN	056 099 100 101 117 175 208
HITACHI	001 188
JASCO	111
JERROLD	001 002 011 017 073 096 097 162 188 210
LINSAY	118
MACOM	191
MAGNAVOX	017 019 068
MOVIETIME	035 039
NSC	035 190
OAK	197 220
PACE	179
PANASONIC	053 176 177 189 214
PANTHER	114
PHILIPS	013 019 020 085 090
PIONEER	001 041 119 171 209 215 216
RADIO SHACK	111 112 213
RCA	053 214
RECOTON	116
REGAL	056 099 100 101 208
REMBRANT	032
SAMSUNG	003 072 186
SCIENTIFIC ATLANTA	183 203 221 222
SEAM	121
SIGNATURE	001 188
SPRUCER	053 081 177 189

Table A19 – Remote Control Product Codes: Cable – continued

Cable Manufacturer/Brand	Setup Code Number
STARCOM	002 011 163
STARGATE	120
TANDY	024
TELECAPATION	028
TEXSCAN	036
TFC	122
TIVO	029 030 and See Table A22
TOCOM	170 205
UNITED CABLE	011
UNIVERSAL	033 034 039 042 113
VIDEOWAY	124 211
VIEWSTAR	019 025 053 086 089 190
ZENITH	065 125 211 219

Table A20 – Remote Control Product Codes: Media Server

Manufacturer/Brand	Setup Code Number
APPLE	008 009
BEYOND	003
ESCIENT (FIREBALL)	004 005 006 007
HARMAN KARDON	001 002
LOGITECH	012
MICROSOFT	003
NAIM	011
REQUEST	010
SONOS	013

Table A21 – Remote Control Product Codes: AUX-Cable/SAT Recorder (PVR)

Manufacturer/Brand	Setup Code Number
DAEWOO	701 704
ECHOSTAR	714 715 716
EXPRESSVU	714
HUGHES	717 727
HYUNDAI	718
PANASONIC	710 723
PHILIPS	711 717 724 727
PROSCAN	719
RCA	719 727
REPLAYTV	708 710 712 725 726
SONICBLUE	710 712
SONY	707 713 720 721 722 723 724

Table A22 – Remote Control Product Codes: AUX- TiVo

Manufacturer/Brand	Setup Code Number
COMCAST TIVO	808
COX TIVO	808
DIRECTV TIVO	806
HUMAX TIVO	803
Nero LiquidTV TIVO	805
PIONEER TIVO	801
TIVO HD XL DVR	807
TIVO HD DVR	804
TIVO SERIES2™ DT DVR	802
TOSHIBA TIVO	803

HARMAN

HARMAN International Industries, Incorporated
8500 Balboa Boulevard, Northridge, CA 91329 USA

© 2013 HARMAN International Industries, Incorporated. All rights reserved. Harman Kardon is a trademark of HARMAN International Industries, Incorporated, registered in the United States and/or other countries. EzSet/EQ is a trademark of HARMAN International Industries, Incorporated. The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by HARMAN International Industries, Incorporated, is under license. Other trademarks and trade names are those of their respective owners. Apple, AirPlay, iPhone, iPod and iTunes are trademarks of Apple Inc., registered in the U.S. and other countries. Blu-ray Disc is a trademark of the Blu-ray Disc Association.CEA is a registered trademark of the Consumer Electronics Association. DLNA®, the DLNA Logo and DLNA CERTIFIED® are trademarks, service marks, or certification marks of the Digital Living Network Alliance. Manufactured under license from Dolby Laboratories. Dolby, Pro Logic, and the double-D symbol are trademarks of Dolby Laboratories. MLP Lossless is a trademark of Dolby Laboratories. Manufactured under license under U.S. Patent #'s 5,956,674; 5,974,380; 6,226,616; 6,487,535; 7,212,827; 7,333,929; 7,392,195; 7,272,567 & other U.S. and worldwide patents issued and pending. DTS-HD, the Symbol, & DTS-HD and the Symbol together are registered trademarks, and DTS-HD Master Audio is a trademark, of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved. HDMI, the HDMI logo and High-Definition Multimedia Interface are registered trademarks of HDMI Licensing LLC in the United States and other countries. Intel is a registered trademark of Intel Corporation. iOS is a registered trademark of Cisco Systems, Inc., and/or its affiliates in the United States and certain other countries. Roku is a registered trademark of Roku, Inc. Roku Streaming Stick is a trademark of Roku, Inc. All rights reserved. TiVo is a registered trademark of TiVo Inc. Series2 is a trademark of TiVo, Inc. Windows Media is a registered trademark of Microsoft Corporation in the United States and/or other countries.

Features, specifications and appearance are subject to change without notice.

Part No. HKP5094 Rev. A

harman/kardon® by HARMAN

www.harmankardon.com

BDT 3/BDT 30

Blu-ray Disc™ -Player

Bedienungsanleitung

harman/kardon®
by HARMAN

Inhaltsverzeichnis

WICHTIGE SICHERHEITSANWEISUNGEN	3
AUSPACKEN	5
AUFSTELLUNGSORT	5
REINIGUNG	5
VIELEN DANK, DASS SIE SICH FÜR EIN PRODUKT VON HARMAN KARDON® ENTSCHIEDEN HABEN	5
BDT 3/BDT 30-LEISTUNGSMERKMALE	6
LIEFERUMFANG	6
BEDIENELEMENTE AN DER VORDERSEITE	7
ANSCHLÜSSE AUF DER RÜCKSEITE	8
FUNKTIONEN DER FERNBEDIENUNG	8
BD-SPIELER ANSCHLIESSEN	10
FERNBEDIENUNG IN BETRIEB NEHMEN	10
BD-SPIELER KONFIGURIEREN	11
DISK-WIEDERGABE	14
WIEDERGABE VON USB-MEDIEN UND DATEN-CDS	16
WIEDERGABELISTEN VERWENDEN	18
FEHLERBEHEBUNG	19
SPEZIFIKATIONEN	20

DEUTSCH

Wichtige Sicherheitsanweisungen

1. Lesen Sie diese Anweisungen.
2. Bewahren Sie diese Anweisungen auf.
3. Nehmen Sie alle Warnungen ernst.
4. Befolgen Sie alle Anweisungen.
5. Verwenden Sie dieses Gerät nicht in der Nähe von Wasser.
6. Reinigen Sie dieses Gerät nur mit einem trockenen Tuch.
7. Achten Sie darauf, keine Lüftungsöffnungen zu blockieren. Stellen Sie dieses Produkt so auf, wie vom Hersteller empfohlen.
8. Stellen Sie das Produkt nicht in der Nähe von Wärmequellen wie Heizstrahler, Heizkörper, Öfen oder anderen Geräten (einschließlich Verstärker-Endstufen) auf.
9. Setzen Sie den zu Ihrem Schutz vorgesehen Sicherheitsmechanismus des gepolten Steckers oder Schukosteckers nicht außer Kraft. Ein gepolter Stecker hat zwei Plättchen, von denen eines breiter als das andere ist. Ein Schukostecker hat zwei Plättchen und einen dritten Erdungsstift. Das breitere Plättchen oder der dritte Stift dienen Ihrer Sicherheit. Wenn der gelieferte Stecker nicht in Ihre Steckdose passt, wenden Sie sich bitte an einen Elektriker, damit die veraltete Steckdose ausgewechselt werden kann.
10. Verlegen Sie das Stromkabel so, dass niemand darauf stehen oder gehen kann und es nicht eingeklemmt wird, vor allem im Bereich von Steckern und Steckdosen und an der Stelle, an der das Kabel aus dem Gerät hervortritt.
11. Verwenden Sie ausschließlich Zubehör, das der Hersteller empfiehlt.
12. Verwenden Sie das Gerät nur mit dem Wagen, Ständer, Stativ, der Halterung oder dem Tisch, der/die vom Hersteller vorgegeben sind oder gemeinsam mit dem Gerät verkauft werden. Wenn ein Wagen verwendet wird, ist Vorsicht zu üben, wenn die Wagen/Gerät-Kombination bewegt wird, um Verletzungen zu vermeiden, die ein umkippender Wagen verursachen könnte.

13. Ziehen Sie das Stromkabel dieses Geräts bei Gewitter oder während langer Zeiträume, in denen das Gerät nicht gebraucht wird, von der Steckdose ab.
14. Lassen Sie alle Wartungsarbeiten von qualifiziertem Fachpersonal ausführen. In folgenden Fällen müssen Sie das Gerät sofort von der Stromversorgung trennen, und danach eine autorisierte Werkstatt aufsuchen: defektes Netzkabel oder Netzstecker, ins Gehäuse sind Gegenstände oder Flüssigkeiten eingedrungen, das Gerät wurde Regen oder Wasser ausgesetzt, das Gerät arbeitet nicht einwandfrei oder fiel herunter.
15. Setzen Sie dieses Gerät keiner Umgebung aus, in der Tropfen oder Spritzer auf das Gerät gelangen könnten, und stellen Sie sicher, dass keine Gegenstände auf dem Gerät abgestellt werden, die mit Flüssigkeit gefüllt sind, wie beispielsweise Vasen.
16. Möchten Sie dieses Gerät vollständig vom Stromnetz trennen, müssen Sie das Netzkabel aus der Steckdose ziehen.
17. Der Netzstecker des Netzkabels muss stets betriebsbereit sein.
18. Setzen Sie Batterien keiner übermäßigen Wärme wie Sonne, Feuer oder einer anderen Wärmequelle aus.

DER BLITZ MIT PFEILSYMBOL INNERHALB EINES GLEICHSEITIGEN DREIECKS IST DAFÜR VORGESEHEN, DEN BENUTZER AUF DAS VORHANDENSEIN NICHT ISOLIERTER "GEFÄHRLICHER STROMSPANNUNG" INNERHALB DES PRODUKTGEHÄUSES HINZUWEISEN DIE AUSREICHT, UM EINE STROMSCHLAGGEFAHR FÜR PERSONEN DARZUSTELLEN.

CAUTION

STROMSCHLAGGEFAHR
NICHT ÖFFNEN

WARNUNG: DIESES GERÄT DARF WEDER REGEN NOCH SONSTIGER FEUCHTIGKEIT AUSGESETZT WERDEN, UM DAS RISIKO EINES BRANDES ODER STROMSCHLAGS ZU VERRINGERN.

DAS AUSRUFEZEICHEN INNERHALB EINES GLEICHSEITIGEN DREIECKS SOLL DEN BENUTZER AUF WICHTIGE BETRIEBS- UND WARTUNGSANWEISUNGEN AUFMERKSAM MACHEN, DIE IN DEN MIT DEM PRODUKT GELIEFERTEN UNTERLAGEN ENTHALTEN SIND.

SIEHE MARKIERUNG AUF DER GERÄTERÜCKSEITE.

FCC-Vorschriften

FCC-Informationen für Benutzer

Dieses Gerät erfüllt Teil 15 der FCC-Regeln. Der Betrieb unterliegt den folgenden beiden Bedingungen: (1) Dieses Gerät darf keine funktechnischen Störungen verursachen, und (2) dieses Gerät muss sämtliche empfangenen Störungen aufnehmen können, darunter Störungen, die unerwünschte Funktionen verursachen können.

Radio- und Fernsehstörungen

Dieses Gerät wurde getestet und entspricht den Grenzwerten digitaler Geräte der Klasse B gemäß Abschnitt 15 der FCC-Bestimmungen. Diese Grenzwerte dienen dem angemessenen Schutz vor funktechnischen Störungen bei der Installation in Wohnbereichen. Dieses Gerät erzeugt und nutzt HF-Energie und kann diese abstrahlen. Bei unsachgemäßer Installation und Verwendung, ohne Befolgen der Anweisungen, kann es schädliche Störungen im Funkverkehr verursachen. In Einzelfällen kann es jedoch auch bei sachgemäßer Verwendung zu Störungen kommen. Sollte dieses Gerät beim Radio- oder Fernsehempfang Störungen verursachen, was durch Aus- und Wiedereinschalten des Geräts festgestellt werden kann, wird der Benutzer gebeten, zu versuchen, die Störung durch eine oder mehrere der folgenden Maßnahmen zu beheben:

- Vergrößern Sie den Abstand zwischen dem Gerät und dem Receiver.
- Schließen Sie das Gerät an eine andere Wandsteckdose an, damit sich das Gerät und der Receiver auf unterschiedlichen Zweigstromkreisen befinden.
- Lassen Sie sich von Ihrem Händler oder einem erfahrenen Radio-/Fernsehtechniker beraten.

HINWEIS: Änderungen oder Modifizierungen, die von HARMAN nicht ausdrücklich genehmigt wurden, könnten die Befugnis des Benutzers zum Betreiben des Geräts ungültig machen.

IC-Aussage und Warnung (nur Kanada)

Dieses digitale Gerät der Klasse B entspricht der kanadischen Richtlinie ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Für kanadisches Modell

Dieses digitale Gerät der Klasse B entspricht der kanadischen Richtlinie ICES-003. Bei Geräten mit Polkennzeichnung gilt:

ACHTUNG: Schützen Sie sich vor Stromschlag, indem Sie den breiten Kontakt in die breite Buchse vollständig einführen.

Für kanadisches Modell

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. Sur les modèles dont la fiche est polarisee:

ATTENTION: Pour éviter les chocs électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
CLASSE 1 PRODUIT LASER

ACHTUNG: Dieses Produkt verwendet ein Lasersystem. Um zu verhindern, dass der Benutzer dem Laserstrahl direkt ausgesetzt wird, darf das Gehäuse nicht geöffnet werden, und es dürfen auch keine der Sicherheitsmechanismen, die zu Ihrem Schutz geboten sind, außer Kraft gesetzt werden. SEHEN SIE NICHT DIREKT IN DEN LASERSTRAHL. Lesen Sie die Bedienungsanleitung sorgfältig durch, um eine ordnungsgemäße Verwendung dieses Produkts sicherzustellen, und bewahren Sie die Anleitung zum eventuellen späteren Gebrauch auf. Sollte das Gerät Wartung oder Reparatur benötigen, wenden Sie sich bitte an Ihre örtliche Harman Kardon-Vertragswerkstatt. Wartungsarbeiten dürfen nur von qualifiziertem Fachpersonal ausgeführt werden.

Hinweise zum Ausbau und zur umweltgerechten Entsorgung verbrauchter Batterien.

Handhabung verschiedener Batterietypen.



Die oben abgebildeten Symbole können auf dem Gehäuse eines Produkts, dessen Verpackung sowie in den Unterlagen oder der Bedienungsanleitung auftreten. Sie zeigen an, dass sowohl das Produkt selbst, als auch die mitgelieferten oder im Produkt verbauten Batterien niemals in den Hausmüll gelangen dürfen. Sie müssen umweltgerecht (entsprechend lokaler Richtlinien oder gemäß den Europäischen Richtlinien 2002/96/EG und 2006/66/EG) entsorgt werden. Bitte informieren Sie sich, wo sich in Ihrer Nähe die nächste Abgabestelle für Elektronikschrott oder ein Recycling-Hof befindet.

Der korrekte Umgang mit dem Produkt und den Batterien hilft Ressourcen zu schonen und beugt Schäden an der menschlichen Gesundheit und der Umwelt vor.

Die mitgelieferten Batterien können unterschiedlichen Typs sein: Alkaline, Kohle/Zink oder Lithium. Sie müssen alle gemäß den oben genannten Anweisungen umweltgerecht entsorgt werden.

Folgen Sie den Hinweisen in der Bedienungsanleitung, um die Batterien aus dem Gerät bzw. der Fernbedienung zu entfernen.

Bei Produkten mit eingebauten Batterien, die für die gesamte Lebensdauer des Produkts vorgesehen sind, ist es für den Benutzer eventuell nicht möglich, die Batterien zu entfernen. In diesem Falle übernehmen Recycling- oder Rückgewinnungszentren die Demontage des Produkts und das Entfernen der Batterie. Sollte es aus irgendeinem Grund erforderlich werden, eine solche Batterie auszuwechseln, muss dieses Verfahren von einem autorisierten Servicecenter ausgeführt werden.

DEUTSCH

Auspacken

Der Karton und das Verpackungsmaterial dienen zum Schutz Ihres Gerätes vor Stößen und Erschütterungen beim Transport. Wir empfehlen deshalb, dass Sie das Material aufbewahren, damit Sie es z. B. bei einem Umzug oder bei einer Reparatur wiederverwenden können.

Selbstverständlich können Sie den Karton zusammenfalten und so Stauraum sparen. Entfernen Sie dazu bitte vorsichtig eventuelle Heftklammern, und ritzen Sie das Klebeband an der Unterseite ein. Das Füllmaterial lässt sich ähnlich aufbewahren. Verpackungsmaterial, das sich nicht zusammenlegen lässt, sollten Sie in einem Plastikbeutel aufbewahren.

Sie wollen Karton und Verpackungsmaterial nicht aufbewahren? Kein Problem: Es ist recycelbar. Bitte schützen Sie die Umwelt und entsorgen Sie es ordnungsgemäß in einem Recycling-Zentrum in Ihrer Umgebung.

Entfernen Sie die durchsichtige Schutzfolie vom Infrarotsensor an der Gerätevorderseite. Tun Sie dies nicht, kann der Empfang von Infrarotsignalen beeinträchtigt werden.

Aufstellungsort

- Um einen reibungslosen Betrieb sicherzustellen und zur Vermeidung von Gefahren, stellen Sie das Gerät bitte nur auf eine feste und ebene Fläche. Falls Sie das Gerät in ein Regal stellen, sollten Sie sich vorher vergewissern, ob es das Gewicht auch aushält.
- Bitte achten Sie beim Aufstellen darauf, dass zur Belüftung des Gerätes oben und unten genügend Freiraum bleibt. Wird das System in einen Schrank oder ähnliches eingebaut, achten Sie bitte auf ausreichende Luftzirkulation. Notfalls müssen Sie einen Ventilator verwenden.
- Bitte platzieren Sie das Gerät nicht direkt auf einem Teppich.
- Stellen Sie das Gerät nicht in einem extrem heißen oder kalten Raum auf. Schützen Sie die Einheit vor direktem Sonnenlicht und stellen Sie sie nicht in der Nähe von Heizkörpern auf.
- Vermeiden Sie Feuchtigkeit.
- Die Lüftungsschlitze auf der Geräteoberseite dürfen nicht verdeckt sein; bitte auch keine Gegenstände darauf abstellen – sie verhindern die Luftzirkulation.
- Platzieren Sie den BDT 3/BDT 30 nicht direkt auf ein Gerät, das viel Abwärme produziert (z. B. eine leistungsstarke Endstufe).
- Der BD-Spieler erzeugt im laufenden Betrieb Wärme. Aus diesem Grund können unter Umständen die Standfüße auf der Gehäuseunterseite auf bestimmten Holz- und Furnierarten Abdrücke hinterlassen. Daher sollten Sie das Gerät nicht auf Oberflächen aus weichem Holz oder anderen Materialien abstellen, die durch die erzeugte Wärme oder das Eigengewicht des Gerätes beschädigt werden könnten. Werkstoffe wie Holzfurniere oder Kunststoffoberflächen reagieren sehr unterschiedlich auf Wärme, Gewicht und Vibrationen – Harman Kardon hat auf dieses Verhalten keinen Einfluss. Deswegen sollten Sie den Aufstellungsort mit Vorsicht auswählen, da Schäden an Ihren Möbeln nicht durch die Gerätegarantie abgedeckt werden.
- Ihr neuer Harman Kardon Blu-ray Disc™ -Player benötigt für den interaktiven BD-Live™ -Betrieb eine Verbindung zum Internet.

Reinigung

- Reinigen Sie das Gerät stets nur mit einem sauberen, weichen, trockenen Tuch. Falls nötig und nur nachdem Sie den Netzstecker gezogen haben, können Sie es zunächst mit mildem Seifenwasser abwischen, gefolgt von einem mit reinem Wasser angefeuchteten Tuch. Trocknen Sie danach die feuchte Oberfläche sofort wieder ab. NIEMALS Benzol, Sprühreiniger, Alkohol, Verdünner oder irgendein anderes flüchtiges Reinigungsmittel verwenden. Reinigungsmittel mit kratzenden bzw. schleifenden Partikeln beschädigen die Oberfläche der Metallteile. Versprühen Sie bitte auch kein Insekten-Vernichtungsmittel in unmittelbarer Nähe des Gerätes.

Bitte registrieren Sie Ihr Produkt im Internet unter www.harmankardon.com.

Hinweis: Dazu werden Sie die Seriennummer benötigen. Während der Registrierung können Sie angeben, ob Sie über neue Produkte und/oder spezielle Angebote informiert werden möchten.

Vielen Dank, dass Sie sich für ein Produkt von Harman Kardon® entschieden haben!

Seit mehr als 50 Jahren stehen die Produkte von Harman Kardon an der Spitze der technischen Entwicklung im Audio- und Heimkino-Bereich. Schon auf dem weltweit ersten Audio-Receiver prangte das Typenschild von Harman Kardon, und bis heute kommen die fortschrittlichsten Audioprodukte aus unserem Hause. Der BDT 3/BDT 30 Blu-ray Disc™ -Player ist ein neues Glanzstück in dieser bewährten Tradition.

Allerneueste Technik für die 3-D- sowie HD-Ton- und Bildwiedergabe macht den BDT 3/BDT 30 zum unentbehrlichen Bestandteil eines modernen Heimkino-Systems. Mit diesem Gerät können Sie Ihre Lieblingsfilme auf BD mit einer Videoauflösung von bis zu 1080/24p abspielen, wenn diese auf der Disk verfügbar ist, und dank HDMI® (High-Definition Multimedia Interface®) 1.4a mit 30/36-B Deep Color können Sie die neueste 3D-Heimkinounterhaltung genießen, wenn Sie das Gerät an einen 3D-fähigen Fernseher anschließen.

Verbinden Sie den BDT 3/BDT 30 mit dem Internet, so liefert die BD-Live™ -Interaktivität (verfügbar bei kompatiblen Disks) zusätzliche Funktionen, Updates und Neuigkeiten über Live-Ereignisse. Und selbst ältere DVDs werden mit einer überwältigenden Bildqualität dargestellt, da Ihr neuer BD-Spieler sie auf eine Videoauflösung von 1080p hochskaliert.

Trotz seiner vielfältigen Fähigkeiten lässt sich der BDT 3/BDT 30 sehr einfach handhaben. Die Bedienelemente gleichen denen eines üblichen DVD-Spielers, und anhand der erweiterten, menügesteuerten Benutzerführung über Ihren TV-Bildschirm können Sie mühelos auf alle Funktionen komfortabel zugreifen. Dank der überaus einfachen Handhabung und seiner überragenden Leistungsmerkmale garantiert Ihnen der BDT 3/BDT 30 langjährigen Mediengenuss in höchster Qualität.

Falls Sie irgendwelche Fragen zu diesem Produkt, seiner Inbetriebnahme oder seiner Bedienung haben sollten, wenden Sie sich bitte an Ihren Fachhändler, oder besuchen Sie die Homepage von Harman Kardon unter der Internet-Adresse www.harmankardon.com.

Ihr BDT-Player ist mit den Regionsinformationen kompatibel, die auf den meisten Blu-ray- und DVD-Disks gespeichert sind. Das Gerät kann ausschließlich solche Disks abspielen, die die Regionsinformationen für die Region enthalten, in die das Gerät geliefert wurde und für deren Verkaufsregion es bestimmt ist:

Gerätemodell/ Verkaufsregion	Blu-ray Disk-Regionalcode	DVD-Regionalcode
BDT 3/USA, Kanada		
BDT 30/Europa, Naher Osten		
BDT 30/Korea, Südostasien		
BDT 3/Mexiko, Lateinamerika		
BDT 30/Australien, Neuseeland		
BDT 30/Russland, Indien		
BDT 30/China		

So spielen zum Beispiel BDT 3-Player, die in die USA geliefert und dort verkauft wurden, nur Blu-ray Disks mit dem Regionalcode A und DVD-Disks mit dem Regionalcode 1 ab.

Ist das eingelegte Medium mit einem anderen Regionalcode versehen, wird es vom BDT-Player nicht wiedergegeben.

BDT 3/BDT 30-Leistungsmerkmale

Anschlüsse

- Ein HDMI-Anschluss
- Ein Anschluss für koaxialen Digitalaudioausgang
- Analoge Audioausgangsanschlüsse rechts und links
- Ein Composite Video-Ausgangsanschluss
- Eine USB 2.0-Buchse für den Anschluss von USB-Speichergeräten mit Videos, Ton- und Bilddateien
- Netzwerkanschluss (LAN) für die Wiedergabe von BD-Live-Inhalten aus dem Internet

Bedienfreundlichkeit

- Bildschirm-Menüsystem
- Abblendbare Punktmatrix-Anzeige an der Gerätevorderseite
- Fernbedienung mit vielen Funktionen

Wiedergabefunktionen

- HDMI 1.4a mit 3-D und 30/36-Bit Deep Color
- Regionalcode: Blu-ray Disc Region A/DVD Region 1 (BDT 3-Modelle); Blu-ray Disc Region B/DVD Region 2 (BDT 30-Modelle);
- Wiedergabe von Datenträgern mit 12 oder 8 cm Durchmesser
- Unterstützte Videoformate: BD-Video (Single-Layer oder Double-Layer), BD-R, BD-RE, DVD-Video, DVD+R/+RW, DVD-R/-RW, CDDA (CD Digital Audio), CD-R/RW
- Unterstützte Audioformate: Dolby® Digital, Dolby Digital Plus, Dolby TrueHD, DTS® Digital, DTS-HD™ High Resolution Audio, DTS-HD Master Audio™, CDDA (CD Digital Audio), PCM, CBR @ 192kbps, VBR @355 kbps, MP3 32kbps – 320kbps sowie variable Abtastrate
- CEC (Consumer Electronics Control) mit grundlegender Steuerung von HDMI/CEC
- Unterstützt JPEG-Bilddateien
- Unterstützt interaktive BD-Live-Inhalte
- Skalierung von Videosignalen auf 720p und 1080p (Full HD)
- Videoausgabe ohne Zeilensprung (Progressive Scan)
- Unterstützte JPEG-Auflösung: 4000 x 5000 Pixel (B x H), max. 20M Pixel
- Bildrotation von JPEG-Bildern in 90°-Schritten
- Miniaturansichten der JPEG-Bilder
- Schneller Vorlauf: 2x, 4x, 8x, 16x, 32x
- Wiedergabe in Zeitlupe: 1/2x, 1/4x, 1/8x, 1/16x
- Wiedergabe in zufälliger Reihenfolge (nur Audio-CDs)
- Wiederholautomatik
- Kindersicherung mit frei wählbarem Passwort
- Automatische Erkennung von bis zu 10 Disks
- Wählbares Bildformat (Seitenverhältnis)

Lieferumfang

Sollte etwas fehlen, wenden Sie sich bitte an den Kundendienst von Harman Kardon. Besuchen Sie uns im Internet unter www.harmankardon.com.

Fernbedienung





Zwei AAA-Batterien

HDMI-Kabel



Netzkabel

(Hinweis: Das beigelegte Netzkabel kann von Land zu Land variieren.)

Bedienelemente an der Vorderseite



Betriebsanzeige: Wenn der BDT 3/BDT 30 an eine Steckdose angeschlossen und sein Netzschalter auf der Rückseite auf "On" gestellt ist, leuchtet die LED *orange* - der BD-Spieler befindet sich im Stand-by-Modus. Haben Sie den BDT 3/BDT 30 mit der Power-Taste an der Fernbedienung vollständig eingeschaltet, leuchtet diese LED *weiß*.

Power-Taste: Mit dieser Taste können Sie den BDT 3/BDT 30 einschalten und wieder in den Stand-by-Modus versetzen.

Diskeinschub: Hier können Sie eine kompatible Disk einlegen. Der BDT 3/BDT 30 akzeptiert Datenträger mit einem Durchmesser von 12 cm und 8 cm.

Diskeinschub öffnen/schließen: Taste zum Öffnen und Schließen des Diskeinschubs. Bitte sorgen Sie dafür, dass keine Gegenstände den Einschub blockieren, bevor Sie die Taste betätigen.

Wiedergabetaste: Mit dieser Taste starten Sie die Wiedergabe der eingelegten Disk. Betrachten Sie gerade Bilder, können Sie mit dieser Taste die Wiedergabe aller Bilddateien im aktuellen Ordner beginnen (Diashow).

Pausentaste: Drücken Sie auf diese Taste, um die Wiedergabe der eingelegten Disk anzuhalten. Beim Abspielen einer Blu-ray Disc oder konventionellen DVD wird dabei das Bild eingefroren. Betätigen Sie erneut diese Taste, fährt der BD-Spieler mit der Wiedergabe fort. Werden gerade JPEG-Bilder angezeigt, wird das aktuell angezeigte Foto eingefroren.

Stopptaste: Drücken Sie auf diese Taste, um die Wiedergabe zu beenden. (Bei manchen Disks können Sie danach durch Drücken auf die Wiedergabetaste genau an der gleichen Stelle fortfahren.) Drücken Sie zweimal auf Stopp, um die Wiedergabe vollständig zu beenden.

Informationsanzeige: In dieser Anzeige können Sie Meldungen und andere Statusinformationen ablesen, wie bereits in diesem Handbuch beschrieben wurde.

Titelsprung/Einzelbild rückwärts: Drücken Sie auf diese Taste einmal, um zum Beginn des aktuellen Titels oder Kapitels bzw. zum vorherigen Foto zu springen. Wenn Sie diese Taste zweimal drücken, beginnt die Wiedergabe am Anfang des vorherigen Titels bzw. Kapitels. Drücken Sie diese Taste mehrmals, um durch die vorherigen Titel bzw. Kapitel nach der gewünschten Stelle zu suchen (Suchlauf rückwärts). Wird gerade ein Video wiedergegeben, können Sie auch Bildweise (Frame) nach der gewünschten Stelle suchen. Drücken Sie dazu während der laufenden Wiedergabe auf Pause und danach auf diese Taste.

Titelsprung/Einzelbild vorwärts: Drücken Sie auf diese Taste einmal, um zum Beginn des nächsten Titels oder Kapitels bzw. zum nächsten Foto zu springen. Drücken Sie diese Taste mehrmals, um durch die nächsten Titel bzw. Kapitel nach der gewünschten Stelle zu suchen (Suchlauf vorwärts). Wird gerade ein Video wiedergegeben, können Sie auch bildweise (Frame) nach der gewünschten Stelle suchen: Drücken Sie dazu während der laufenden Wiedergabe auf die Pausentaste und danach auf diese Taste.

USB-Anschluss: Führen Sie vorsichtig einen USB-Stick oder den Stecker einer externen USB-Festplatte mit einem Kabel vom Typ A in diese Buchse.

WICHTIG: Schließen Sie hier keinen PC oder einen anderen USB-Host/- Controller an - Sie könnten unter Umständen beide Geräte beschädigen.

Richten Sie den Stecker so aus, dass er einwandfrei und vollständig in den USB-Anschluss des BDT 3/BDT 30 gleitet. Sie können jederzeit den USB-Stecker aus der Buchse ziehen – Sie müssen vorher kein bestimmtes Verfahren einhalten.

Anschlüsse auf der Rückseite



HINWEIS: Siehe Abschnitt *BD-Spieler anschließen* auf Seite 10. Dort finden Sie detaillierte Informationen zum Verbinden mit anderen Geräten.

Netzschalter: Damit schalten Sie das Netzteil des BDT 3/BDT 30-Spielers aus und wieder ein. Nachdem Sie den Player an die gewünschten Geräte angeschlossen und die Verbindungen geprüft haben (siehe *BD-Spieler anschließen* auf Seite 10), stellen Sie diesen Schalter auf die Position "Ein". Verwenden Sie das Gerät längere Zeit nicht, sollten Sie den Netzschalter auf "Off" stellen - damit ist der BD-Spieler vollständig ausgeschaltet.

Netzkabel-Anschlussbuchse: Haben Sie alle Kabelverbindungen hergestellt und überprüft, können Sie hier das Stromkabel anschließen. Stecken Sie das andere Ende in eine *nicht geschaltete* Steckdose.

Netzwerk-Anschluss: Um interaktive BD-Live-Inhalte wiedergeben zu können, müssen Sie diesen Anschluss über Ihr Heimnetzwerk (LAN) mit dem Internet verbinden. Verwenden Sie hierzu ein Kabel vom Typ Cat. 5/Cat. 5e/RJ45-Netzwerkkabel. Siehe Abschnitt *Interaktive BD-Live-Inhalte* auf Seite 15, dort erhalten Sie weitere Informationen.

Koaxialer Digitalaudio-Ausgangsanschluss: Verbinden Sie diese Buchse mit dem koaxialen Digitaleingang Ihres AV-Receivers bzw. Surround-Prozessors. HINWEIS: Wenn Ihr AV-Receiver oder Surround-Prozessor über einen HDMI-Anschluss verfügt, ist es empfehlenswert, diesen zu verwenden, da er eine überlegene Tonqualität bietet.

Analoge Audio-Ausgangsanschlüsse: Verbinden Sie diese Anschlüsse mit den analogen Audioeingängen Ihres AV-Receivers, Surround-Prozessors oder analogen Recorders.

Composite Video-Ausgangsanschluss: Verbinden Sie diesen Ausgang mit dem Composite Video-Eingang Ihres TV-Geräts oder AV-Receivers. HINWEIS: Wenn Ihr AV-Receiver oder Surround-Prozessor über einen HDMI-Anschluss verfügt, ist es empfehlenswert, diesen zu verwenden, da er eine überlegene Bildqualität bietet.

HDMI-Ausgangsanschluss: Verbinden Sie den HDMI-Ausgang des BD-Spielers mit dem HDMI-Eingang Ihres Fernsehgeräts, Ihres AV-Receivers oder Surround-Prozessors. Das HDMI-Kabel überträgt sowohl Video als auch Audio. Wenn Sie es also direkt an das TV-Gerät anschließen und den koaxialen Digitalausgang des BDT 3/BDT 30 mit einem Heimkinoaudiosystem verbinden, empfehlen wir Ihnen, den HDMI-Audioausgang des BDT 3/BDT 30 zu deaktivieren, um die überlegene Audioleistung des Heimkinoaudiosystems zum Tragen zu bringen. Siehe Abschnitt *Toneinstellungen: Tonausgang* auf Seite 13, dort erhalten Sie weitere Informationen.

WICHTIG: Ihr BDT 3/BDT 30-Spieler ist kompatibel zum HDCP-Standard (High Definition Copy Protection). Auch Ihr TV-Gerät muss diesem Standard entsprechen, wenn Sie Signale über den HDMI-Eingang einspeisen wollen. Um die Wiedergabequalität nicht zu gefährden, sollte das HDMI-Kabel nicht länger als 3 Meter sein. Hat Ihr Fernsehgerät einen DVI-Eingang, benötigen Sie einen passenden HDMI-zu-DVI-Adapter zur Übertragung von Videosignalen. (Die DVI-Schnittstelle überträgt ausschließlich Videosignale.)

Lüfteröffnung: Der BDT 3/BDT 30-Spieler hat einen Lüfter, der für die nötige Kühlung im Gehäuse sorgt. Stellen Sie bitte sicher, dass keine Gegenstände die Lüfteröffnung blockieren und damit die Kühlung beeinträchtigen.

Funktionen der Fernbedienung



Hauptschalter Ein: Mit dieser Taste schalten Sie den BDT 3/BDT 30 aus dem Standby-Modus vollständig ein.

Öffnen/Schließen-Taste: Taste zum Öffnen und Schließen des Diskeinschubs. Bitte sorgen Sie dafür, dass keine Gegenstände den Einschub blockieren, bevor Sie die Taste betätigen.

Hauptschalter Aus: Mit dieser Taste schalten Sie den BDT 3/BDT 30 wieder zurück in den Standby-Modus.

Einstellungen-Taste: Drücken Sie auf diese Taste, um das Settings-Menü aufzurufen. Siehe Abschnitt *Menü "Settings" (Einstellungen)* auf Seite 12, dort erhalten Sie weitere Informationen.

Optionen-Taste: Drücken Sie auf diese Taste, um alle für den gerade markierten Eintrag verfügbare Optionen anzuzeigen.

Home-Taste: Mit dieser Taste springen Sie aus jedem Untermenü ins Hauptmenü zurück.

Kamerawinkel-Taste: Mit dieser Taste schalten Sie durch alle auf der eingelegten Disk verfügbaren Kamerawinkelspuren. HINWEIS: Die Einstellmöglichkeiten können von Disk zu Disk variieren. Nicht alle Disks sind mit mehreren Kamerawinkelspuren ausgestattet bzw. gestatten den Spurwechsel per Kamerawinkeltaste.

Tonspurtaste: Mit dieser Taste schalten Sie durch alle auf der eingelegten Disk verfügbaren Tonspuren. HINWEIS: Die Einstellmöglichkeiten können von Disk zu Disk variieren. Nicht alle Disks sind mit mehreren Tonspuren ausgestattet bzw. gestatten den Spurwechsel per Tonspurtaste.

Wiederholtaste: Spielt der BDT 3/BDT 30 eine Blu-ray Disc oder DVD-Disk ab, können Sie mit dieser Taste eine der folgenden Wiederholfunktionen aktivieren: Kapitel, Titel, Alle oder Aus. Spielt der BDT 3/BDT 30 eine Audio-CD, stehen Ihnen folgende Wiederholfunktionen zur Verfügung: Track, Alle und Aus. HINWEIS: Die Einstellmöglichkeiten können von Disk zu Disk variieren. Nicht alle Disks verfügen über eine Wiederholfunktion.

Untertiteltaste: Mit dieser Taste schalten Sie durch alle auf der eingelegten Disk verfügbaren Untertitelspuren. HINWEIS: Die Einstellmöglichkeiten können von Disk zu Disk variieren. Nicht alle Disks sind mit mehreren Untertitelspuren versehen.

Abschnitt wiederholt abspielen: Drücken Sie auf diese Taste, um die Abschnitt-wiederholfunktion zu aktivieren. Beim ersten Tastendruck legen Sie den Beginn des Abschnitts (A) fest. Betätigen Sie die Taste erneut, um das Abschnittsende (B) anzugeben - gleich darauf beginnt der BD-Player mit der Wiedergabe des definierten Abschnitts. Drücken Sie ein drittes Mal auf diese Taste, um die Wiederholfunktion auszuschalten.

Suchfunktionstaste: Drücken Sie auf diese Taste, um die Suchfunktion zu aktivieren. Geben Sie den gewünschten Titel, das Kapitel oder die Spielzeit ein, und der BD-Spieler springt die angegebene Stelle auf der Disk an.

Pausetaste: Drücken Sie auf diese Taste, um die Wiedergabe einer Musik-Datei zu unterbrechen. Beim Abspielen einer Blu-ray Disc oder konventionellen DVD wird dabei das Bild eingefroren. Betätigen Sie erneut diese Taste, fährt der BD-Spieler mit der Wiedergabe fort. Werden gerade JPEG-Bilder angezeigt, wird das aktuell angezeigte Foto eingefroren.

PIB-Taste: Drücken Sie auf diese Taste, um einen zweiten Video-Stream während der Wiedergabe einer Blu-ray Disc mit Bonusinhalten abzuspielen.

Titelsprung/Einzelbild rückwärts: Drücken Sie einmal auf diese Taste, um zum Beginn des aktuellen Titels bzw. zum vorherigen Foto zu springen. Wenn Sie diese Taste zweimal drücken, beginnt die Wiedergabe am Anfang des vorherigen Titels. Betätigen Sie diese Taste mehrmals, um zu den nächsten Titeln bzw. Kapiteln zu springen. Wird gerade ein Video wiedergegeben, können Sie auch bildweise nach der gewünschten Stelle suchen: Drücken Sie dazu während der laufenden Wiedergabe auf Pause und danach auf diese Taste.

Titelsprung/Einzelbild vorwärts: Drücken Sie einmal auf diese Taste, um zum Beginn des nächsten Titels bzw. zum nächsten Foto zu springen. Betätigen Sie diese Taste mehrmals, um zu den nächsten Titeln bzw. Kapiteln zu springen. Wird gerade ein Video wiedergegeben, drücken Sie bitte auf "Pause" und dann auf diese Taste, um bildweise (per Frame) weiterzuschalten.

Stopptaste: Drücken Sie auf diese Taste, um die Wiedergabe zu beenden. (Bei manchen Disks können Sie danach durch Drücken auf die Play-Taste genau an der gleichen Stelle fortfahren.) Drücken Sie zweimal auf Stopp, um die Wiedergabe vollständig zu beenden. HINWEIS: Manche Einstellungen und Funktionen sind nur dann verfügbar, wenn die Wiedergabe vollständig beendet ist.

Suchlauf/Zeitlupe rückwärts: Drücken Sie auf diese Taste, um durch den aktuellen Titel rückwärts nach der gewünschten Stelle zu suchen. Bei der Wiedergabe von Blu-ray Disc und DVD-Disks können Sie durch wiederholtes Betätigen der Taste die Rücklaufgeschwindigkeit bestimmen: 2x, 4x, 8x, 16x und 32x. Ist die Wiedergabe unterbrochen (Pause), können Sie mit dieser Taste das aktuelle Programm rückwärts in Zeitlupe abspielen: 1/2, 1/4, 1/8, 1/16 und wieder normale Geschwindigkeit.

Suchlauf/Zeitlupe vorwärts: Drücken Sie auf diese Taste, um durch den aktuellen Titel vorwärts nach der gewünschten Stelle suchen. Bei der Wiedergabe von Blu-ray Discs und DVD-Disks können Sie durch wiederholtes Betätigen der Taste die Vorlaufgeschwindigkeit bestimmen: 2x, 4x, 8x, 16x und 32x (normale Geschwindigkeit). Ist die Wiedergabe unterbrochen (Pause), können Sie mit dieser Taste das aktuelle Programm vorwärts in Zeitlupe abspielen: 1/2, 1/4, 1/8, 1/16 und wieder normale Geschwindigkeit.

Wiedergabetaste: Mit dieser Taste starten Sie die Wiedergabe der eingelegten Disk bzw. der im Bildschirmmenü ausgewählten Musik-Datei. Betrachten Sie gerade Bilder, können Sie mit dieser Taste die Wiedergabe aller Bilddateien im aktuellen Ordner beginnen (Diashow).

Exit-Taste: Drücken Sie auf diese Taste, um zum vorherigen Menü bzw. zur vorherigen Menüebene zu gelangen.

Popup-Menü-Taste: Wird gerade eine Blu-ray Disc oder DVD-Disk abgespielt und Sie drücken auf diese Taste, wird das Disk-Menü auf dem Bildschirm angezeigt. HINWEIS: Die Einstellmöglichkeiten können von Disk zu Disk variieren. Nicht alle Disks haben ein Popup-Menü. Ist dies bei der DVD der Fall und Sie betätigen die Popup- Menu-Taste, wird das Disk-Menü auf dem Bildschirm angezeigt.

OK-Taste: Mit dieser Taste bestätigen Sie den gerade markierten Eintrag im Bildschirmmenü.

Navigationstasten: Mit diesen Pfeiltasten navigieren Sie durch die Bildschirmmenüs des BD-Spielers.

Display-Taste: Mit dieser Taste aktivieren Sie die Status-Anzeige - hier können Sie Informationen über die gerade laufende Disk oder Datei ablesen.

Top Menu-Taste: Mit dieser Taste können Sie das Top-Menü der eingelegten BD- bzw. DVD-Disk aufrufen. HINWEIS: Die Einstellmöglichkeiten können von Disk zu Disk variieren. Nicht alle DVDs haben ein Top-Menü. Ist dies bei der DVD der Fall und Sie betätigen die Top Menu-Taste, wird das Disk-Menü auf dem Bildschirm angezeigt.

Lesezeichen (grüne Taste): Drücken Sie diese Taste, um die Lesezeichen-Funktion zu aktivieren. Siehe Abschnitt *Lesezeichen-Funktion* auf Seite 15, dort erhalten Sie weitere Informationen.

Programmiertaste (rote Taste): Drücken Sie diese Taste, um eine programmierte Abspielliste für die aktuelle Disk zu erstellen. Siehe Abschnitt *Zusammenstellen einer eigenen Abspielfolge* auf Seite 15, dort erhalten Sie weitere Informationen.

Bild vergrößern (blaue Taste): Drücken Sie auf diese Taste, um das gerade spielende Video- bzw. Standbild zu vergrößern oder zu verkleinern. Mit den Pfeiltasten lässt sich sogar der Ausschnitt verändern. HINWEIS: Diese Funktion ist diskabhängig. Sie steht nicht bei allen Disks zur Verfügung.

Miniaturansicht (gelbe Taste): Drücken Sie bei laufender Diashow auf diese Taste, werden alle Bilder des aktuellen Ordners in Miniaturansicht auf dem Bildschirm angezeigt.

Farbige Funktionstasten (Rot, Grün, Gelb und Blau): Wenn der BDT 3/BDT 30 eine Blu-ray Disc abspielt, können über diese Tasten je nach Disk unterschiedliche Menüs und Funktionen aufgerufen werden. Informationen hierzu finden Sie in den Menüanweisungen zu jeder Disk. HINWEIS: Diese Blu-ray Disc-Funktionen setzen alle vom Benutzer programmierten Lesezeichen-, Miniaturansicht-, Programm- und Zoom-Funktionen außer Kraft.

Zahlenfeld: Über dieses Zahlenfeld können Sie Ziffern eingeben.

Display-Helligkeit: Mit dieser Taste schalten Sie durch die unterschiedlichen Helligkeitsstufen für das Display an der Gerätevorderseite: 100 %, 50 %, 25 %, Auto/ Aus. Haben Sie die Helligkeit ausgeschaltet, so schaltet das Display übergangsweise auf volle Helligkeit um, wenn Sie eine der Tasten auf der Fernbedienung betätigen.

Löschtaste: Drücken Sie auf diese Taste, um eine über das Zahlenfeld gemachte falsche Eingabe zu löschen.

BD-Spieler anschließen

HDMI-Anschluss verkabeln

Wenn Ihr Receiver/Prozessor einen HDMI-Eingang hat

Verbinden Sie den HDMI-Ausgang am BD-Player mit dem HDMI-Eingang am AV-Receiver/Prozessor - verwenden Sie hierzu das beigelegte HDMI-Kabel. Verbinden Sie danach den HDMI-Ausgang am AV-Receiver/Prozessor mit einem weiteren HDMI-Kabel mit dem HDMI-Eingang an Ihrem TV-Gerät.



Wenn Ihr Receiver/Prozessor keinen HDMI-Eingang hat

Verbinden Sie den HDMI-Ausgang am BD-Player mit dem HDMI-Eingang an Ihrem TV-Gerät - verwenden Sie hierzu das beigelegte HDMI-Kabel.

Verbindung über koaxialem Digitalaudioausgang

Wenn Sie den HDMI-Ausgang des BDT 3/BDT 30 nicht mit dem Receiver/Prozessor verbunden haben, verbinden Sie den koaxialen Digitalaudioausgang mit dem koaxialen Digitaleingang Ihres Receivers/Prozessors.



Verbindungen über analogen Audioausgang

Verbinden Sie die analogen Audioausgabeanschlüsse des BDT 3/BDT 30 mit den analogen Audioeingängen Ihres Receivers/Prozessors oder den analogen Audioeingängen Ihres analogen Recorders.

Verbindungen über Composite Video-Ausgang

Wenn Sie den HDMI-Ausgang des BDT 3/BDT 30 nicht mit Ihrem TV-Gerät oder Ihrem Audio-/Video-Receiver verbunden haben, verbinden Sie den Composite Video-Ausgang des BD-Players mit dem Composite Video-Eingang Ihres TV-Geräts oder Audio-/Video-Receivers.

Netzwerk-Anschluss

Verwenden Sie ein Cat. 5/RJ45-Netzwerkkabel (nicht im Lieferumfang enthalten), um den BDT 3/BDT 30 über Ihren DSL-Router, Netzwerk-Verteiler (Switch), Ihr DSL-Modem oder das Heimnetzwerk mit dem Internet zu verbinden. HINWEIS: Der BDT 3/BDT 30 kann mit keinem anderen Gerät in Ihrem Netzwerk Verbindung aufnehmen. Den Netzwerkzugang benötigen Sie für die Wiedergabe von BD-Live-Inhalten mit dem BDT 3/BDT 30. Weitere Infos finden Sie im Abschnitt "Interaktive BD-Live-Inhalte" auf Seite 15.



Netzkabel-Anschlussbuchse (AC Input)

Der BDT 3/BDT 30 ist mit einem abnehmbaren Netzkabel ausgestattet. Das ist während der Verkabelung umfangreicher Heimkino-Systeme besonders praktisch.

HINWEISE:

- Die Betriebsspannung für den BDT 3/BDT 30 beträgt 110 - 240 V Wechselstrom bei 50/60 Hz, die Leistungsaufnahme beträgt 25 Watt. Der Anschluss des Geräts an eine Steckdose mit abweichender Spannung könnte den BD-Spieler beschädigen oder zu unerwartetem Verhalten führen.
- Bitte überprüfen Sie alle Kabelverbindungen Ihres BD-Spielers, bevor Sie das Netzkabel in eine Steckdose stecken.
- Stecken Sie den Stecker des Player-Netzkabels in die Buchse des abnehmbaren Netzkabels des BDT 3/BDT 30. Stecken Sie den Stecker des Netzkabels in eine funktionstüchtige, *nicht geschaltete* Steckdose.



Stellen Sie den Netzschalter auf der Rückseite des BDT 3/BDT 30 auf "On". Kurz darauf leuchtet die Betriebsanzeige gelb auf - der BD-Spieler befindet sich dann im Stand-by-Modus.

Fernbedienung in Betrieb nehmen

Batterien einlegen

Die Fernbedienung des BDT 3/BDT 30 wird mit zwei AAA-Batterien betrieben (im Lieferumfang enthalten). Legen Sie die Batterien wie in der Abbildung gezeigt ein – achten Sie dabei auf korrekte Polarität.



Einsatz der Fernbedienung

Zielen Sie bitte immer mit der Fernbedienung auf die Vorderseite des BD-Spielers. Stellen Sie sicher, dass keine Objekte wie z. B. Möbelstücke die Gerätefront verdecken. Helles Licht, Leuchtstoffröhren und Plasma-Fernseher können Interferenzen hervorrufen, die den Infrarot-Empfang stören.

- Die Fernbedienung hat eine Reichweite von bis zu 6 Metern – je nachdem wie die Lichtverhältnisse im Hörraum sind.
- Die Fernbedienung funktioniert mit einer Abweichung von bis zu 30° zur Mittelachse einwandfrei.

Sollte die Fernbedienung nicht einwandfrei funktionieren, prüfen Sie bitte zuerst, ob die Batterien korrekt ins Batteriefach eingelegt sind. Besteht das Problem weiterhin, sollten Sie die Batterien austauschen.

DEUTSCH

BD-Spieler konfigurieren

HINWEIS: Die in dieser Bedienungsanleitung abgebildeten Bildschirmmenüs dienen lediglich illustrativen Zwecken und können von denen Ihres BD-Spielers abweichen.

Für die Konfiguration des BDT 3/BDT 30 benötigen Sie die Fernbedienung, um durch die Bildschirmmenüs zu navigieren und Einstellungen vorzunehmen.

- Mit den Pfeiltasten nach oben und unten navigieren Sie durch die Menüeinträge. Der gerade ausgewählte Eintrag wird durch einen Rahmen kenntlich gemacht.
- Mit der OK-Taste wird der gerade markierte Eintrag bestätigt. Daraufhin wird auf dem Bildschirm das ausgewählte Untermenü angezeigt.
- Drücken Sie auf die Exit-Taste, um zum vorherigen Menü zurückzukehren.

Setup Wizard (Konfigurations-Assistent):

Beim erstmaligen Einschalten des BDT 3/BDT 30 wird der Konfigurations-Assistent auf dem Bildschirm angezeigt.


Page: 1/5
Setup Wizard
Welcome to the Harman Kardon BDT Setup Wizard.
Some simple information is needed to ensure you get the best experience from your product.
You can adjust these settings later in addition to making changes to more advanced settings by pressing the 'Settings' button on the remote.
OK Next

Er hilft Ihnen dabei, ein paar Grundeinstellungen (z. B. Menüsprache) vorzunehmen, damit die Videoausgabe des BDT 3/BDT 30 ordnungsgemäß mit Ihrem TV-Gerät funktioniert. Drücken Sie auf die OK-Taste – auf dem Bildschirm wird das Menü zur Wahl der Menüsprache angezeigt.



Wählen Sie die gewünschte Sprache und quittieren Sie mit "OK" – auf dem Bildschirm wird nun das Menü zur Wahl der TV-Auflösung angezeigt.


Page: 3/5
Setup Wizard
Please select the highest resolution that your TV supports. If you are unsure, select "Auto."
Upon making a selection the screen will be changed to the chosen resolution. You will be presented with the option to continue with the new resolution or "Cancel" to return to the previous resolution. If the screen remains blank, please wait 15 seconds without pressing anything and the system will automatically return to the previous resolution.
Auto
480i/576i
480p/576p
720p
1080i
1080p
Previous
OK Next

Markieren Sie mit den Pfeiltasten die zu Ihrem Fernsehgerät passende Auflösung und bestätigen Sie mit "OK" - nun wird das Menü zur Wahl des Bildseitenverhältnisses angezeigt. Sind Sie sich nicht sicher, welches Seitenverhältnis Sie wählen sollen, wählen Sie bitte "Auto" – damit überlassen Sie dem BD-Spieler die Wahl.



Bestätigen Sie mit "OK" – alle Einstellungen werden nun gespeichert. Betätigen Sie erneut durch Drücken der Taste "OK", um den Konfigurations-Assistenten zu verlassen. Weitere Informationen zu Bildformaten finden Sie unter *"Bildformat"* auf Seite 13.

Menü "Settings" (Einstellungen)

Drücken Sie auf die Settings-Taste der Fernbedienung, um das Settings-Menü des BDT-Players zu öffnen - hier können Sie wichtige Einstellungen vornehmen. Mit den Pfeiltasten nach links und rechts wechseln Sie zwischen den Einträgen des Hauptmenüs. Mit den Pfeiltasten nach oben und unten navigieren Sie durch die verschiedenen Listen und Untermenüs. Ihre Wahl bestätigen Sie immer mit der OK-Taste. Drücken Sie auf die Exit-Taste, um zum vorherigen Menü zurückzukehren.

General Settings (Allgemeine Einstellungen)



System: Im Untermenü "System" können Sie folgende Parameter konfigurieren:

- **Front Panel Brightness (Display-Helligkeit):** Stellen Sie hier die Helligkeit des Displays an der Gerätevorderseite des BDT 3/BDT 30 ein.
- **Screen Saver (Bildschirmschoner):** Mit dem Bildschirmschoner verhindern Sie, dass statische Bildstrukturen (z. B. Menüs) sich bei der Verwendung des BDT 3/BDT 30 in Ihren TV oder Plasma-Bildschirm "einbrennen".
- **Auto Power Off (Abschaltautomatik):** Legen Sie hier fest, nach wie vielen Minuten im Leerlauf der BDT 3/BDT 30 selbständig in den Stand-by-Modus umschaltet.
- **CEC:** Wenn diese Option auf "On" gesetzt ist, können Sie die CEC-Funktionen zur Wiedergabe oder zum Standby-Betrieb durch Drücken nur einer Taste aktivieren oder deaktivieren.
- **Funktionen zur Wiedergabe oder zum Standby-Betrieb durch Drücken nur einer Taste:** Wenn diese Optionen auf "On" gesetzt sind, kann der BDT 3/BDT 30 durch Befehle von der Fernbedienung eines TV-Geräts, das an den HDMI-Ausgang des Players angeschlossen ist, in den Wiedergabe- oder Standby-Modus versetzt werden.
- **System Upgrade (Systemaktualisierung):** In diesem Untermenü können Sie die Software des BDT 3/BDT 30 auf den neuesten Stand bringen - sie steht auf den Webseiten von Harman Kardon zum Herunterladen zur Verfügung.
- **Setup Wizard (Konfigurations-Assistent):** Diese Option aktiviert den Konfigurations-Assistenten des BDT 3/BDT 30 (siehe *Setup Wizard (Konfigurations-Assistent):* auf Seite 11).
- **BD-Live Storage (BD-Live-Speicherung):** Mit dieser Option legen Sie fest, wo der BDT 3/BDT 30 BD Live-Inhalte speichern soll. Sie können den Inhalt auf einem USB-Speichergerät über den USB-Port des BDT 3/BDT 30 speichern. Siehe Abschnitt *Interaktive BD-Live-Inhalte* auf Seite 15, dort erhalten Sie weitere Informationen.
- **Restore Defaults (Werkseinstellungen wiederherstellen):** Mit diesem Befehl stellen Sie den Auslieferungszustand des BDT 3/BDT 30 wieder her. HINWEIS: Mit dieser Option setzen Sie auch das Passwort für die Kindersicherung wieder zurück (Voreinstellung: 0000, Siehe Abschnitt *Parental Control (Kindersicherung)* auf dieser Seite.

Language (Sprache): Hier lässt sich die Sprache für die Bildschirmmenüs, die Menüführung der eingelegten Disk sowie die bevorzugte Tonspursprache und Untertitelsprache festlegen.

- HINWEIS: Sollte die hier angewählte Sprache auf der eingelegten Disk nicht verfügbar sein, können Sie über das Menüsystem der Disk die gewünschte Sprache festlegen.

Playback (Wiedergabe): Im Untermenü "Playback" (Wiedergabe) können Sie folgende Parameter konfigurieren:

- **Kamerawinkel-Symbol (Show Angle Icon):** Legen Sie fest, ob das Kamerawinkel-Symbol auf dem Bildschirm angezeigt werden soll, wenn die eingelegte Disk Szenen aus mehreren Perspektiven anbietet.
- **Auto Play (Automatische Wiedergabe):** Hier können Sie bestimmen, ob eine Disk automatisch wiedergegeben werden soll, sobald sie eingelegt wird.
- **Show PIP Icon (Bild-in-Bild-Symbol):** Legen Sie fest, ob das Bild-in-Bild-Symbol (PIP) auf dem Bildschirm angezeigt werden soll, wenn Sie eine Blu-ray Disc abspielen, die entsprechende Inhalte anbietet.
- **Show Secondary Audio Icon (Alternative Tonspur-Symbol):** Legen Sie fest, ob das Alternative Tonspur-Symbol (PIP) auf dem Bildschirm angezeigt werden soll, wenn die eingelegte Disk zusätzliche Tonspuren anbietet.
- **Disc Resume (Wiederaufnahme):** Hier können Sie bestimmen, dass eine Disk, die bei laufender Wiedergabe mit der Auswurftaste (Eject) entnommen wurde, an der gleichen Stelle mit der Wiedergabe fortfährt, wenn sie wieder eingelegt wird. HINWEIS: Die Einstellmöglichkeiten können von Disk zu Disk variieren. Die Wiederaufnahme wird nicht von allen Disks unterstützt.
- **DivX® VOD DRM:** Hier geben Sie Ihre Registrierungsdaten für die Wiedergabe DivX-codierter Inhalte ein.

Parental Control (Kindersicherung): Hier können Sie das Passwort für die integrierte Kindersicherung sowie die entsprechende Schutzstufe festlegen. HINWEIS: Das voreingestellte Passwort lautet 0000.

Network (Netzwerk): In diesem Untermenü können Sie folgende Parameter konfigurieren:

- **Information (Info):** Hier können Sie die aktuelle IP-Adresse, die Subnetzmaske, das Gateway und die DNS-Adressen Ihres Netzwerks einsehen.
- **Test Connection (Verbindung testen):** Mit diesem Befehl können Sie die Netzwerkverbindung Ihres BDT 3/BDT 30 testen.
- **IP Configuration (Netzwerk-Konfiguration):** Hier können Sie die Netzwerkeinstellungen (automatisch oder manuell) vornehmen. Verwenden Sie die Auto-Option, es sei denn, Sie haben von Ihrem Administrator Einstellungen erhalten.
- **BD-Live Connection (BD-Live-Verbindung):** Hier können Sie die BD-Live-Verbindungsvoreinstellungen des BDT 3/BDT 30 vornehmen. Mit der Einstellung "Always Allow" (Immer zulassen) werden BD-Live Inhalte grundsätzlich und ohne Rückfrage heruntergeladen. Bei der Einstellung "Limit" (Beschränken) werden nur dann BD-Live-Inhalte empfangen, wenn die eingelegte Disk auch offiziell BD-Live-zertifiziert ist. Mit "Prohibited" (Nie zulassen) wird der BD-Live-Zugriff blockiert. Siehe Abschnitt *Interaktive BD-Live-Inhalte* auf Seite 15, dort erhalten Sie weitere Informationen.
- **Proxy Setting (Proxy-Einstellung):** Läuft der Internetzugriff über einen Proxy-Server, müssen Sie diesen Parameter auf "Enabled" (Aktiviert) setzen und danach die Adresse samt Portnummer Ihres Proxy-Hosts eingeben. Ist kein Proxy vorhanden, stellen Sie bitte diesen Parameter auf "Disabled" (Deaktiviert). Diese Einstellung sollten nur fortgeschrittene Benutzer ändern - in den meisten Heimnetzwerken ist die Einstellung "Disabled" (Deaktiviert) zutreffend.

Display-Einstellungen



TV: In diesem Untermenü können Sie folgende Parameter konfigurieren:

- **Aspect Ratio (Bildformat):** Hier können Sie festlegen, wie Programmmaterial mit einem Seitenverhältnis von 4:3 (konventionelles TV) auf einem Fernseher mit 16:9-Format bzw. 16:9-Programmmaterial auf einem konventionellen 4:3-Fernseher dargestellt werden soll. Die Einstellung "16:9 Full" dehnt 4:3-Material so weit aus, bis es den 16:9-Bildschirm ausfüllt. Im "16:9 Normal"-Modus wird 4:3-Material im richtigen Seitenverhältnis auf dem 16:9-Bildschirm dargestellt, wobei links und rechts schwarze Balken angezeigt werden. Im "4:3 Pan & Scan"-Modus wird Widescreen-Material formatfüllend auf einem 4:3-TV dargestellt. Im "4:3 Letterbox"-Modus wird 16:9-Programmmaterial passend und ohne Verzerrungen mit schwarzen Balken oben und unten dargestellt.
- **Resolution (Auflösung):** Mit dieser Option können Sie die Videoausgabeauflösung des BDT 3/BDT 30 auswählen. Die Einstellung "Auto" wählt automatisch die beste Auflösung für Ihr TV-Gerät.
- **Color Space (Farbraum):** Hier können Sie einen der voreingestellten Farbräume für die Video-Wiedergabe festlegen.
- **Film Mode (Filmmodus):** Wenn Ihr Flachbildfernseher Signale im Format 1080p und mit einer Bildwiederholfrequenz von einem ganzzahligen Mehrfachen von 24 wiedergeben kann, sollten Sie diesen Parameter auf "On" setzen, um die eingelegte Blu-ray Disc in voller Qualität zu genießen, die in 24 Bildern pro Sekunde aufgezeichnet ist. Kann Ihr Flachbildfernseher keine 1080p/24 Hz-Signale verarbeiten, stellen Sie diesen Parameter bitte auf "Off" - der BDT 3/BDT 30 wird dann das vorliegende Programmmaterial auf die standardmäßige Bildwiederholrate von 30 Hz umwandeln.
- **HDMI Deep Color (HDMI-Farbtiefe):** Hier können Sie die Farbtiefe am HDMI-Ausgang zum TV-Gerät hin justieren. Beherrscht Ihr TV-Gerät den Deep Color-Modus, sollten Sie diese Betriebsart aktivieren und die Vorteile der erweiterten Farbpalette nutzen.
    - On: Der BDT 3/BDT 30 gibt das Videosignal immer mit 36-Bit oder 30-Bit Deep Color aus.
    - Off: Der BDT 3/BDT 30 gibt das Videosignal mit 24-Bit Deep Color aus.
- **TV Standard (TV-Standard):** Mit dieser Option können Sie den Standard Ihres TV-Displays festlegen.
    - Auto: Der BDT 3/BDT 30 legt den Standard für Ihr TV-Gerät automatisch fest.
    - PAL: Legt die Videoanzeige auf den Standard PAL fest.
    - NTSC: Legt die Videoanzeige auf den Standard NTSC fest.
- **HDMI 3D:** Diese Option bestimmt, wie der Player mit 3D-Programmen umgeht, wenn er über den HDMI-Anschluss an einen 3D-fähigen Fernseher angeschlossen ist.
    - Auto: Der BDT 3/BDT 30 zeigt Video automatisch in 3D an, wenn das Programm im 3D-Format vorliegt.
    - Off: Der BDT 3/BDT 30 zeigt Video nicht in 3D an.

Video Processing (Videonachbearbeitung): Legen Sie hier fest, wie das Videosignal vom BDT 3/BDT 30 vor der Weitergabe an das Fernsehgerät nachbearbeitet wird.

- **Video Mode (Videomodus):** Hier können Sie eines der voreingestellten Videonachbearbeitungsprofile auswählen, mit denen Sie die Helligkeit, den Kontrast, die Farbsättigung und die Bildschärfe regulieren.
    - Standard: Neutrale Einstellungen
    - Vivid (Kräftig): Optimal für Videospiele
    - Cinema (Kino): Optimal für die Wiedergabe von Videofilmen und für viele TV-Sendungen
    - Custom (Benutzerdefiniert): Mit dieser Option können die Videoeinstellungen manuell angepasst werden. Hierzu stehen Ihnen Schieberegler für Helligkeit, Farbsättigung, Farbton und Kontrast zur Verfügung. Die Standardeinstellung ist jeweils 0. Verwenden Sie die Navigationstasten, um den Wert einer Einstellung zu ändern.

Toneinstellungen (Audio Settings)



Audio Output (Tonausgang): In diesem Untermenü stehen Ihnen folgende Einträge zur Verfügung:

- **HDMI Audio Out (HDMI-Tonausgang):** Der HDMI-Ausgang am BDT 3/BDT 30 kann neben Video- auch Tonsignale übertragen. Vier Möglichkeiten stehen zur Wahl:
    - Auto: Bei dieser Einstellung sendet der BD-Spieler Tonsignale über den HDMI-Ausgang aus. Das Datenformat wird dem hier angeschlossenen Gerät automatisch angepasst.
    - Bitstream Native (Bitstream ursprünglich): In diesem Modus sendet der BD-Spieler das Tonsignal im ursprünglichen Format an den HDMI-Ausgang.
    - PCM: Bei dieser Einstellung erzeugt der BD-Spieler aus dem Mehrkanal-Datenstrom einen Stereo-Downmix und schickt ihn an den HDMI-Ausgang.
    - Off: Damit schalten Sie die Tonausgabe des BDT-Players über HDMI aus. Wenn Sie den HDMI-Ausgang nur zur Übertragung von Videosignalen verwenden, sollten Sie den Parameter "HDMI Audio Out" auf "Off" stellen. Die Tonsignale gelangen in diesem Fall über den koaxialen Digitalausgang zum AV-Receiver/Prozessor Ihres Heimkinos.
- **Coaxial Output (Koaxialer Ausgang):** Wollen Sie das Tonsignal ausschließlich über den koaxialen Digitalausgang an Ihr Heimkino-System weitergeben, verwenden Sie bitte eine der folgenden drei Optionen:
    - Bitstream Native (Bitstream ursprünglich): Bei dieser Einstellung sendet der BD-Spieler das unveränderte Original-Tonformat an den koaxialen Digitalausgang.
    - PCM: In diesem Modus erzeugt der BDT 3/BDT 30 aus dem Mehrkanal-Datenstrom der BD- oder DVD-Disk einen Stereo-Downmix und schickt ihn an den koaxialen Digitalausgang. (Siehe Abschnitt *PCM Downsampling* weiter unten.)
    - Transcode (Transcodieren): In diesem Modus wandelt der BD-Player die verlustfreien Mehrkanal-Formate Dolby TrueHD und DTS-HD Master Audio in ein verlustbehaftetes Format und sendet es an den koaxialen Digitalausgang.
- **PCM Downsampling:** Hier können Sie festlegen, mit welcher Abtastrate das Stereo-PCM-Signal errechnet werden soll. Stellen Sie hier bitte die höchste Abtastrate ein, die der angeschlossene Receiver bzw. Prozessor verarbeiten kann. HINWEIS: Kann das Gerät am koaxialen Digitalausgang Signale mit einer Abtastrate von 192 kHz verarbeiten, stellen Sie bitte diesen Parameter auf "Off" - das Signal wird dann unverändert weitergegeben.

- **Dynamic Range Ctrl:** Mit dieser Option können Sie den Dynamikumfang steuern.
  - Auto: Der BDT 3/BDT 30 legt den dynamischen Bereich automatisch fest, und zwar basierend auf dem Lautstärkebereich der Audioquelle.
  - On: Der BDT 3/BDT 30 aktiviert den dynamischen Bereich immer.
  - Off: Der BDT 3/BDT 30 deaktiviert den dynamischen Bereich immer.

Menü "Information"



In diesem Menü wird die aktuelle Firmware-Version und die vom Hersteller zugewiesene MAC-Netzwerk-Adresse des BDT 3/BDT 30 angezeigt. Dieses Untermenü dient lediglich Informationszwecken - es sind keine Änderungen möglich.

Disk-Wiedergabe

Hinweise zur Handhabung von Disks

- Halten Sie die Disk immer an den Rändern, um Fingerabdrücke und andere Verschmutzung von der Datenschicht fernzuhalten. Berührend Sie nicht die Datenschicht (Unterseite der Disk).



- Bringen Sie keine Etiketten oder Klebestreifen an. Finden Sie auf der Datenseite Kleberreste oder ähnliche Substanzen, müssen Sie diese vollständig entfernen, bevor Sie die Disk abspielen.
- Setzen Sie die Disk nicht direktem Sonnenlicht oder einer anderen Hitzequelle aus. Lassen Sie keine Datenträger im Auto liegen, da bei Sonneneinstrahlung im Inneren eines Fahrzeugs hohe Temperaturen entstehen können.
- Bewahren Sie Disks grundsätzlich in ihrer Hülle auf – nicht im Laufwerk Ihres BD-Players.
- Verwenden Sie zum Beschriften der Disk keine Kugelschreiber oder andere spitze Schreibgeräte.
- Lassen Sie die Disk nicht fallen bzw. verbiegen Sie sie nicht.

Hinweise zur Reinigung von Disks

- Sie sollten die Disk vor dem Abspielen mit einem trockenen, fusselfreien Tuch reinigen. Wischen Sie immer von der Mitte nach außen.
- Verwenden Sie niemals chemische Mittel wie Benzin, Lösungsmittel, handelsübliche Reinigungsmittel oder antistatische Sprühmittel für Vinyl-LPs.

Regionalcodes

Ihr BDT-Player ist mit den Regionsinformationen kompatibel, die auf den meisten Blu-ray- und DVD-Disks gespeichert sind. Ist das eingelegte Medium mit einem anderen Regionalcode versehen, wird es vom BDT-Player nicht wiedergegeben.

Die vollständigen Informationen über die Regionsinformationen Ihres Geräts sind im Kasten auf Seite 5 angegeben.

Copyright

Ton- und Videomaterial kann dem Schutz geistigen Eigentums unterliegen und darf in diesem Fall nicht ohne entsprechende Genehmigung kopiert werden. Bitte informieren Sie sich über die in Ihrem Land geltenden Richtlinien und Gesetze.

Kopierschutz

Ihr BDT-Player ist kompatibel zum HDCP-Standard (High Definition Copy Protection). Ein am HDMI-Ausgang angeschlossener Flachbildfernseher muss ebenfalls HDCP-konform sein.

Der BDT-Player verwendet Kopierschutz-Technologien. Haben Sie eine geschützte BD- oder DVD-Disk eingelegt und versuchen, das Programmmaterial mit einem Videorecorder zu kopieren, wird die Videokassette nicht richtig funktionieren.

Unterstützte Diskformate

Der BDT-Player kann die folgenden Disktypen (der Größen 12 cm und 8 cm) wiedergeben:

- BD-Video (Ein- und Zweiseitige Datenträger)
- DVD-Video:
- DVD+R/+RW
- DVD-R/-RW
- CDDA (CD Digital Audio)
- CD-R/-RW

HINWEIS: Die Kompatibilität und Leistungsfähigkeit von doppelseitigen Disks wird nicht garantiert.

Unterstützte Media-Codecs

Der BD-Spieler kann Programmmaterial abspielen, das in folgenden Audio-/Videoformaten vorliegt:

- MPEG 1, Layer 1
- MPEG 2, Layer 2
- MPEG 2, Layer 3
- H.264
- VC-1
- AAC
- MP3 (auf CD-R/RW, DVD+R/+RW, BD-R/RE und USB)
- JPEG (auf CD-R/RW, DVD+R/+RW, BD-R/RE und USB)
- DivX 3.x/4.x/5.x (auf CD-R/RW, DVD+R/+RW und USB)

HINWEIS: Es sind viele Kombinationen von Formaten auf einer Disk möglich - der BDT 3/BDT 30 kann aber unter Umständen nicht alle abspielen. Gekaufte BD- und DVD-Disks sind mit vielen Sonderfunktionen ausgestattet, müssen aber nicht alle Möglichkeiten des BD-Spielers ausschöpfen. Ein Beispiel: Der Player kann Disks mit mehreren Kamerawinkeln abspielen. Die Funktion steht aber nur dann zur Verfügung, wenn die eingelegte Disk auch entsprechende Videospuren anbietet. Welche Tonspuren bzw. Sprachen die Disk bereithält, können Sie der Verpackung entnehmen.

Die Wiedergabemöglichkeit selbst gebrannter Medien hängt von deren Qualität und dem verwendeten Brennlaufwerk ab.

Disks einlegen und abspielen

Drücken Sie auf die Auswurftaste, um den Diskeinschub zu öffnen, und legen Sie die gewünschte Disk ein. Drücken Sie erneut auf die Auswurftaste, um den Diskeinschub zu schließen.

- Legen Sie nie mehr als eine Disk in den Diskeinschub.
- Legen Sie die Disk mit der beschrifteten Seite nach oben ein.

Drücken Sie auf die Wiedergabetaste, um mit der Wiedergabe zu beginnen.

Verwenden Sie zur Steuerung der Wiedergabe von Disks die Tasten "Wiedergabe", "Pause", "Stopp", "Titelsprung vorwärts/rückwärts" und "Suchlauf vorwärts/rückwärts". Siehe Abschnitt *Funktionen der Fernbedienung* auf Seite 9, dort finden Sie weitere Informationen zu den Funktionen dieser Tasten.

Wiedergabefunktionen

Repeat (Wiederholen): Spielt der BDT 3/BDT 30 eine Blu-ray Disc oder DVD-Disk ab, können Sie mit dieser Taste einen der folgenden Wiederholungsmodi aktivieren: Kapitel, Titel, Alle oder Aus. Wird gerade eine Audio-CD abgespielt, stehen Ihnen folgende Wiederholungsmodi zur Verfügung: Track, Alle und Aus. HINWEIS: Die Wiederholungsfunktion ist nicht bei allen Blu-ray Discs verfügbar.

A-B (Abschnittwiederholung): Spielt der BDT 3/BDT 30 eine Blu-ray Disc, DVD-Disk oder Musik-CD ab, können Sie mit dieser Taste einen Abschnitt festlegen und ihn wiederholt abspielen: Beim ersten Tastendruck legen Sie den Beginn des Abschnitts (A) fest. Betätigen Sie die Taste erneut, um das Abschnittsende (B) zu markieren - gleich darauf beginnt der BD-Player mit der Wiedergabe des definierten Abschnitts. Drücken Sie ein drittes Mal auf die A-B-Taste, um den jeweiligen Wiederholungsmodus auszuschalten. HINWEIS: Nicht alle Blu-ray Discs gestatten diese Wiederholungsmodi.

Find (Suchen): Drücken Sie auf diese Taste, um die Suchfunktion zu aktivieren. Geben Sie den gewünschten Titel, das Kapitel oder die Spielzeit ein, und der BD-Spieler spielt die angegebene Stelle auf der Disk ab. Siehe Abschnitt *Suchtaste* auf Seite 9, dort erhalten Sie weitere Informationen. HINWEIS: Blockiert die gerade eingelegte Disk die hier beschriebene Suchfunktion, können Sie dennoch über das diskeigene Menüsystem das gewünschte Kapitel ansteuern.

Options (Optionen): Drücken Sie auf diese Taste, um alle für die eingelegte Disk verfügbaren Optionen anzuzeigen. Bei Blu-ray Discs erscheinen die Optionen "Titel", "Kapitel", "Spielzeit", Tonspuren", "Kamerawinkel", "Untertitel". Ferner werden PIP-Optionen, Optionen für eine zweite Audiospur und die Abtastrate, Standbildoptionen, Optionen für schnellen Vorlauf und wiederholte Szenenwiedergabe angezeigt. Bei DVD-Disks erscheinen die Optionen "Titel", "Kapitel", "Spielzeit", "Wiedergabemodi", "Tonspuren", "Kamerawinkel" sowie Optionen für die Abtastrate, Standbildoptionen und Optionen für schnellen Vorlauf und wiederholte Szenenwiedergabe. Wird eine Audio-CD wiedergegeben, erscheinen die Optionen "Titelauswahl", "Spielzeit", "Wiedergabemodi", "Abtastrate", "Suchen" und "Wiederholen".

Display-Taste: Spielt der BDT 3/BDT 30 eine Blu-ray Disc oder DVD-Disk ab, können Sie mit dieser Taste die Statusanzeige ein- und wieder ausschalten.



Top Menu (Top Menu-Taste): Mit dieser Taste können Sie das Menü der eingelegten BD- bzw. DVD-Disk aufrufen. HINWEIS: Die Einstellmöglichkeiten können von Disk zu Disk variieren. Nicht alle DVDs haben ein Top-Menü. Hat die aktuelle DVD kein Top-Menü, wird stattdessen das Disk-Menü angezeigt. Dies hängt von der entsprechenden Disk ab.

Popup (Popup-Taste): Durch Drücken dieser Taste während der Wiedergabe eine Blu-ray Disc oder DVD-Disk wird das Popup-Menü angezeigt.

Bookmark (Lesezeichen): Mit dieser Funktion können Sie bis zu 12 Stellen auf der eingelegten Disk markieren. Drücken Sie auf diese Taste, um die aktuelle Stelle auf der Disk zu markieren. Um ab einer der mit der Lesezeichenfunktion markierten Stellen abzuspielen, halten Sie die Lesezeichentaste gedrückt, wodurch die Lesezeichenliste angezeigt wird. Wählen Sie nun mit den Pfeiltasten das gewünschte Lesezeichen und bestätigen Sie mit "OK" - der BD-Spieler beginnt sofort mit der Wiedergabe ab der gewünschten Position.

HINWEIS: Diese Funktion steht nicht bei allen Disks zur Verfügung. Nicht alle Disks unterstützen die Lesezeichenfunktion.

Programmed Play (Abspielfolge): Hier können Sie für die eingelegte CD-, DVD- oder BD-Disk eine eigene Abspielfolge programmieren: HINWEIS: Nicht alle Blu-ray Discs unterstützen die Abspielfolge-Funktion.

1. Drücken Sie dazu auf die Program-Taste. Auf dem Bildschirm erscheint das Program-Menü (unten sehen Sie das Program-Menü einer eingelegten Musik-CD).



2. Drücken Sie auf "OK", und wählen Sie danach mit den Pfeiltasten nach oben und unten den gewünschten Titel für den ersten Programmschritt. HINWEIS: Nicht alle Blu-ray Discs gestatten die Zusammenstellung einer eigenen Abspielfolge.
3. Drücken Sie auf die Pfeiltaste nach rechts, um das gewünschte Kapitel für den ersten Programmschritt auszuwählen (gilt nur bei Blu-ray Discs oder DVD-Disk).
4. Wiederholen Sie die Schritte 2 bis 3, um die Wiedergabeliste zu vervollständigen.
5. Ist Ihre Abspielfolge fertig, drücken Sie bitte auf die Wiedergabetaste - die Wiedergabe beginnt sofort.

Interaktive BD-Live-Inhalte

BD-Live Interaktivität gibt es nur bei ausgewählten Blu-ray Discs. Wählen Sie den BD-Live-Eintrag im Menü der eingelegten Disk, um die entsprechenden Inhalte aus dem Internet auf einen mit dem USB-Anschluss des BDT 3/BDT 30 verbundenen Speicher herunterzuladen und wiederzugeben. Hierzu müssen Sie den Netzwerkanschluss auf der Geräterückseite mit Ihrem Heimnetzwerk verbinden.

HINWEIS: Ziehen Sie das USB-Speichergerät nicht ab, während BD-Live-Informationen heruntergeladen werden. Wenn Sie das Gerät abziehen und der Harman Kardon-Willkommensbildschirm angezeigt wird, drücken Sie die Wiedergabetaste, um zum Anfang der Disk zurückzukehren.

Können Sie während der Wiedergabe einer BD-Live-Disk keine Verbindung zum Internet herstellen, gehen Sie bitte wie folgt vor: Drücken Sie zuerst auf die Settings-Taste. Markieren Sie anschließend den Eintrag "Network Setup" (Netzwerkeinrichtung). Wählen Sie "Test Connection" (Verbindung testen). Wird der Test erfolgreich abgeschlossen (der BDT 3/BDT 30 konnte mit dem Internet Verbindung aufnehmen), liegt der Fehler beim Server, den die BD-Live-Disk im Internet abfragen will. Suchen Sie auf der Diskhülle nach weiteren Informationen oder nehmen Sie Verbindung mit dem entsprechenden Anbieter auf. War der Verbindungstest nicht erfolgreich, erfragen Sie bitte die korrekten Netzwerk-Einstellungen bei Ihrem Internetdienstanbieter (ISP). Sollte das Problem weiterhin bestehen, wenden Sie sich bitte an Ihren Internetdienstanbieter.

Musik-CDs abspielen

Spielt der BDT 3/BDT 30 gerade eine Musik-CD ab, werden in der Statusleiste der Wiedergabemodus, der Disktyp, die aktuelle Titelnummer, die Gesamtanzahl der Titel und die aktuelle Spielzeit angezeigt.



Wiedergabe von USB-Medien und Daten-CDs

Der BDT 3/BDT 30 spielt folgende Datentypen ab: MP3-Dateien (mit einer Abtastrate von bis zu 320 kBit/s), AAC-Audiodateien, JPEG-Standbilder, MPEG 1 (Layer 1), MPEG 2 (Layers 2 und 3) sowie DivX® -Videodateien (Version 3.x, 4.x, 5.x), die auf einem USB-Gerät oder einer CD-Datendisk gespeichert sind.

WICHTIG: Der BDT 3/BDT 30 kann nur auf Datenträger zugreifen, die mit dem Dateisystem FAT32 formatiert sind.

Möchten Sie Inhalte von einem Gerät am USB-Anschluss wiedergeben, drücken Sie zuerst auf die Home-Taste und wählen Sie danach "USB" als Quelle.



Daraufhin werden auf dem Bildschirm drei Ordner namens "Photo", "Music" und "Video" angezeigt - die tatsächliche Ordnerstruktur auf dem Datenträger spielt keine Rolle. Wählen Sie aus diesen drei Ordnern den gewünschten Medientyp aus.



Nun zeigt der BD-Spieler die Ordnerstruktur auf dem Datenträger an. Wählen Sie den gewünschten Ordner aus und auf dem Bildschirm erscheinen alle Dateien des zuvor markierten Typs. Befinden sich Dateien des gleichen Typs im Hauptverzeichnis, werden diese ebenfalls angezeigt.

Drücken Sie auf die Pfeiltaste nach links, um in der Ordnerstruktur eine Ebene nach oben zu springen.

Fotos wiedergeben

Wählen Sie im oberen Verzeichnis "Photo" aus. Öffnen Sie anschließend den gewünschten Ordner mit den Fotos und markieren Sie eine der Bilddateien. Eine Miniaturdarstellung des gewählten Fotos wird auf der rechten Bildschirmseite angezeigt.



Verwenden Sie zur Steuerung der Bildwiedergabe folgende Tasten der Fernbedienung:

Wiedergabetaste: Drücken Sie auf diese Taste, um die automatische Wiedergabe (Diashow) der Bilder im aktuellen Ordner zu starten. Das gerade markierte Bild erscheint als erstes. Nach 15 Sekunden wird das nächste Bild aus der Liste angezeigt.

Pausentaste: Wenn Sie diese Taste drücken, wird das aktuell angezeigte Foto eingefroren. Drücken Sie auf die Wiedergabetaste, um mit der Wiedergabe fortzufahren.

Stopptaste: Drücken Sie auf diese Taste, um die Diashow zu beenden - auf dem Bildschirm erscheint wieder das aktuelle Verzeichnis.

Titelsprung vorwärts-rückwärts: Mit diesen Tasten können Sie zum nächsten bzw. vorherigen Bild in der Diashow oder im Verzeichnis springen.

Pfeiltaste nach oben: Drücken Sie bei laufender Diashow auf diese Taste, dreht der BD-Spieler das gerade angezeigte Bild um 180°. Betätigen Sie diese Taste, während die Ordnerstruktur auf dem Bildschirm dargestellt wird, um den vorherigen Verzeichniseintrag zu markieren.

Pfeiltaste nach unten: Drücken Sie bei laufender Diashow auf diese Taste, wird das gerade angezeigte Bild horizontal gespiegelt. Betätigen Sie diese Taste während die Ordnerstruktur auf dem Bildschirm dargestellt wird, um den nächsten Verzeichniseintrag zu markieren.

Pfeiltaste nach links: Drücken Sie bei laufender Diashow auf diese Taste, dreht der BD-Spieler das gerade angezeigte Bild um 90° entgegen dem Uhrzeigersinn. Betätigen Sie diese Taste während die Ordnerstruktur auf dem Bildschirm dargestellt wird, um zur nächsthöheren Verzeichnisebene zu springen.

Pfeiltaste nach rechts: Drücken Sie bei laufender Diashow auf diese Taste, dreht der BD-Spieler das gerade angezeigte Bild im Uhrzeigersinn um 90° im Uhrzeigersinn.

Optionen: Drücken Sie bei laufender Diashow auf diese Taste, wird das Optionen-Menü mit folgenden Einträgen angezeigt:

Datei: Wählen Sie eine anzuzeigende Datei aus.

Wiedergabemodus: Bestimmen Sie, wie die Dateien abgespielt werden: in der normalen Reihenfolge, in zufälliger Reihenfolge (bis Sie auf die Stopp-Taste drücken) oder in zufälliger Reihenfolge (der BD-Spieler zeigt jede Datei im aktuellen Ordner einmal in zufälliger Reihenfolge an und wechselt anschließend zur Verzeichnisansicht).

Slide Show (Diashow): Wählen Sie die Anzeigedauer für die Bilder aus. 5 Sekunden, 15 Sekunden oder 30 Sekunden.

Transition (Überblendung): Zur Verfügung stehen mehrere Überblendeffekte.

Drücken Sie auf die Options-Taste, während die Verzeichnisstruktur angezeigt wird, wird das Playlist- Options-Fenster auf dem Bildschirm angezeigt. Siehe Abschnitt *Wiedergabelisten verwenden* auf Seite 18, dort erhalten Sie weitere Informationen.

Miniaturansicht (gelbe Taste): Drücken Sie bei laufender Diashow auf diese Taste, werden alle Bilder des aktuellen Ordners in Miniaturansicht auf dem Bildschirm angezeigt. Verwenden Sie die Navigations- und OK-Tasten, um anzuzeigende Bilder zu markieren und auszuwählen.

Bild vergrößern (blaue Taste): Drücken Sie bei laufender Diashow auf diese Taste, wird die Wiedergabe gestoppt und das gerade angezeigte Bild zweifach vergrößert. Betätigen Sie diese Taste mehrmals, um den Vergrößerungsfaktor zu ändern - zur Verfügung stehen folgende Werte: 3x, 4x, 1/2x, 1/3x und 1/4x.

Tondateien abspielen

Wählen Sie in der obersten Ordnerebene den Dateityp "Music". Öffnen Sie anschließend einen Ordner mit Musikdateien, und markieren Sie eine. Auf der rechten Bildschirmseite erscheinen daraufhin Informationen zur ausgewählten Datei.



Markieren Sie eine Tondatei, wird diese sofort abgespielt. Wenn der ausgewählten Datei im Ordner weitere Musikdateien folgen, gibt der BDT 3/BDT 30 jede davon in der auf dem Bildschirm angezeigten Reihenfolge wieder. Der folgende Bildschirm wird beim Abspielen von Musikdateien angezeigt:

Ist die gerade spielende MP3-Datei mit einem Album-Cover-Art ID3-Tag versehen, erscheint das Albumcover auf dem Bildschirm.

Verwenden Sie zur Steuerung der Wiedergabe von Musikdateien die Tasten "Wiedergabe", "Pause", "Stopp", "Titelsprung vorwärts/rückwärts" und "Suchlauf vorwärts/rückwärts". Siehe Abschnitt *Funktionen der Fernbedienung* auf Seite 9, dort finden Sie weitere Informationen zu den Funktionen dieser Tasten.

Spielt der BDT 3/BDT 30 auf einem USB-Datenträger oder auf Daten-CD gespeicherte Musikdateien ab, weicht die Funktionsweise der Funktionen "Repeat" (Wiederholen) und "Options" (Optionen) von denen der Wiedergabe von Blu-ray Discs, DVDs und Musik-CDs etwas ab:

Wiederholtaste: Drücken Sie mehrmals auf diese Taste, um durch folgende Modi zu schalten: 1 (Titel), All (Ordnerinhalt), Off (Aus). Der gerade aktive Repeat-Modus wird im Statusbalken angezeigt.

Optionen: Drücken Sie auf diese Taste, um alle für den gerade spielenden Titel verfügbare Optionen anzuzeigen:

Datei: Damit können Sie eine Datei direkt für die Wiedergabe auswählen.

Spielzeit: Zeigt die aktuelle Spielzeit oder die Restspielzeit der laufenden Titel an.

Wiedergabemodus: Bestimmen Sie, wie die Musikdateien abgespielt werden: in der normalen Reihenfolge, in zufälliger Reihenfolge (bis Sie auf die Stopptaste drücken) oder in Shuffle-Reihenfolge (der BD-Spieler spielt jede Datei im aktuellen Ordner einmal in zufälliger Reihenfolge an und wechselt anschließend zur Verzeichnisansicht).

Bitrate (Abtastrate): Zeigt die Abtastrate des gerade abgespielten Titels an.

Advance (Vorwärts): Spielt den aktuellen Song mit hoher Geschwindigkeit ab.

Replay (Wiederholen): Bei jedem Betätigen der OK-Taste springt der BD-Spieler bei laufender Wiedergabe zehn Sekunden zurück.

Sie können gleichzeitig Fotos und Musikdateien wiedergeben, solange diese auf dem gleichen Datenträger gespeichert sind (USB-Datenträger oder Daten-CD). Drücken Sie - während die gewünschte Musikdatei abgespielt wird - auf die Home-Taste. Öffnen Sie danach den Ordner mit den Fotodateien. Markieren Sie das erste Foto und starten Sie die Diashow.

Videos abspielen

Wählen Sie in der obersten Ordnerebene den Dateityp "Video". Öffnen Sie anschließend einen Ordner mit Videos und markieren Sie eine Videodatei im aktiven Ordner.



Die Videodatei wird automatisch wiedergegeben. Sind im aktuellen Ordner weitere Videodateien gespeichert, werden diese vom BDT 3/BDT 30 der Reihe nach wie auf dem Bildschirm aufgelistet abgespielt.

Verwenden Sie zur Steuerung der Wiedergabe von Videodateien die Tasten "Wiedergabe", "Pause", "Stopp", "Titelsprung vorwärts/rückwärts" und "Suchlauf vorwärts/rückwärts". Siehe Abschnitt *Funktionen der Fernbedienung* auf Seite 9, dort finden Sie weitere Informationen zu den Funktionen dieser Tasten.

Spielt der BDT 3/BDT 30 auf einem USB-Datenträger oder auf Daten-CDs gespeicherte Videodateien ab, weicht die Funktionsweise der Funktionen "Repeat" und "Options" von der während der Wiedergabe von Blu-ray Discs und DVDs etwas ab:

Wiederholtaste: Drücken Sie mehrmals auf diese Taste, um durch folgende Modi zu schalten: 1 (aktuelles Video), All (Ordnerinhalt), Off (Aus).

Optionen: Drücken Sie auf diese Taste, um alle für den gerade spielenden Titel verfügbare Optionen anzuzeigen:

Datei: Wählen Sie eine Datei direkt aus - sie wird sofort wiedergegeben.

Titel: Wählen Sie einen Titel direkt aus - er wird sofort wiedergegeben (wenn verfügbar).

Kapitel: Wählen Sie ein Kapitel direkt aus - es wird sofort wiedergegeben (wenn verfügbar).

Spielzeit: Es wird die abgelaufene Spielzeit oder die Restlaufzeit des aktuellen Titels angezeigt.

Wiedergabemodus: Bestimmen Sie, wie die Videodateien abgespielt werden: in der normalen Reihenfolge, in zufälliger Reihenfolge (bis Sie auf die Stopptaste drücken) oder in Shuffle-Reihenfolge (der BD-Spieler spielt jede Datei im aktuellen Ordner einmal in zufälliger Reihenfolge an und wechselt anschließend zur Verzeichnisansicht).

Tonoptionen: Hier wählen Sie die gewünschte Tonspur (wenn verfügbar).

Wiedergabelisten verwenden

USB-Datenträger und Daten-CDs können viele Dateien enthalten. Um auch bei umfangreichen Medienarchiven den Überblick nicht zu verlieren, können Sie Wiedergabelisten zusammenstellen.

Wiedergabeliste erstellen

HINWEIS: Die Vorgehensweise ist bei Daten-CDs und USB-Datenträgern identisch:

1. Drücken Sie auf die Home-Taste. Auf dem Bildschirm erscheint das Home-Menü.
2. Wählen Sie "CD data disc" oder "USB". Die Ordner "Photo", "Music" und "Video" erscheinen auf dem Bildschirm.
3. Wählen Sie den gewünschten Dateityp für die Wiedergabeliste aus. Sie können für jeden Dateityp eine separate Wiedergabeliste erstellen.
4. Suchen Sie im Verzeichnisbaum nach den gewünschten Dateien. Markieren Sie eine Datei und drücken Sie auf die Optionstaste, um diese Datei in die Wiedergabeliste aufzunehmen. Daraufhin wird das Playlist-Options-Fenster auf dem Bildschirm angezeigt.
5. Wählen Sie "Add to Playlist", um die Datei der Wiedergabeliste hinzuzufügen.
6. Wiederholen Sie die Schritte 4 und 5, um weitere Dateien auszuwählen.

Möchten Sie eine Wiedergabeliste für einen anderen Dateityp zusammenstellen, wiederholen Sie die Schritte 1 bis 6 - wählen Sie in Schritt 3 einen anderen Dateityp.

Wiedergabeliste abspielen

1. Drücken Sie auf die Home-Taste. Auf dem Bildschirm erscheint das Home-Menü.
2. Wählen Sie den Eintrag "Playlist". Die Ordner "Photo", "Music" und "Video" werden auf dem Bildschirm angezeigt.
3. Wählen Sie den gewünschten Dateityp aus, um die entsprechende Wiedergabeliste zu öffnen. Die Wiedergabeliste wird geöffnet.
4. Wählen Sie den ersten Eintrag aus der Liste und drücken Sie auf die Wiedergabetaste. Die Wiedergabe beginnt.
5. Um eine Wiedergabeliste wiederholt abzuspielen, drücken Sie bitte auf die Wiederholtaste. Sie haben die Wahl zwischen "1" (einen Titel wiederholen) oder "All" (die gesamte Wiedergabeliste wiederholen).

Fehlerbehebung

Sollte einmal Ihr BDT 3/BDT 30 nicht so reagieren, wie Sie vielleicht erwarten, sollten Sie die hier abgebildete Checkliste durchgehen, bevor Sie sich an Ihren Fachhändler wenden.

Problem	Lösung
Der BD-Spieler lässt sich nicht einschalten (die Betriebsanzeige leuchtet nicht auf):	• Überprüfen Sie, ob das Netzkabel richtig in die Netzteilbuchse eingesteckt ist. • Überprüfen Sie, ob der BD-Spieler mit einer Strom führenden, nicht geschalteten Steckdose verbunden ist. • Überprüfen Sie, ob der Netzschalter auf der Geräterückseite eingeschaltet ("On") ist.
Die eingelegte Disk wird nicht wiedergegeben:	• Überprüfen Sie, ob die Disk richtig eingelegt wurde (bedruckte Seite nach oben). • Überprüfen Sie den Typ der eingelegten Disk: BD-Video (Single-Layer oder Double-Layer), DVD-Video, DVD+R/+RW, DVD-R/-RW, CDDA (CD Digital Audio), CD-R/RW. Andere Disktypen können nicht wiedergegeben werden.
Keine Bildwiedergabe:	• Überprüfen Sie die Verkabelung zwischen BD-Spieler und TV. • Stellen Sie bitte sicher, dass das TV-Gerät eingeschaltet und der korrekte Eingang ausgewählt ist. • Überprüfen Sie, ob die Einstellungen im Display Settings-Menü zu Ihrem Fernseher passen. • Stellen Sie sicher, dass der Fernseher HDCP-konform ist. Der BD-Spieler kann nicht mit TV-Geräten zusammenarbeiten, die nicht HDCP-konform sind.
Keine Tonwiedergabe:	• Überprüfen Sie, ob das HDMI- und/oder koaxiale Digitalkabel korrekt angeschlossen ist. • Wenn Sie für die Tonübertragung ein koaxiales Digitalkabel verwenden, müssen Sie die Einstellungen am Receiver/Prozessor/TV überprüfen. • Wenn Sie für die Tonübertragung nur das HDMI-Kabel verwenden, müssen Sie die HDMI-Audioeinstellungen am angeschlossenen Gerät überprüfen. • Wenn Sie für die Tonübertragung nur das HDMI-Kabel verwenden, muss am BDT 3/BDT 30 der Parameter HDMI Audio Output auf "On" stehen.
Das Bildformat ist falsch:	• Korrigieren Sie das Bildformat im Menü "Display Settings".
Bei der Wiedergabe von Blu-ray Discs und/oder DVD-Disks ist das Bildsignal verrauscht:	• Reinigen Sie die Disk und suchen Sie nach Kratzern.
Kein Zugriff auf den angeschlossenen USB-Datenträger möglich:	• Stellen Sie sicher, dass das Gerät im FAT32-Dateiformat formatiert ist. Andere Dateisysteme werden vom BDT 3/BDT 30 nicht unterstützt.
Der BD-Player reagiert nicht auf Befehle der Fernbedienung:	• Ersetzen Sie die Batterien der Fernbedienung - achten Sie auf korrekte Polarität. • Gehen Sie mit der Fernbedienung näher zum BD-Player. • Stellen Sie sicher, dass der Empfangssensor am BD-Player nicht durch verdeckt wird. • Stellen Sie sicher, dass die Schutzfolie von der Gerätevorderseite entfernt wurde.
Das Ø-Symbol wird auf dem Bildschirm angezeigt, sobald Sie eine Taste der Fernbedienung betätigen:	• Die gewünschte Funktion wird gerade unterdrückt.
Der BD-Player reagiert auf die Bedientasten an der Gerätevorderseite und auf der Fernbedienung gar nicht oder nur fehlerhaft:	• Trennen Sie den BD-Player vom Stromnetz. Warten Sie 30 Sekunden. Stellen Sie die Stromversorgung wieder her.

Weitere Informationen zur Fehlersuche finden Sie im Internet unter www.harmankardon.com im Abschnitt Fragen & Antworten (FAQs).

Spezifikationen

Unterstützte Diskformate:	BD-Video (Single-Layer oder Double-Layer), BD-R, BD-RE, DVD-Video, DVD+R/+RW, DVD-R/-RW, CDDA (CD Digital Audio), CD-R/RW mit 12 oder 8 cm Durchmesser
Regionalcode (BD/DVD):	
Gerätemodell/Verkaufsregion:	
BDT 3/USA, Kanada:	A/1
BDT 30/Europa, Naher Osten:	B/2
BDT 30/Korea, Südostasien:	A/3
BDT 3/Mexiko, Lateinamerika:	A/4
BDT 30/Australien, Neuseeland:	B/4
BDT 30/Russland, Indien:	C/5
BDT 30/China:	C/6
Audioformate:	Dolby Digital, Dolby Digital Plus, Dolby TrueHD, DTS Digital, DTS-HD High Resolution Audio, DTS-HD Master Audio, PCM, CBR @ 192kbps, VBR @355 kbps, MP3 32kbps – 320kbps sowie variable Abtastrate
Standbild-Format:	JPEG
Video-Standard:	NTSC (BDT 3); PAL (BDT 30)
HDMI-Version:	HDMI 1.4a mit 3-D und 30/36-Bit Deep Color
Betriebsspannung:	110 – 240 V Wechselstrom bei 50/60 Hz
Stromverbrauch:	max. 25 W, <0,5 W im Standby-Modus
Abmessungen (H x B x T):	66 mm x 440 mm x 352 mm
Gewicht:	3,7 kg

HARMAN

HARMAN Consumer, Inc.
8500 Balboa Boulevard, Northridge, CA 91329 USA
516.255.4545 (nur in den USA)

Hergestellt in China

© 2011 HARMAN International Industries, Incorporated. Alle Rechte vorbehalten.

Harman Kardon ist eine Marke von HARMAN International Industries, Incorporated, eingetragen in den USA und/oder anderen Ländern. Blu-ray Disc und BD-Live sind Marken der Blu-ray Disc Association. DivX®, DivX Certified® und die damit verbundenen Logos sind Marken von DivX, Inc. und werden in Lizenz verwendet. ÜBER DIVX VIDEO: DivX® ist ein von der DivX, Inc. entwickeltes digitales Videoformat. Das vorliegende Gerät ist für die Wiedergabe DivX-codierter Inhalte offiziell zertifiziert. Weitere Informationen sowie Software zur Konvertierung von Videodateien ins DivX-Format finden Sie im Internet unter www.divx.com. ÜBER DIVX VIDEO ON DEMAND: Sie müssen dieses DivX Certified® -Gerät zuerst registrieren, bevor Sie DivX Video-on-Demand (VOD)-Inhalte abspielen. Den Registrierungsschlüssel erzeugen Sie im Setup-Menü, Abschnitt VOD. Gehen Sie mit diesem Code zur Website vod.divx.com, um den Registrierungsvorgang abzuschließen und noch mehr Wissenswertes über DivX VOD zu lernen. Hergestellt in Lizenz der Dolby Laboratories. Dolby ist eine eingetragene Marke von Dolby Laboratories. Hergestellt in Lizenz unter Verwendung folgender US-Patente: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535 & und anderer in den USA bzw. weltweit eingetragener oder & beantragter Patente. DTS ist eine eingetragene Marke, DTS-HD und DTS-HD Master Audio sind Marken der DTS, Inc. Das Produkt umfasst auch Software. © DTS, Inc. Alle Rechte vorbehalten. HDMI, das HDMI-Logo und High-Definition Multimedia Interface sind eingetragene Marken der HDMI Licensing LLC. In diesem Produkt kommen Kopierschutz-Technologien zum Einsatz, die von Patenten und anderen Rechten auf geistiges Eigentum in den USA geschützt werden. Die Nutzung dieser Technologien muss von der Rovi Corporation genehmigt werden. Das Einsatzgebiet beschränkt sich auf den Heimbereich, es sei denn, es liegt eine entsprechende Genehmigung der Rovi Corporation vor. Das Zerlegen dieser Einheit mit dem Ziel, Reverse Engineering zu betreiben, ist verboten.

Änderungen an Merkmalen, Spezifikationen und Aussehen können ohne vorherige Ankündigung erfolgen.

Teilenr. -- Rev.: Abschnitt

harman/kardon® by HARMAN

www.harmankardon.com